Index

A

Absolute base address p-sects
  changing number of, 2–21
ALPH00.FNT, 2–7
..ALRG, 2–53
ALTMDE, 2–22
ARDPS, 2–44
..ATDK, 2–37
..ATFX, 2–37
Auto installation file
  list of (table), 2–6

B

BA.MAC, 2–8
Bad block replacement
  in user-written handlers, 2–44
Banner pages
  changing default width of, 2–42
BATCH
  modifying to save disk space, 2–27
BATCH.SAV, 2–5
BHALT, 2–31
BINCOM.SAV, 2–4
..BLDS, 2–19
Bootstrap
  installing on diskette, 6–6
  installing on RX02, 7–5
  installing on working system, 3–4, 4–5, 5–5, 8–7
  loading software, B–1
  magtape
    list of (table), 2–7
Bootstrap loader
  RK05 address and contents, B–8
  RK06 address and contents, B–13
  RK07 address and contents, B–13
  RL01 address and contents, B–14
  RL02 address and contents, B–14
  RX11 address and contents, B–9
  RX211 address and contents, B–16
  TJU16 address and contents, B–11
Bootstrap loader (Cont.)
  TM11 address and contents, B–11
  TSV05 address and contents, B–18
Bootstrap message
  changing, 2–36
  suppressing, 2–35
Bootstrapping the system
  in less than 16K words, 2–31
BSTRAP.MAC, 2–8
BSTRNG, 2–36
BUP
  Changing acceptable number of bad blocks, 2–34
BUP.SAV, 2–4

C

..CMDS, 2–54
Components
  arranging on small working system, 2–15
CONFIG
  RMON fixed offset 300
    $FBMON bit, 2–64
CONFIG.COM, 2–9
CONFIG.SAV, 2–9
CONSOL.MAC, 2–9
CREF
  changing page listing length, 2–48
CREF.SAV, 2–4
CUSTOM.TXT, 2–9
  customization symbol values, 2–18
Customizations
  for distributed monitors, 2–18
  software
    getting symbol values for, 2–18
  table of, 1–4

D

DATIME.MAC, 2–9
DATIME.SAV, 2–10
DBGSYM.SAV, 2–7
Debuggers

Debuggers (Cont.)
list of (table), 2–7
Default device
assigning, 2–15
changing for EDIT command, 2–38
changing for FRUN command, 2–37
changing for indirect command files, 2–36
changing for QUEMAN, 2–39
DEMOB1.BAS, 2–7
DEMOBG.MAC, 2–7
DEMOF1.FOR, 2–7
DEMOF2.FOR, 2–7
DEMOF3.FOR, 2–7
DEMOFG.MAC, 2–7
DEMOKD.TXT, 2–7
DEMOM1.MAC, 2–7
Demonstration programs
creating volumes for, 2–17
list of (table), 2–7
Density
changing for magtape, 2–27
Device handlers
choosing for peripheral devices, 2–13
choosing for working system, 2–12
controller installed at nonstandard address, 2–24
list of (table), 2–2
renaming, 2–24
user-written
bad block replacement for, 2–45
for magtapes, 2–46
when bootstrap doesn't install, 2–24
Devices
assigning default to data, 2–15
installing nonstandard, 2–23
..DIAL, 2–32
DIAL command
using with VTCOM, 2–32
DIBOL
LINK change requirement, 2–22
DIFFERENCES/CHANGEBAR command, 2–18
DIR
changing default number of columns in, 2–19
changing default order of listings, 2–20
DIR.SAV, 2–4
DIRECTORY command, 2–11
Directory listings
Directory listings (Cont.)
changing default number of columns in, 2–19
reading, 2–11
sorting
changing default of, 2–20
Directory segments
changing default number of, 2–41
Disk distribution kit
backing up, 5–2, 6–2
bootstrapping, 5–1, 6–1
copying bootstrap to system volume, 5–4, 6–4
initializing backup volume, 5–3, 6–3
installing
bootstrapping distribution volume, 5–1
installing on disk, 5–1
installing on small device, 6–1
unprotecting backup volumes, 5–4, 6–4
Disk distribution kit to disk
if SYSGEN required, 5–12
Disk distribution kit to small device
if SYSGEN required, 6–14
Diskettes
installing system to run on, 3–1, 6–1
sizes of (table), 2–11
Distribution kit
disk
installing on disk, 5–1
installing on small device, 6–1
files on (table), 2–2
magtape
installing on disk, 8–1
RX01
installing on disk, 4–1
installing on small devices, 3–1
RX50
installing on Professional 300 Series, 9–1
D keyboard command
use of above background job, 2–39
DL.MAC, 2–8
DL.SYS, 2–2
DLX.SYS, 2–2
DM.MAC, 2–8
DM.SYS, 2–2
DMX.SYS, 2–2
..DOFF, 2–47
..DPFX, 2–55
..DSFX, 2–56

DU.MAC, 2–8
DU.SYS, 2–2
DUMP.SAV, 2–4
DUP.SAV, 2–4
DUX.SYS, 2–2
DW.MAC, 2–8
DW.SYS, 2–2
DWX.SYS, 2–2
DX.MAC, 2–8
DX.SYS, 2–2
DXX.SYS, 2–2
DY.MAC, 2–8
DY.SYS, 2–2
DYX.SYS, 2–3
DZ.MAC, 2–8
DZ.SYS, 2–3
DZX.SYS, 2–3

E

EDBITS, 2–50
..EDDV, 2–38
EDIT
  with nonstandard ESCAPE codes, 2–22
EDIT.SAV, 2–4
EDIT keyboard command
  changing default file name for, 2–39
  file type
    changing default, 2–38
Editors
  See Text editors
EDTG.MAC, 2–7, 2–8
E keyboard command
  use of above background job, 2–39
EL.MAC, 2–8
ELCOPY.MAC, 2–8
ELINIT.MAC, 2–8
ELTASK.MAC, 2–8
..EMON, 2–39
Errors
  fatal
    preventing reset from, 2–30
ERROUT.OBJ, 2–8
ERROUT.SAV, 2–5
ERRTXT.MAC, 2–8

F

..FAST, 2–54
FATAL, 2–30
Fatal errors
  preventing reset from, 2–30
FB.MAC, 2–8
$FBMON bit, 2–64
FB monitor
  features of, 1–2
Files
  distributed
    list of (table), 2–2
  size of
    setting upper limit on, 2–33
File types
  default
    changing for FRUN command, 2–38
    changing for indirect command files, 2–37
FILEX.SAV, 2–4
Foreground/background monitor
  See FB monitor
FORMAT.SAV, 2–4
..FRDK, 2–37
FRUN keyboard command
  changing default device for, 2–37
  file type
    changing default, 2–38
..FRUX, 2–38
FSM.MAC, 2–8
Fully-mapped monitor
  See ZM monitor

G

GIDIS.SAV, 2–4
..GON, 2–65
Graphics
  list of files for (table), 2–7

H

Handler files
  magtape (table), 2–26
Handlers
  See Device handlers
Hardware magtapes
  installing support for, 2–25
..HELF, 2–43
HELP.EXE
  creating from HELP.SAV, 2–28
HELP.SAV, 2–4
HELP.TXT

HELP.TXT (Cont.)
creating from HELP.SAV, 2–28
HELP file
changing default device for, 2–43
changing default file name for, 2–43
HELP package, 2–13
Help text
modifying, 2–28

I

I/O page
depositing in, 2–39
examining, 2–39
IND
changing default device for, 2–44
Changing default file type, 2–34
changing default to, 2–48
Eliminating or changing terminating message, 2–46
suppressing dynamic allocation of a region for, 2–53
IND.SAV, 2–4
INDEX.IDX, 2–5
INDEX.SAV, 2–4
INDEXA.IMG, 2–6
INDEXB.IMG, 2–6
INDEXX.SAV, 2–4
..INDF, 2–34
Indirect command files
changing default device for, 2–36
file type
changing default, 2–37
nesting
changing depth, 2–40
start-up
choosing for working system, 2–14
suppressing, 2–35
suppressing echo, 2–36
using IND with, 2–48
..INDN, 2–44
..INDR, 2–48
Installation
customization
features available through, 1–4
disk distribution kit to disk, 5–1
disk distribution kit to small device, 6–1
magtape distribution kit to disk, 8–1
Manual or automatic?, 1–1
preparation for, 2–1
Installation (Cont.)
procedure, 1–1
reading path for, 1–11
RX01 distribution to disk, 4–1
RX01 distribution to small device, 3–1
RX02 distribution kit to RX02, 7–1
survey of procedures, 2–1
test of working system on disk, 4–8, 5–7
test of working system on RX02, 7–7
test of working system on small device, 3–6, 6–9
Introduction to RT–11
creating volumes for, 2–17
..IRDF, 2–63
..IRDM, 2–63
..IRDX, 2–63
IVP.MAP, 2–6

J

..JDEV, 2–59
..JOU, 2–57
..JSIZ, 2–58

K

KED
Adjusting journal file size, 2–58
Automatic journaling, 2–57
Forcing a journal device, 2–59
modifying default file type, 2–51
Modifying maximum LEARNs, 2–60
Modifying storage capacity for LEARN, 2–60
Restoring LOCAL form feed, 2–61
KED.SAV, 2–4
KEX
Adjusting journal file size, 2–58
Automatic journaling, 2–57
Forcing a journal device, 2–59
limiting memory requested by, 2–49
Modifying maximum LEARNs, 2–60
Modifying storage capacity for LEARN, 2–60
Restoring LOCAL form feed, 2–61
KEX.SAV, 2–4
Keypad editor
See KED.SAV
KMON.MAC, 2–8
KMOVLY.MAC, 2–8
..28KW, 2–35

L

LCBITS, 2–50
..LCCH, 2–64
..LCFF, 2–61
LD
  changing default logical disk file type, 2–47
  Handler suffix customization, 2–19
LD.MAC, 2–8
LD.SYS, 2–3
..LDEX, 2–47
LDX.SYS, 2–3
LIBR.SAV, 2–4
Libraries
  list of (table), 2–7
Library modules
  increasing number of for LINK, 2–21
Line printer handlers
  changing CSR addresses in, 2–24
  changing vectors in, 2–24
  choosing for working system, 2–13
LINK
  changing default output to 132-column, 2–52
  changing size of library module list, 2–21
  changing size of library module list of, 2–21
  Making /G option a default, 2–65
  modifying listing page length, 2–43
  modifying to change default SYSLIB device, 2–28
LINK.SAV, 2–5
LINPPG, 2–43
LMLSIZ, 2–22
Load maps
  changing default page length for, 2–43
LP.MAC, 2–8
LP.SYS, 2–3
  choosing, 2–13
  renaming, 2–13
LPX.SYS, 2–3
LS.MAC, 2–8
LS.SYS, 2–3
  choosing, 2–13
  renaming, 2–13
LSX.SYS, 2–3

M

..MACN, 2–61
MACRO.SAV, 2–5
MACRO assembler
  changing default .ENABLE/.DISABLE options, 2–50
  changing default .LIST/.NLIST options, 2–49
  changing page listing length, 2–48
  files required for, 2–13
  increasing default work file size of, 2–52
..MACS, 2–60
magtape distribution kit
  bootstrapping, 8–2
  if SYSGEN required, 8–15
Magtape distribution kit
  installing on disk, 8–1
  preserving, 8–4
Magtapes
  Also see Magtape distribution kit, 2–66
  Changing default label size, 2–66
  changing parity and density of, 2–27
  Creating a master (distribution), 8–6
  handler files (table), 2–26
  hardware
    installing support for, 2–25
  user-written handlers for, 2–45
Mapped monitors, 1–3
  See also XM monitor, ZM monitor
..MAXM, 2–49
..MBAD, 2–34
MBOOT.BOT, 2–7
MBOT16.BOT, 2–7
MDUP.AI, 2–5
MDUP.MM, 2–5, 8–2
  device support, A–1
MDUP.MS, 2–5, 8–2
  device support, A–1
MDUP.MT, 2–5, 8–2
  device support, A–1
MDUP.MU, 2–5, 8–2
MDUP.SAV, 2–5
  nonstandard device support,modifying for, A–1
MDUPMT, 2–46
Memory
  running in less than available, 2–31
  size of
    setting upper limit on, 2–35
MM.SYS, 2–3
MMHD.SYS hardware magtape handler, 2–25

MMHDX.SYS hardware magtape handler, 2–25
MMX.SYS, 2–3
Monitor map files
  customization symbol values, 2–18
Monitors
  See also SB monitor, FB monitor, XM monitor, and ZM monitor
  customizations available for
    descriptions of, 2–18
  customizations available for (table), 1–4
  depositing in, 2–39
  distributed
    choice of, 1–3
    features available in (table), 1–3
    list of (table), 2–2
  examining, 2–39
  selection of for working system, 2–12
MONMRG.SAV, 2–5
MS.SYS, 2–3
MSB.COM, 2–6, 8–5
MSBOOT.BOT, 2–7, 8–2
MSCP bootstrap, B–4
  address and contents of, B–6
  loading using MICRO-ODT, B–4
  loading using switch register, B–5
MSCPCK.SAV, 2–5
MSCP disks
  assigning unit numbers to, 2–24
  changing CRS addresses in, 2–24
  changing vectors in, 2–24
  partitioning, 2–24
MSHD.SYS hardware magtape handler, 2–25
MSHDX.SYS hardware magtape handler, 2–25
MSX.SYS, 2–3
MT.SYS, 2–3
MTB.COM, 2–6, 8–5
MTDPS, 2–45
MTHD.SYS hardware magtape handler, 2–25
MTHDX.SYS hardware magtape handler, 2–25
..MTLS, 2–66
MTTEMT.MAC, 2–8
MTTINT.MAC, 2–8
MTX.SYS, 2–3
MU.SYS, 2–3
MUB.COM, 2–6, 8–6
MUX.SYS, 2–3

N

..NB1, 2–42
..NB2, 2–43
..NB3, 2–43
NC.MAC, 2–8
NCX.SYS, 2–3
Nesting depth
  indirect command files
    changing, 2–40
NI.MAC, 2–8
..NIND, 2–36
NITEST.MAC, 2–10
NL.MAC, 2–9
NL.SYS, 2–3
NLX.SYS, 2–3
NQ.MAC, 2–9
NQX.SYS, 2–3
NU.MAC, 2–9
NUX.SYS, 2–3

O

ODT
  creating a monitor-independent, 2–58
ODT.OBJ, 2–7
Output ring buffer
  increasing space requirement in to resume job, 2–40
Overlaid utilities
  on system volume, 2–16

P

Parity
  changing for magtape, 2–27
PAT.SAV, 2–5
PGSIZE, 2–48
PI.SYS, 2–3
PIP.SAV, 2–5
PIPMT, 2–45
PIX.SYS, 2–3
Professional 300 Series
  installing on, 9–1
    bootstrapping system diskette, 9–2
    compressing system disk, 9–4
    copying distribution to system disk, 9–3
    creating working system, 9–4
    customizing the system, 9–4
    formatting hard disk, 9–2

Professional 300 Series
installing on (Cont.)
if SYSGEN required, 9–11
installing bootstrap on system disk, 9–3
testing working system, 9–6
PROGDF, 2–39
Program sections
See P-sects
P-sects
absolute base address
changing number of, 2–21

Q

QSIZE, 2–22
QSWNUM, 2–21
QUEMAN
changing default device for, 2–39
QUEMAN.SAV, 2–5
choosing for working system, 2–14
QUEUE
allowing first form feed, 2–47
QUEUE.REL, 2–5
changing size of work file, 2–22
choosing for working system, 2–14
QUEUE work file
changing size of, 2–22
..QULP, 2–40

R

Reading path
for installation, 1–11
RESORC.SAV, 2–5
Ring buffer
output
increasing space requirement in to resume job, 2–40
RK.MAC, 2–9
RK.SYS, 2–3
RK05
loading bootstrap, B–8
RK06
loading bootstrap, B–12
RK07
loading bootstrap, B–12
RK11 DECpack
See RK05
RKX.SYS, 2–3
RL01
loading bootstrap, B–14
RL02
loading bootstrap, B–14
$RMON, 2–33
RMON.MAC, 2–9
RT11AI.SYS monitor, 2–2
RT11FB.SYS monitor, 2–2
RT11MT.SYS monitor, 2–2
RT11SB.SYS monitor, 2–2
RT11XB.SYS monitor, 2–2
RT11XM.SYS monitor, 2–2
RT11ZB.SYS monitor, 2–2
RT11ZM.SYS monitor, 2–2
RTFB.MAP, 2–6
RTMON.REL, 2–10
RTSB.MAP, 2–6
RTXM.MAP, 2–6
RTZM.MAP, 2–6
RX01 diskette
device name, 2–11
initializing and formatting, 6–5
size of, 2–11
RX01 distribution kit
bootstrapping distribution volume, 3–1
copying bootstrap to system volume, 3–4
copying distribution to system disk, 4–2
Customizing, 3–4
if SYSGEN required, 4–1, 4–14
initializing backup volumes, 3–2
installing
bootstrapping distribution volume, 4–1
installing on disk, 4–1
installing on small devices, 3–1
squeezing system volume, 3–5
to small device, 3–1
unprotecting backup volumes, 3–5
RX02 diskette
device name, 2–11
initializing and formatting, 6–5
size of, 2–11
RX02 distribution kit
bootstrapping, 7–2
installing on RX02, 7–1
if SYSGEN required, 7–13
RX11
loading bootstrap, B–9
RX211
loading bootstrap, B–15
RX50 diskette

RX50 diskette (Cont.)
device name, 2–11
initializing, 6–4
size of, 2–11
RX50 distribution kit
installing on Professional 300 Series, 9–1

S

SBFB.ANS, 2–6
SB monitor
features of, 1–2
SDH.SYS, 2–7
SDHX.SYS, 2–7
SDS.SYS, 2–7
SDSX.SYS, 2–7
SEGTBL, 2–42
SEND
VTCOM
changing default speed, 2–54
SET MODE NOSJ, 2–65
SET MODE SJ, 2–65
.SETTOP programmed request
used with KEX, 2–49
SETUP.SAV, 2–5
Single-job monitor
See SB monitor
Single-line command editor
Changing edit mode to REPLACE, 2–63
Removing JSW bit 6 check, 2–62
Single-mapped monitor
See XM monitor
SIPP.SAV, 2–5
installing customization symbol values, 2–18
SL.SYS, 2–4
..SLCN, 2–62
SLMIN
Changing edit mode to REPLACE, 2–63
Removing JSW bit 6 check, 2–62
SLMIN.SYS, 2–4
..SLNT, 2–35
SLP.SAV, 2–5
SLX.SYS, 2–4
Software customizations, 2–18
choosing, 2–17
getting symbol values for, 2–18
using CUSTOM.TXT with, 2–18
Software kit
distributed components of, 2–2
Source files
choosing for working system, 2–14
list of (table), 2–8
SP.MAC, 2–9
SP.SYS, 2–3
SPLIT.SAV, 2–10
SPOOL.REL, 2–5
changing output device, 2–52
changing work file size, 2–51
choosing for working system, 2–14
SPOOL.SAV, 2–5
SPOOL.SYS
created by SPOOL.REL, 2–51
..SPSO, 2–52
..SPSZ, 2–51
SPX.SYS, 2–3
SRCCOM
changing insertion/deletion characters used by, 2–18
/D option, 2–18
SRCCOM.SAV, 2–5
SRDPS, 2–45
STRTAI.COM, 2–6
STRTFB.COM, 2–6
STRTSB.COM, 2–6
STRTXB.COM, 2–6
STRTXM.COM, 2–6
STRTZB.COM, 2–6
STRTZM.COM, 2–6
Subroutines
list of (table), 2–7
SWAP.SYS, 2–4
need for, 2–12
SWS, 2–20
SYSGEN.COM, 2–6
SYSLIB
customization patch symbol, 2–28
SYSLIB.OBJ, 2–7
changing default device of, 2–28
need for, 2–13
SYSMAC.SML, 2–7
modifying system macro library, 2–55
SYSTEM.MLB, 2–7
System generation
list of files for (table), 2–6
System Library
See SYSLIB.OBJ
System macro library
modifying SYSMAC.SML, 2–55

System volume
including overlaid utilities, 2–16

T

TERMID.SAV, 2–6
Terminals
changing default output from printer to, 2–19
Text editors
choosing for working system, 2–14
TJ.MAC, 2–9
TJU16
loading bootstrap, B–10
TM.MAC, 2–9
TM11
loading bootstrap, B–10
TMSCP bootstrap
address and contents of, B–3
loading using MICRO-ODT, B–1
loading using switch register, B–2
TRANSF.EXE, 2–10
TRANSF.SAV, 2–5
TRANSF.TSK, 2–10
TRMTBL.MAC, 2–9
TS.MAC, 2–9
TSV05 handler
loading bootstrap
MICRO-ODT, B–17
switch register, B–18
TT.MAC, 2–9
..TTON, 2–41
..TTQU, 2–36
TU.MAC, 2–9

U

UBX.SYS, 2–3
UCL
changing name and default device for, 2–53
changing size of, 2–54
UCL.SAV, 2–5
..UCLD, 2–53
UM.MAC, 2–9
Unmapped monitors, 1–2
Unsupported software
list of (table), 2–9
USR.MAC, 2–9
Utilities volume
creating a, 2–15
Utility programs
Utility programs (Cont.)
choosing for working system, 2–14
creating volume for, 2–15

V

V5NOTE.TXT, 2–10
V5USER.TXT, 2–6
VBGEXE.SAV, 2–10
VDT.OBJ, 2–7
VERIFY.COM, 2–7
Virtual memory
device name, 2–11
size of, 2–11
VM.MAC, 2–9
VM.SYS, 2–4
VMX.SYS, 2–4
VTCOM
Changing command mode character, 2–64
changing default send speed of, 2–54
dial string
modifying default prefix of, 2–55
modifying default suffix of, 2–56
setting default DIAL string, 2–32
VTCOM.REL, 2–5
VTCOM.SAV, 2–5

W

Working system
for Introduction to RT–11, 2–16
on disk
backing up, 4–7, 5–6, 8–8
compressing, 4–6, 5–6, 8–7
creating from disk, 5–4
creating from magtape, 8–6
creating from RX01, 4–4
installing bootstrap on, 4–5, 5–5
installing customizations on, 4–6, 5–5, 8–7
protecting, 4–6
test of installation, 4–8, 5–7, 8–10
on Professional 300 Series, 9–4
backing up, 9–5
testing installation, 9–6
on RX02
backing up, 7–6
compressing, 7–5
creating from RX02, 7–3
installing bootstrap on, 7–5
installing customizations on, 7–5

Working system
on RX02 (Cont.)
test of installation, 7–7
on small device
backing up, 3–6, 6–8
compressing, 6–7
creating from disk, 6–4
creating from RX01, 3–3
installing bootstrap on, 6–6
installing customizations on, 3–4, 6–7
test of installation, 3–6, 6–9
selecting components for, 2–10
WRKSIZ, 2–52

X

XB.ANS, 2–6
XB.MAC, 2–9
XB monitor
See XM monitor
XC.MAC, 2–9
XC.SYS, 2–4
XCX.SYS, 2–4
XL.MAC, 2–9
XLX.SYS, 2–4
XM.ANS, 2–6
XM.MAC, 2–9
XMEL.ANS, 2–6
XM monitor
features of, 1–3
XMSUBS.MAC, 2–9

Z

ZB.ANS, 2–6
ZB.MAC, 2–9
ZB monitor
See ZM monitor
ZM.ANS, 2–6
ZM.MAC, 2–9
ZM monitor
features of, 1–3