

DEC 4000 Model 6x0/7x0 AXP Series TZ87 Subsystem Installation

EK-XTZ87-IN.A01

January 1994

This document illustrates how to install the TZ87 subsystem in a DEC 4000 Model 6x0 or Model 7x0 AXP series system.

© Digital Equipment Corporation 1994. All rights reserved.

S2464

TZ87 Tape Drive

TZ87 Overview		
Description Cartridge type	Streaming tape drive CompacTape III	
Capacity	10 GB (uncompressed) 20 GB (compressed)	
Form factor	5 1/4 in	
Media size	1/2 in	
Transfer rate	1.25 MB/s (uncompressed)	
Temperature	10°C (50°F)–40°C (104°F) (operating)	
Relative humidity	20%–80%	
Voltage	+5 VDC \pm 5% and +12 VDC \pm 5%	
Current	+5 V: 2.5 A and +12 V: .8 A	
Power	22.1 W maximum	
Add-On Option Part Number		
TZ87 embedded tape drive	TZ87E-MX	
Field Service Orderable Parts and Options		
FRUs CompacTape III cartridge	TK87–BA (whole unit replacement) TK85K–01	
CompacTape III cartridge (quantity of 7)	TK85K-07	
CompacTape III cartridge (quantity of 1008)	TK85K-A0	
Cleaning Tape III cartridge	TK85-HC	
TZ87 electronic controller module	54-21259-01	
SCSI ID Select cable	17-01936-01	

Documentation

TZ87 Series Cartridge Tape Subsystem

EK-OTZ87-OM

Owner's Manual

TZ87 Tape Drive Operator's

Reference Card

EK-OTZ87-RC

Figure 1 TZ87 Cassette Tape Drive





Table 1 TZ87 Top Side Light Summary

Light	State	Condition
Operate Handle (green)	On	Okay to operate the cartridge insert/release handle.
	Off	Do not operate the cartridge insert/release handle.
Tape in Use (yellow)	Blinks On	Tape is moving. Tape is loaded and ready for use.
Use Cleaning Tape (yellow)	On	Drive head needs cleaning, or the current data cartridge is faulty.
	Remains on after you unload the cleaning tape.	Cleaning was not done. Replace cleaning cartridge.
	After cleaning, turns on again when you reload the data cartridge.	Faulty data cartridge. Try another cartridge.
	Off	Cleaning is complete or is unnecessary.
Write-Protect (orange)	On Off	Tape is write-protected. Tape is write-enabled.
All indicators on one side of panel	On	Power-on self-test is starting.
	Blinks	An error has occurred. Press the Unload button or turn drive power off and then on again to clear the error.

Table 2 Bottom Front Panel Light Summary

Light	State	Condition
All lights are yellow		
TK50/70	On	Indicates tape is recorded in TK50 or TK70 format.
TK85	On	Indicates tape is recorded in TK85 format.
	Blinks	Indicates tape is recorded in another density. This density was selected for a write from BOT. ¹
TK86	On	Indicates tape is recorded in TK86 format.
	Blinks	Indicates tape is recorded in another density. This density was selected for a write from BOT. ¹
TZ87	On (default)	Indicates tape is recorded in TZ87 format.
	Blinks	Indicates tape is recorded in another density. This density was selected for a write from BOT. ¹
Data Compression	On	Compression mode enabled. (Compression can be done in TZ87 density only.)
	Off	Compression mode disabled.
Density Override	On	A density selection has been set from the drive's front panel.
	Off (default)	Density selection is under host control or automatic.
	Blinks	Drive is in density selection mode.

 $^{^{1}\}mathrm{Density}$ over ride by Density Select Switch on OCP




Note: The SCSI ID select cable overrides the SCSI ID jumpers.

MLO-012201

Note _

When a removable-media compartment is empty, install blank bezels to maintain maximum airflow. See Storage Tray Information in the DEC4000 AXP Options Guide for part numbers and illustrations.

Figure 3 Bus Continuity Card



When either the J6 or J7 backplane connector is not used, insert the bus continuity card into those slots to maintain bus continuity. There are two bus continuity cards already installed in the backplane.

Figure 4 TZ87: Inserting a Tape




Figure 5 TZ87: Removing a Tape

