



SCIENTIFIC DATA SYSTEMS

Reference Manual

SDS 930 Computer

SDS 930 BASIC INSTRUCTIONS

Mnemonic	Octal Code	Name	Page Ref.	Mnemonic	Octal Code	Name	Page Ref.
CENTRAL PROCESSOR				BRANCH			
LOAD, STORE				BRU A, T	01	Branch Unconditionally	14
STA A, T	35	Store A	8	BRX A, T	41	Increment Index & Branch	14
STB A, T	36	Store B	8	BRM A, T	43	Mark Place & Branch	15
STX A, T	37	Store Index	8	BRR A, T	51	Return Branch	15
XMA A, T	62	Exchange M and A	9	TEST/SKIP			
LDX A, T	71	Load Index	8	SKS A	40	Skip if Signal Not Set	27
LDB A, T	75	Load B	8	SKE A, T	50	Skip if A Equals M	15
LDA A, T	76	Load A	8	SKB A, T	52	Skip if M and B Do Not Compare Ones	16
EAX A, T	77	Copy Effective Address into index	8	SKN A, T	53	Skip if M Negative	16
ARITHMETIC				SKR A, T	60	Reduce M, Skip if < 0	16
SUB A, T	54	Subtract M from A	10	SKM A, T	70	Skip if A = M on B Mask	15
ADD A, T	55	Add M to A	9	SKA A, T	72	Skip if M and A Do Not Compare Ones	16
SUC A, T	56	Subtract with Carry	10	SKG A, T	73	Skip if A Greater Than M	15
ADC A, T	57	Add with Carry	9	SKD A, T	74	Difference Exponents; Skip	16
MIN A, T	61	Memory Increment	9	SHIFT			
ADM A, T	63	Add A to M	9	LRSH N, T	0 66 24XXX	Logical Right Shift AB	17
MUL A, T	64	Multiply	10	RSH N, T	0 66 00XXX	Right Shift AB	17
DIV A, T	65	Divide	11	RCY N, T	0 66 20XXX	Right Cycle AB	17
LOGICAL				LSH N, T	0 67 00XXX	Left Shift AB	18
ETR A, T	14	Extract	11	LCY N, T	0 67 20XXX	Left Cycle AB	18
MRG A, T	16	Merge	11	NOD N, T	0 67 10XXX	Normalize; Decrement X	18
EOR A, T	17	Exclusive Or	11	CONTROL			
REGISTER CHANGE				HLT	00	Halt	18
CLA	0 46 00001	Clear A	12	NOP	20	No Operation	19
CLB	0 46 00002	Clear B	12	EXU A, T	23	Execute	19
CAB	0 46 00004	Copy A into B	12	BREAKPOINT TESTS			
CBA	0 46 00010	Copy B into A	12	BPT 4	0 40 20040	Breakpoint No. 4 Test	19
XAB	0 46 00014	Exchange A and B	12	BPT 3	0 40 20100	Breakpoint No. 3 Test	19
CBX	0 46 00020	Copy B into Index	13	BPT 2	0 40 20200	Breakpoint No. 2 Test	19
CXB	0 46 00040	Copy Index into B	13	BPT 1	0 40 20400	Breakpoint No. 1 Test	19
XXB	0 46 00060	Exchange Index and B	13	OVERFLOW			
STE	0 46 00122	Store Exponent	13	ROV	0 02 20001	Reset Overflow	19
LDE	0 46 00140	Load Exponent	14	REO	0 02 20010	Record Exponent Overflow	18
XEE	0 46 00160	Exchange Exponents	14	OVT	0 40 20001	Overflow Test; Reset	19
CXA	0 46 00200	Copy Index into A	13	INTERRUPT			
CAX	0 46 00400	Copy A into Index	13	EIR	0 02 20002	Enable Interrupts	23
XXA	0 46 00600	Exchange Index and A	13	DIR	0 02 20004	Disable Interrupts	23
CNA	0 46 01000	Copy Negative into A	14	AIR	0 02 20020	Arm Interrupts	23
BAC	0 46 00012	Copy B into A, Clear B	13	IDT	0 40 20002	Interrupt Disabled Test	23
ABC	0 46 00005	Copy A into B, Clear A	13	IET	0 40 20004	Interrupt Enabled Test	23
CLR	0 46 00003	Clear AB	12	MEMORY EXTENSION			
CLX	2 46 00000	Clear X	13		0 06 200SR	Set Extension Register	19
					0 40 4000T	Extension Register Test	20

Legend:

A = address; *A = indirect address; T = tag field; N = number of shifts

Price: \$2.50

SDS 930 COMPUTER REFERENCE MANUAL

February 1966



SCIENTIFIC DATA SYSTEMS/1649 Seventeenth Street/Santa Monica, California/(213)UP1-0960

REVISIONS

This publication, SDS 90 00 64D, dated February 1966, is a revision of the SDS 930 Computer Reference Manual, SDS 90 00 64C. Changes to the previous manual are indicated by a vertical line in the margin of the page.

RELATED PUBLICATIONS

<u>Title of Manual</u>	<u>Publication Number</u>
SDS ALGOL 60 Reference	90 06 99
SDS 900 Series FORTRAN II Reference	90 00 03
SDS 900 Series FORTRAN II Operations	90 05 87
SDS MONARCH Reference	90 05 66
SDS SYMBOL and META-SYMBOL Reference	90 05 06
SDS 920/930 Programmed Operators Technical	90 00 20
SDS 930 Computer EXAMINER Diagnostic System Technical	90 00 97
SDS 900 Series Utility and Debug Package (AID)	01 20 13
SDS Project Management System Reference	90 08 18
SDS SORT/MERGE Reference	90 09 97
SDS Business Language Reference	90 10 22

CONTENTS

I.	GENERAL DESCRIPTION	1
	Introduction	1
	SDS 930 Registers	3
	SDS 930 Memory	4
	Memory Word Formats	4
	Special Characteristics	6
II.	MACHINE INSTRUCTIONS	8
	Introduction	8
	Load/Store Instructions	8
	Arithmetic Instructions	9
	Logical Instructions	11
	Register Change Instructions	12
	Branch Instructions	14
	Test and Skip Instructions	15
	Shift Instructions	17
	Control Instructions	18
	Breakpoint Tests	19
	Overflow Instructions	19
	Memory Extension Instructions	19
	Floating Point Operations	20
III.	INTERRUPT SYSTEM	21
	Priority Interrupt System	21
	Priority Interrupt Operations	21
	Interrupt Control	22
	Non-Interruptable Instructions	22
	Enable/Disable Interrupt Instructions	22
	Arming Feature (Optional)	23
	Channel Interrupt Designations	24
	End-of-Word/End-of-Transmission Interrupt Operations; Compatible Mode	24.
	Count Equals Zero/End-of-Record; Extended Mode	24
IV.	INPUT/OUTPUT INSTRUCTIONS	25
	Introduction	25
	Direct Memory Access System	26
	Primary Input/Output Instructions	26
	Communication Channel Input/Output	28
	Communication Channel EOM	31
	Standard EOM/EOD Instructions	33
	Compatible/Extended Input/Output Modes	34
	Input/Output Class EOM/EOD	34
	Terminal Functions; Extended Mode	35
	Channel and Device SKS	37
	Single-Word Data Transfer Via Channels W and Y	38
	Direct Parallel Input/Output Instructions	41
	Single-Bit Input/Output	41
	Communication Channel Programming	42
	Control Console	44

IV. (Continued)

Peripheral Equipment Description	49
Paper Tape Input/Output	49
Card Input/Output	52
Magnetic Tape Input/Output	56
Line Printer	62

APPENDICES


SDS Character Codes	A-1
Table of Powers of Two	A-2
Octal-Decimal Integer Conversion Table	A-3
Octal-Decimal Fraction Conversion Table	A-7
Two's Complement Arithmetic	A-10
Optional Equipment	A-11
Data Multiplexing System	A-11
Memory Interface Connection	A-15
Automatic Power Fail-Safe	A-15
Memory Parity Interrupts	A-15
Real-Time Clock	A-16
Programmed Operator Instructions	A-17
Channel Memory Access Priority	A-19
Division Instruction	A-19
Instruction List - Functional Categories	A-20
Instruction List - Numerical Order	A-25
Instruction List - Alphabetical Order	A-29

FIGURES

SDS 930 Computer (Frontispiece)	iv
1-1 SDS 930 Computer Configuration	2
1-2 Basic Register Flow Diagram	3
4-1 SDS 930 Time-Multiplexed Communication Channel, Block Diagram	29
4-2 SDS 930 Direct Access Communication Channel, Block Diagram	30
4-3 SDS 930 Computer Control Panel	45
4-4 Card Read Into Memory in Hollerith	52
4-5 Printer Control Indicator Lights and Switches	62
A-1 SDS 930 Computer Overall Configuration	A-12

TABLES

3-1 Interrupt Location Assignments	22
4-1 Unit Address Codes	32
4-2 Format Control Characters	65



SDS 930 Computer

I. GENERAL DESCRIPTION

INTRODUCTION

The SDS 930 is a high-speed, low-cost, general-purpose digital computer with the following characteristics:

- 24-bit word plus parity bit
- Binary arithmetic
- Single address instructions with
 - Index Register
 - Indirect Addressing
 - Programmed Operators
- Basic core memory 4,096 words, expandable to 32,768 words, all addressable with
 - 0.7 microsecond access time
 - 1.75 microsecond cycle time
- Memory overlap between Central Processor and I/O with two memory banks
- Memory available in 4, 8, and 16 K banks
- Multi-precision programming facility
- Typical execution times (including memory access and indexing)

Fixed-Point Operations (in microseconds)

Add	3.5
Multiply	7.0

Floating-Point Operations (in microseconds)

	24-bit Fraction (plus 9-bit Exponent)	39-bit Fraction (plus 9-bit Exponent)
Add	77	92
Multiply	54	147

- Program interchangeability with other SDS 900 Series Computers
- Parity checking of all memory and input/output operations
- Priority Interrupt System
 - SDS I/O Options Interrupts 2 levels standard, 38 optional
 - System Interrupts, 896 optional

- Optional powerfail-safe feature permits saving contents of memory and programmable registers in case of power failure.
- Up to four I/O communication channels (with optional interlacing capability), time-multiplexed with computer operation, providing input/output rates of up to one word per 3.5 microseconds
- An optional Direct Memory Access System that allows input/output transfer to occur simultaneously with computer memory access, providing input/output rates of up to one word per 1.75 microseconds
- One to four Direct Access Communication Channels that incorporate the Direct Memory Access System
- Data Multiplex Channel that uses direct memory access connection and accepts/transmits information from external devices, or subchannels, which may operate simultaneously; thus, externally controlled and sequenced equipment may perform input/output buffering and control operations rather than the computer.
- Time-Multiplexed Input/Output Channels operate upon either words or characters. A 6-bit character is the standard character size; 6- and 12-bit characters, or 6-, 12-, and 24-bit characters can be specified as desired. Direct Access Channels operate upon words and characters. These channels accept 6-, 8-, 12-, and 24-bit characters. The number of characters per word is specified by the external device.
- Input/output with Scatter-Read and Gather-Write facility
- Standard input/output
 - Time-Multiplexed Communication Channel (without interlace)
 - Control Console
- Optional input/output devices
 - Automatic typewriter
 - Photoelectric paper-tape reader and paper-tape punch, and spooler mounted on cart
 - MAGPAK Magnetic Tape System
 - Magnetic-tape units (IBM-compatible; binary and BCD)
 - Punched-card equipment
 - Line printers, graph plotters
 - Typewriter with electromechanical paper-tape reader and punch, auxiliary disc files




Figure 1-1. SDS 930 Computer Configuration

Communications equipment, teletype consoles, display oscilloscopes

A/D converters, digital multiplexer equipment, and other special system equipment

- FORTRAN II and symbolic assembler as part of complete software package
- All-silicon semiconductors
- Operating temperature range: 10° to 40°C
- Dimensions: 124 inches x 25-1/2 inches x 65 inches
- Power: 3 kva

SDS 930 REGISTERS

The 930 Central Processor contains the following arithmetic and control registers. They are full-word, 24-bit registers except as noted.

AVAILABLE TO THE PROGRAMMER (see Fig. 1-2, dark lines)

The A Register is the main accumulator of the computer. The B Register is an extension of the A Register. The B Register contains the less significant portion of double-length numbers.

The Index Register, X, used in address modification, is a full-word register. Indexing operations occur only with the least significant 14 bits.

The P Register is a 14-bit register that contains the memory address of the current instruction. Unless modified by the program, the contents of P increase by one at the completion of each instruction.

The Memory Extension Registers, EM3 and EM2, are 3-bit registers that specify the portion of extended memory being used.

NOT AVAILABLE TO THE PROGRAMMER (see Fig. 1-2, light lines)

The S Register is a 14-bit register that contains the address of the memory location to be accessed for instructions or data. The address is augmented by one of the Memory Extension Registers.

The C Register is an arithmetic and control register used in multiply, divide, and other operations. All instructions come from memory to the C Register before decoding. Address modification and parity generation/detection take place in the C Register.

The O Register is a 6-bit register that contains the instruction code of the instruction being executed.

The M Register is a 24-bit register that holds each word as it comes from memory. Recopying of a word into memory takes place from the M Register.




Figure 1-2. Basic Register Flow Diagram

SDS 930 MEMORY

Core memory is expandable from 4,096 to 32,768 words. Word length is 24 bits plus parity. The address field in the instruction format is 14 bits long, allowing direct access of up to 16,384 words. The Memory Extension System provides direct access to the total 32,768 words.

Memory is available in 4,096-, 8,192-, and 16,384-word banks.

As an optional feature, if a power loss is detected, the computer may be interrupted and the transient, programmable registers stored to provide complete fail-safe capability. With this option, power failure causes no loss of information.

Even parity is automatically generated or checked during each read/write cycle. A control panel switch may be set to halt the computer automatically in case of parity error detection.

The memory is cyclic, or "wrap-around", for each 16,384 words being addressed. An attempt to access from a location whose address is greater than that available results in an access of all zeros. An attempt to store into such a location results in a "no-op" operation, with the next instruction in sequence being executed.

MEMORY EXTENSION SYSTEM


The Memory Extension System, containing two memory extension registers, allows addressing of memories greater than 16,384 words. The program loads either or both of the Extend Memory Registers and activates them as desired. Each register contains 3 bits, or one octal digit, that can become the most significant, or fifth, digit of any operand address.




The program uses the first extension register, EM3, by calling for an address with a 1, 1 in the most and next most significant address bits, respectively (a "3" for the most significant octal digit). The program calls for EM2, the second extension register, by setting the same two address bits to 1, 0 (a "2" for the most significant octal digit). Via memory extension instructions, the program can set each of the registers to a desired "5th digit" and can test the current setting of each register. Once set, the contents of either register remain set until changed by program or by pressing the START button.

The program always addresses the first 8,192 words of core, 00000-17777, directly without regard to the Extend Memory Registers. Whenever the operator initializes the computer (presses START), the computer presets a 3 in EM3 and a 2 in EM2. This allows the programmer to address the first 16,384 words of core, 00000-37777, without being concerned with the extension system.

Example 1. By previously setting EM2 to 4, the program adds the contents of location 43300 to the A Register by executing ADD 23300. The "2" calls for register EM2:



Example 2. EM3 setting is 5; EM2 setting is 7:



When $(EM3) \neq 3$, the computer lights the EM3 light on the control panel. When $(EM2) \neq 2$, the computer lights the EM2 light on the control panel. When executing the MARK PLACE AND BRANCH (BRM) instruction, the computer records the contents of EM3, EM2, and the Overflow Indicator in the mark location. BRM stores overflow in bit 0 of the mark; it stores the contents of EM3 in bits 3 through 5 and the contents of EM2 in bits 6 through 8. Bits 1 and 2 are unpredictable; bit 9 is zero.

Memory Write Lock-Out Feature (Optional)


Permanent memory protection for selected areas of memory in the SDS 930 Computer is provided by a memory lock-out feature, which is controlled either manually by switches or by the program with a lock-out register, protects the contents of memory from inadvertent destruction by operating programs.

The entire memory is divided into 2048 word blocks. This first block, from 0000 to 2047, is further divided into four subblocks of 512 words each. Each of these blocks can be individually protected by turning on the appropriate switch with the manual-controlled option or placing a one in the appropriate position of the lock-out register with the program-controlled option.

Read operations are always allowed, but if a program or I/O channel attempts to store or write into a protected block of memory, an internal interrupt occurs to octal location 35. The memory cell referenced is not altered. Therefore, not only is memory protected, but also the supervisory program is notified that an attempt to write into an interlocked area has occurred.


MEMORY WORD FORMATS

A computer word is 24 binary digits (bits) long.



The format above numbers the bits from the left, or most significant end of the word, to the right, or least significant end of the word. This numbering format is the basis of references to bit positions or bit numbers. Octal notation most easily describes the contents of the 24 bits of a word. Thus, one octal digit, 0 through 7, represents three binary digits. For example, the octal number, 01234567, represents its binary equivalent, 000 001 010 011 100 101 110 111.

The computer instruction word format is:



Bit position 0 contains the Relative Address Bit. Standard loading programs use this bit; central processor decoding logic does not use or sense this bit. A 1-bit (octal value of 4) in this position causes some standard loading programs to add the assigned location of the instruction to the address field contents prior to actual storage into the assigned location.

Bit position 1 (octal value of 2) contains the Index Register Bit.

Bit positions 2 through 8 contain the Instruction Code Field which determines the operation to be performed. The Programmed Operator facility uses bit position 2 (octal value of 1); it is part of the "Tag" Field (bit positions 0 - 2).

Bit position 9 (octal value of 4) contains the Indirect Address Bit.

Bit position 10 (octal value of 2) contains the Memory Extension Bit that controls addressing above location 8,191. A 1-bit in this position activates the memory extension logic.

Bit positions 10 through 23 contain the Address Field which usually represents the location of the operand called for by the instruction code.

The following examples use standard assembler format in expressing instructions. This format is:

LDA 1000,T

where:

LDA is a representative mnemonic instruction code, 1000 is a representative address that is written decimally, and T is a 1-digit octal integer that represents the Tag Field.

To express indirect addressing (that is, a "one" in the Indirect Address position), the programmer prefixes an asterisk to the address field:


LDA *1000,T

The interpretation of the Tag Field (bit positions 0 - 2) integer, T, when required, is composed of the sum of the octal values of its constituents; it is written as follows:

Tag Field Integer T	Interpretation
0 (or blank)	No Relative Address, No Index, No Programmed Operator
1	Programmed Operator
2	Index
3	Programmed Operator and Index
4	Relative Address
5	Programmed Operator and Relative Address
6	Both Relative Address and Index
7	Programmed Operator, Index, and Relative Address

Tag Fields of 1,3,5,7 are usually replaced by a specific Programmed Operator mnemonic along with Tag Fields of 0,2,4,6, respectively.


In the explanation of specific instructions, the format used for the instruction word is:



where R, X, and I are as defined previously, 000 represents the instruction, and M represents a generalized memory address.

FIXED-POINT FORMAT

Fixed-point data words have the format:



Numbers held in this format are 8-digit, octal numbers, with the sign incorporated as the "leading bit" in the most significant octal digit. Bit position 0 is the sign bit, with negative numbers having a "1" in bit position 0 and positive numbers having a "0" in bit position 0.

The memory holds fixed-point numbers as 23-bit fractions with an assumed binary point to the left of bit position one. Numbers held in one word have the equivalent precision of over six decimal digits. The range of values of the fixed-point format is from minus one to slightly less than plus one. Scaling is used in handling numbers during computation.


Programmers sometime consider fixed-point numbers to be integers, with the binary point to the right of bit position 23. The range of integer values is from -2^{23} to $+2^{23}-1$.

The memory holds negative, fixed-point numbers in two's complement form; the computer operates on these numbers arithmetically in a two's complement number system. See Appendix A-10 for a discussion of two's complement arithmetic.

FLOATING-POINT FORMAT

SDS offers standard programmed operator packages for performing double and single-precision floating-point arithmetic. The following paragraphs explain the standard floating-point number formats.

Double-Precision Floating-Point Format




The fractional portion of a double-precision, floating-point number is a 39-bit, proper fraction, with the leading bit being the sign bit and the assumed binary point just to the left of the most significant magnitude bit (bit 1 of the upper word). The floating-point exponent is a 9-bit integer, with the leading bit being the sign. The standard routines operate on both fraction and exponent in two's complement form. If F represents the contents of the fractional field and E represents the contents of the exponent field, the number has the form $F \times 2^E$.

Double-precision, floating-point numbers have over 11 decimal digits of precision and a decimally equivalent exponent range of 10^{-77} to 10^{+77} .

Standard Programmed Operators assume that the more significant word is in the A Register, or stored in memory location M + 1, and that the less significant word is in the B Register, or stored in memory location M.

Single-Precision Floating-Point Format



The fractional portion of a single-precision, floating-point number is a 24-bit proper fraction, with the leading bit being the sign and the assumed binary point just to the left of the most significant magnitude bit. The floating-point exponent is a 9-bit integer with a leading sign bit. The standard routines operate on both fraction and exponent in two's complement form.

Single-precision, floating-point numbers have over six decimal digits of precision and a decimally equivalent exponent range of 10^{-77} to 10^{+77} .

Standard Programmed Operators assume that the fractional word is in A, or stored in memory location $M + 1$, and that the exponent word is in B, or stored in memory location M. When entering a standard Programmed Operator routine, bits 0 - 14 of the exponent word are ignored.

SPECIAL CHARACTERISTICS

Certain computer features simplify programming and provide significant economies in memory and in program running time.

ADDRESS MODIFICATION

Indexing and indirect addressing, used singly or in combination, perform address modification. In both indexing and indirect addressing, the computer performs address modification after bringing the instruction from memory but before executing it. The instruction remains in memory in its original form. The results of indexing and/or indirect addressing form the "effective address".

INDEXING

The computer contains an Index Register for address modification. The use of this register to modify the address in an instruction does not increase instruction execution time.

If the content of the Index Bit in an instruction is a "one", the computer adds the contents of bits 10 through 23 of the X Register to the contents of the Address Field of the instruction prior to execution. This addition does not keep any overflow or carry beyond the fourteenth address bit.

The instruction set provides instructions for modifying and testing the X Register, and for transferring information between the X and B Registers, the X and A Registers, and the X Register and memory.

INDIRECT ADDRESSING

The Indirect Address Bit is in bit position 9 of the instruction. This bit determines whether the computer uses indirect addressing with the instruction being executed.

A zero in the Indirect Address Bit causes the computer to use the contents of the Address Field (bit positions 10 - 23 in the instruction) as the 5-digit, octal address requested by the instruction. A one in the Index Bit causes the computer to add the contents of the Index Register to this address to form the effective address.

A one in the Indirect Address Bit causes the computer to decode the contents of the effective address, accessed as described above, as if it were an instruction without an instruction code; that is, the address logic reinitiates address decoding, using the word in the effective location (the memory cell whose address is the effective address). This is an iterative process and provides multi-level indirect addressing. Indirect addressing adds one cycle time to instruction execution time for each level of addressing. The programmer can use indexing to modify indirect addressing at every level.

EXAMPLES: INDEXING AND INDIRECT ADDRESSING

The octal instruction code for LOAD A REGISTER (LDA), used in the examples, is 76.

Location	Contents	Effect
X	00000001	
1000	00001001	
1001	00041002	
1002	00001003	
1003	00000002	
2000	0 76 01000	$(1000) = 00001001 \rightarrow A$
2001	2 76 01000	$(1000 + 1) = (1001) = 00041002 \rightarrow A$
2002	0 76 41000	$((1000)) = (1001) = 00041002 \rightarrow A$
2003	2 76 41000	$((1000 + 1)) = ((1001)) = (41002) =$ $((1002)) = (1003) = 00000002 \rightarrow A$

Nomenclature

When discussing properties of the various instructions, including the indirect addressing facility, several terms describe specific locations or addresses.

The term "effective memory location" describes the location in memory from which the final operand is taken at the conclusion of all indirect addressing and indexing. This term is sometimes shortened to "effective location." It is the location whose address is the effective address.

The term "effective operand" means the contents of the effective memory location.

PROGRAMMED OPERATORS

Programmed Operators (called POP) permit the calling of subroutines with a single instruction of the same form as built-in machine instructions. The computer decodes the codes 100g - 177g as special instructions and transfers to a subroutine uniquely determined by the code. The computer records the address of the POP instruction at location 00000 together with an indirect address bit so that the program continuity may be maintained. By indirect addressing which refers to location 00000, which in turn refers to the POP instruction, the subroutine can gain access to the effective address of the operand associated with the POP instruction.

Programmed Operator subroutines are assigned three-letter, mnemonic designations in the same manner as built-in, machine instructions described in Section II. A program can use up to 64 Programmed Operators at any one time; however, since Programmed Operators are programmer-specified, the programmer can select alternate sets or sub-sets of the 64 Programmed Operators from program to program or from section to section of the same program. The total number of Programmed Operators is without limit; but it is inconvenient to use more than 64 in one program. Other computers in the SDS 900 Series maintain symbolic homogeneity through use of Programmed Operators. Mnemonic designations are identical in all computers. For example, while the designation "FLA" (for Floating ADD) may refer to a built-in, machine instruction in one computer, it refers to a Programmed Operator subroutine in another. This technique preserves the one-to-one instruction relationship; programs written for one 900 Series Computer can run on any other computer in the series.

A more detailed discussion and a list of standard SDS Programmed Operator routines are in Appendix A-17.

OVERFLOW

The Overflow Indicator in the computer permits the detection of erroneous arithmetic operations that occur during the execution of a program. The Overflow Indicator turns on if any of the following occur:

- A sum or difference resulting from an addition or subtraction that cannot be contained within the A Register.

- Multiplication of N by N where N is 40000000, the largest negative number that can be represented in an SDS 930 word. The A and B Registers cannot contain this product.

- A division operation where the absolute value of the numerator is equal to (positive result) or larger than the absolute value of the denominator. The A Register cannot contain this quotient.

- A left-shift operation that shifts a bit of absolute magnitude equal to one beyond position 1 of the A Register.

The instruction set (see Section II) contains instructions to reset, or test and reset the state of the Overflow Indicator.

The only instruction whose execution is altered by the state of the Overflow Indicator is OVERFLOW TEST (OVT), which skips if overflow is reset. Thus, the state of the Overflow Indicator can be ignored if desired. This is unlike some machines in which overflow causes a trap or halt.

To determine whether a particular instruction causes overflow, turn off the Overflow Indicator before executing the instruction. An instruction that may be used to turn on overflow is BRR. The instruction A BRR A, 4 "branches" to the next location and turns on the Overflow Indicator.

If the Overflow Indicator is on, it remains on until the appropriate instruction turns it off.

The execution of Programmed Operator, closed and interrupt subroutines automatically preserves the status of the Overflow Indicator. In the execution of a Programmed Operator instruction, the computer automatically places the status of the Overflow Indicator in bit position 0 of location 00000 and resets the Overflow Indicator. The instruction, MARK PLACE AND BRANCH (BRM), places the status of the Overflow Indicator in bit position 0 of the effective memory location and does not disturb the Overflow Indicator.

The instruction, RETURN BRANCH (BRR), automatically merges the contents of the Overflow Indicator with the contents of bit position 0 of the effective memory location and places the result in the Overflow Indicator. Section II contains a description of the above branch instructions.

SUBROUTINE EXECUTION

The SDS 930 Computer provides three distinct methods of subroutine execution:

- Normal closed subroutine where the input parameters are specified in appropriate registers such as the A Register

- Interrupt subroutine that is entered as the result of an interrupt

- Programmed Operator subroutine.

A program enters a normal closed subroutine via a MARK PLACE AND BRANCH (BRM) instruction; BRM automatically stores the contents of the Program Counter (P) Register and the status of EM3, EM2, and Overflow Indicator in the branch-to location. P Register value is the address of the BRM instruction. A RETURN BRANCH (BRR) instruction accomplishes the return to the main program; the BRR adds one to the stored P Register value and transfers control to that location. See Section II, Branch Group, for a description of the branch instructions.

Interrupt subroutines are closed subroutines that are initiated by the detection of program-controlling interrupts that automatically cause the specific interrupt subroutine to be entered. A BRM instruction enters an interrupt subroutine; the BRM automatically stores the contents of the P Register, EM3, EM2, and Overflow Indicator in the branch-to location. The value stored from the P Register is the address of the instruction to which program control should return after the interrupt is serviced by the interrupt subroutine. A BRANCH UNCONDITIONALLY (BRU) instruction with indirect addressing returns control to the main program at the completion of the subroutine. BRU also clears the interrupt from the active state. Note that this differs from the normal closed subroutine return that uses the BRR (stored P value + 1 \rightarrow P). The point in an execution cycle at which the interrupt routine-entering BRM executes has already caused the proper incrementing to occur.

II. MACHINE INSTRUCTIONS

INTRODUCTION

This section describes SDS 930 instructions; the instructions are in functional groups. Lists of instructions in functional, numerical, and alphabetical order are in Appendices A-20, A-25, and A-29, respectively.

The following statements apply to the instruction descriptions:

All instruction times are in memory cycles, where each cycle is 1.75 microseconds, and include accessing the instruction and all required operands.

Parentheses denote "contents of." For example, "(A)" denotes "contents of the A Register."


Indexing and Indirect Addressing apply to all instructions except as noted. Indexing does not change the instruction execution time. Each level of indirect addressing requires one additional memory cycle.

The interrupt system can interrupt the program sequence at the end of any instruction except as noted.

Each instruction description specifies the registers affected.

With the description of each instruction is a diagram representing the format of the instruction. Preceding this diagram is the mnemonic code that identifies the instruction and the name of the instruction.


EXAMPLE:



The letter M represents the address part of the instruction. Some instructions have octal numbers in the address field. These instructions do not refer to memory.

LOAD/STORE INSTRUCTIONS


LDA LOAD A



LDA loads the contents of the effective memory location into the A Register.

Registers Affected: A Timing: 2


STA STORE A



STA stores the contents of the A Register in the effective memory location.

Registers Affected: M Timing: 3


LDB LOAD B



LDB loads the contents of the effective memory location into the B Register.

Registers Affected: B Timing: 2


STB STORE B



STB stores the contents of the B Register in the effective memory location.

Registers Affected: M Timing: 3


LDX LOAD INDEX



LDX loads the entire 24-bit contents of the effective memory location into the Index Register.

Registers Affected: X Timing: 2


STX STORE INDEX



STX stores the entire 24-bit contents of the Index Register in the effective memory location.

Registers Affected: M Timing: 3

EAX COPY EFFECTIVE ADDRESS INTO INDEX REGISTER



EAX copies the address of the effective memory location into the Index Register.

The addressing process for this instruction operates as in a Load A instruction, except that instead of obtaining the contents of the effective memory location, the effective memory address acts as the operand. This addressing process is sometimes called "immediate addressing." For example, if execution of this instruction occurs with a zero indirect address bit and a zero


in the index field, then the actual bit configuration in the address field of EAX copies into the Index Register.

The ten most significant bits of the Index Register are unaffected.

Registers Affected: X_{10-23}

Timing: 2

XMA EXCHANGE MEMORY AND A




XMA loads the contents of the effective memory location into the A Register and stores the contents of the A Register in the effective memory location.

Registers Affected: A, M

Timing: 3

ARITHMETIC INSTRUCTIONS

ADD ADD MEMORY TO A



This instruction adds the contents of the effective memory location to the A Register and places the result in A.


After execution, bit position 0 of the Index (X) Register contains the carry from bit position 0 of the 24-bit adder. Therefore, the programmer should be careful when attempting to hold a full word quantity in X while performing an addition.

If both numbers are of the same sign but the sign of the result is opposite, overflow has occurred and the computer has set the Overflow Indicator.

Registers Affected: A, X_0 , Overflow Indicator

Timing: 2

ADC ADD WITH CARRY



This instruction performs multi-precision addition. Using the instruction, ADD M TO A (55), the program adds the lower halves of the numbers first. ADD automatically retains the carry in the sign position of the X Register. The program then adds the two upper halves, using ADC. ADC is the same as ADD M TO A (55), except that it adds the carry bit previously generated into the low-order position.

After execution, bit position 0 of the Index (X) Register contains the carry from bit position 0 of the 24-bit adder. Therefore, the programmer should be careful when attempting to hold a full word quantity in X while performing an add with carry.

The computer automatically clears the Overflow Indicator prior to execution of this instruction since overflow resulting from the addition of the lower half of the multi-precision numbers is not meaningful.

If both numbers of the upper half are of the same sign but the sign of the result is opposite, an overflow has occurred and the computer sets the Overflow Indicator.

Registers Affected: A, X_0 , Overflow Indicator

Timing: 2

EXAMPLE:

Assume the A and B Registers contain a double-precision number to which the double-precision number, 15034166 12300000, in Locations 1021 and 1020 is added. The less significant half appears in 1020.


The sign position of B and the sign position of the less significant half (1020) are not considered signs but are binary digits. Thus, a double-precision number in AB consists of a sign (A_0) and 47 binary digits (A_1-A_{23} , B_0-B_{23}). The number is in two's complement form.

The program is:

Location	Instruction	A	B	Carry
(Prior to Execution)		20314624	71510426	-
2100	XAB	71510426	20314624	-
2101	ADD 1020	04010426	20314624	1
2102	XAB	20314624	04010426	1
2103	ADC 1021	35351013	04010426	0

NOTE: Since the process is self-propagating, this instruction is used in performing additions of any precision. See the instruction, EXCHANGE A AND B (XAB), one of the Register Change Instructions, this section, for an explanation of its operation.

ADM ADD A TO MEMORY




ADM adds the contents of the A Register to the effective memory location and stores the result in the same location.

If both numbers are of the same sign but the sign of the result is opposite, an overflow occurs and the computer sets the Overflow Indicator. The contents of the A Register do not change.

Registers Affected: M, Overflow Indicator

Timing: 3

MIN MEMORY INCREMENT




MIN increases the contents of the effective memory location by one, and places the resulting sum in the same location. The contents of the A Register do not change.

Overflow occurs with this instruction only when the contents of M are 37777777 before execution. In this case, 40000000 is the result in M.

Registers Affected: M, Overflow Indicator Timing: 3

SUB SUBTRACT MEMORY FROM A




SUB subtracts the contents of the effective memory location from the A Register and places the result in the A Register.

After execution, bit position 0 of the Index (X) Register contains the carry from bit position 0 of the 24-bit adder. Therefore, the programmer should be careful when attempting to hold a full word quantity in X while performing a subtraction.

If both numbers are of the same sign after the subtrahend has been complemented for addition but the sign of the result is opposite, an overflow has occurred and the computer sets the Overflow Indicator.

Registers Affected: A, X₀, Overflow Indicator Timing: 2

SUC SUBTRACT WITH CARRY



This instruction performs multiple precision subtractions. The program uses the instruction, SUBTRACT M FROM A (54), to subtract the lower half of the numbers first; this automatically retains the carry in the sign position of the X Register. This instruction (SUC) then subtracts the two upper halves. SUC is the same as SUBTRACT M FROM A (54), except for the retention of the carry bit previously generated in the sign position of the X Register.

After execution, bit position 0 of the Index (X) Register contains the carry from bit position 0 of the 24-bit adder. Therefore, the programmer should be careful when attempting to hold a full word quantity in X while executing SUC.

The Overflow Indicator automatically clears prior to execution of this instruction since overflow resulting from the subtraction of the lower half of the numbers is not meaningful.

If both numbers of the upper half of the subtraction are of the same sign after the computer complements the subtrahend for addition but the sign of the result is opposite, overflow occurs and the computer sets the Overflow Indicator.

EXAMPLE:

Assume that Registers A and B and memory location M contain a triple-precision number from which the triple-precision number in location L+2, L+1, and L is subtracted. The octal numbers 36142070 31567000 10000001 and 14236213 46120000 are in the following locations:

A	B	M
36142070	31567000	10000001
L+2	L+1	L
14236213	46120000	10000000

The sign of one triple-precision number is in A₀, while its 71 binary digits are in A₁₋₂₃, B₀₋₂₃, and M₀₋₂₃. The sign of the other number is in L₀, and its 71 digits are in L₁₋₂₃, L+1₀₋₂₃, and L+2₀₋₂₃.

Execution:


Location	Instruction	A	B	Carry
2100	XMA M	10000001	31567000	-
2101	SUB L	00000001	31567000	0
2102	XMA M	36142070	31567000	0
2103	XAB	31567000	36142070	0
2104	SUC L+1	63447000	36142070	1
2105	XAB	36142070	63447000	1
2106	SUC L+2	21704655	63447000	0

Answer: 21703654 63447000 00000001

NOTE: Since the process is self-propagating, this instruction performs subtractions of any precision. See EXCHANGE A AND B (XAB), under Register Change Instructions, this section, for explanation of its operation.

Registers Affected: A, X₀, Overflow Indicator Timing: 2

MUL MULTIPLY



This instruction multiplies the contents of the A Register by the contents of the effective memory location and places the product in the A and B Registers with the more significant portion in A. The sign of the product is in A₀; the bit in B₀ is part of the product, not treated as a sign bit. Since the product contains at most 46 significant bits, the content of B₂₃ is not significant and is zero.

The original contents of B do not affect the operation of the MULTIPLY instruction and are destroyed. If the contents of both the multiplier and multiplicand have the value 40000000₈, overflow occurs and the computer sets the Overflow Indicator.


Registers Affected: A, B, Overflow Indicator Timing: 4

EXAMPLE: Multiplication of 3 by 3

	<u>A</u>	<u>B</u>	<u>Memory</u>
Before Execution	00000003	Not Meaningful	00000003
After Execution	00000000	00000022	00000003

Note that 00000000 00000011₈ scaled at 46
is equal to 00000000 00000022₈ scaled at 47

DIV DIVIDE



This instruction divides the contents of the A and B Registers, treated as a double-precision number, by the contents of the effective memory location and places the quotient in the A Register, with the remainder in the B Register.

No overflow occurs if $-1 \leq \frac{(A, B)}{M} < 1$ (if the contents of A and B divided by the contents of the effective location are greater than or equal to minus one but strictly less than plus one). If the quotient exceeds these boundaries, overflow occurs and the computer sets the Overflow Indicator. In this latter case, the results are not arithmetically correct. See Appendix A-19 for a further description of division.

Registers Affected: A, B, Overflow Indicator Timing: 10


EXAMPLE:

Division of 7 scaled at binary 46 by 3 at binary 23 is:

	<u>A</u>	<u>B</u>	<u>Memory</u>
Before Execution	00000000	00000016	00000003
After Execution	00000002	00000001	00000003

LOGICAL INSTRUCTIONS

ETR EXTRACT



ETR performs a logical "AND" between corresponding bits of the A Register and the effective memory location and places the result in A. This instruction performs the operation bit by corresponding bit according to the following:

<u>A</u>	<u>M</u>	<u>Result in A</u>
0	0	0
0	1	0
1	0	0
1	1	1


Registers Affected: A

Timing: 2

EXAMPLE:

	<u>A</u>	<u>M</u>
Before Execution	64231567	00777600
After Execution	00231400	00777600

MRG MERGE



MRG performs a logical "Inclusive OR" between corresponding bits of the A Register and the effective memory location and places the result in A. This instruction performs the operation bit by corresponding bit, as follows:

<u>A</u>	<u>M</u>	<u>Result in A</u>
0	0	0
0	1	1
1	0	1
1	1	1


Registers Affected: A

Timing: 2

EXAMPLE:

	<u>A</u>	<u>M</u>
Before Execution	06446254	02340712
After Execution	06746756	02340712

EOR EXCLUSIVE OR



EOR performs a logical "Exclusive OR" between corresponding bits of the A Register and the effective memory location and places the result in A. This instruction performs the operation bit by corresponding bit, as follows:

<u>A</u>	<u>M</u>	<u>Result in A</u>
0	0	0
0	1	1
1	0	1
1	1	0

Registers Affected: A

Timing: 2

EXAMPLE:

	<u>A</u>	<u>M</u>
Before Execution	34165031	70077021
After Execution	44112010	70077021

The proper memory word configuration logically inverts selected bit positions of the A Register. If all "ones" appear in the memory word, a one's complement of A results.

EXAMPLE :

	<u>A</u>	<u>M</u>
Before Execution	10357211	77777777
After Execution	67420566	77777777

REGISTER CHANGE INSTRUCTIONS

The facility to operate on and exchange data between the A, B, and Index Registers is available within the set of micro-instructions in the Register Change Group.

All instructions in the group use the same operation code, 46. Bit positions 14 through 23 of the address field specify the function to be performed by each micro-instruction. The programmer may specify combinations of address bits to perform simultaneous operations.

If the selected bits copy two registers into a third during one operation, a merge of the former two registers into the latter results.

If the selected control bits copy into a register and clear that same register, the clear has no effect.

The function of each address bit is :

Instruction Bit	Octal Position	Octal Value	Function
1	00	2	Clear X
23		1	Clear A
22	07	2	Clear B
21		4	Copy (A) into B
20		1	Copy (B) into A
19	06	2	Copy (B) into X
18		4	Copy (X) into B
17		1	Bits 15-23 only*
16	05	2	Copy (X) into A
15		4	Copy (A) into X
14	04	1	Copy -(A) into A

*See STORE EXPONENT (4600122) for special functions of this bit.

EXAMPLE :

The following instruction copies (A) into B and clears the A Register :


0 46 00005

Both functions occur simultaneously, that is, within the one cycle time of the instruction.

Indirect addressing and indexing do not apply to these instructions.

These instructions require one machine cycle regardless of the number of functions performed. As an aid to the programmer, the most useful combinations have mnemonic designations assigned to them that are recognized by standard SDS programming systems.

CLA CLEAR A




CLA clears the contents of the A Register to zero.

Registers Affected : A

Timing : 1

CLB CLEAR B




CLB clears the contents of the B Register to zero.

Registers Affected : B

Timing : 1

CLR CLEAR AB




CLR clears the contents of both the A and B Registers to zero.

Registers Affected : A, B

Timing : 1

CAB COPY A INTO B




CAB copies the contents of the A Register into the B Register.

Registers Affected : B

Timing : 1

CBA COPY B INTO A




CBA copies contents of the B Register into the A Register.

Registers Affected : A

Timing : 1

XAB EXCHANGE A AND B




XAB copies the contents of the A Register into the B Register and, simultaneously, copies the contents of the B Register into the A Register.

Registers Affected : A, B

Timing : 1


BAC COPY B INTO A, CLEAR B



BAC copies the contents of the B Register into the A Register and, simultaneously, clears the B Register to zero.

Registers Affected: A, B Timing: 1


ABC COPY A INTO B, CLEAR A



ABC copies the contents of the A Register into the B Register and, simultaneously, clears the A Register to zero.

Registers Affected: A, B Timing: 1


CLX CLEAR INDEX REGISTER



The contents of the Index Register are set to zero.

Registers Affected: X Timing: 1


CXA COPY INDEX INTO A



CXA copies the contents of the Index Register into the A Register.

Registers Affected: A Timing: 1


CAX COPY A INTO INDEX



CAX copies the contents of the A Register into the Index Register.

Registers Affected: X Timing: 1


XXA EXCHANGE INDEX AND A



XXA copies the contents of the Index Register into the A Register and, simultaneously, copies the contents of the A Register into the Index Register.

Registers Affected: A, X Timing: 1


CBX COPY B INTO INDEX



CBX copies the contents of the B Register into the Index Register.

Registers Affected: X Timing: 1


CXB COPY INDEX INTO B



CXB copies the contents of the Index Register into the B Register.

Registers Affected: B Timing: 1


XXB EXCHANGE INDEX AND B



XXB copies the contents of the Index Register into the B Register and, simultaneously, copies the contents of the B Register into the Index Register.

Registers Affected: B, X Timing: 1

STE STORE EXPONENT



STE copies the least significant nine bits of the B Register into the Index Register, extends bit 15 of the Index Register (the sign of the exponent) into bit 0, and then clears the nine least significant bits of B.


EXAMPLE:

	<u>B</u>	<u>Index</u>
Before Execution	64152713	---
After Execution	64152000	77777713

Note: This instruction assists in the manipulation of floating-point, double-precision numbers, where the fraction is stored in the high order 39 bits and the exponent in the low order nine bits of the combined AB Register. (See Floating-Point Operations, this section.)

Registers Affected: B, X Timing: 1

LDE LOAD EXPONENT



LDE copies the least significant nine bits of the Index Register into the least significant nine bits of the B Register and clears the nine least significant bits of B prior to the transfer.

EXAMPLE:


	<u>B</u>	<u>Index</u>
Before Execution	34765712	00000151
After Execution	34765151	00000151

Note: This instruction assists in the manipulation of floating-point, double-precision numbers, where the fraction is stored in the most significant 39 bits and the exponent in the least significant nine bits.

Registers Affected: B

Timing: 1

XEE EXCHANGE EXPONENTS



XEE exchanges the least significant nine bits of the B Register and the Index Register. The exchange loses no information. The new bit 15 of the Index Register (the sign of the exponent) then extends into bit 0.

EXAMPLE:


	<u>B</u>	<u>Index</u>
Before Execution	67142355	77777133
After Execution	67142133	00000355

Note: This instruction assists in the manipulation of floating-point, double-precision numbers, where the fraction is stored in the most significant 39 bits and the exponent in the least significant nine bits.

Registers Affected: B, X

Timing: 1

CNA COPY NEGATIVE INTO A



CNA copies the two's complement of the contents of the A Register into the A Register.


Registers Affected: A

Timing: 1

BRANCH INSTRUCTIONS

Branch instructions conditionally or unconditionally change the course of the program by altering the contents of the program counter. The programmer should note that these instructions branch to locations determined by the effective address; this means that the branch can operate with all levels of indirect and indexed addressing.

BRU BRANCH UNCONDITIONALLY




BRU takes the next instruction from the location determined by the effective address.

A BRU instruction with an Indirect Address bit equal to "one" clears the highest priority interrupt level then active in addition to branching to the effective location.

Registers Affected: P

Timing: 1

BRX INCREMENT INDEX & BRANCH



BRX increments the contents of the entire Index Register by one. If the resultant Index Register value contains a "1" in bit position 9 of the index, the computer transfers control to the effective location. If not, it takes the next instruction in sequence.

If a BRX instruction is indexed, any transfer of control is to the effective address determined by the value of the index immediately prior to the execution of BRX. The test for transfer is on the incremented value of the Index Register, just as if the BRX instruction were not indexed.

The most significant bits of the Index Register (bits 0-8) have no effect on the execution of the instruction, but may be affected by it.

If a branch occurs, an interrupt cannot occur following the execution of this instruction.

EXAMPLE:

Location	Instruction	X Register
0777	STA 1500	77777776
1000	BRX 1006	77777777
1001	LDA 2000	
1006	BRX 1001	00000000
1007	LDA 2100	00000000


The execution of these instructions is in the following order as given by their locations:

0777
1000
1006
1007

Registers Affected: X

Timing: 1, if branch
2, if no branch

BRM MARK PLACE AND BRANCH



BRM stores the contents of the P Register (the address of the BRM instruction itself) in the effective memory location and transfers control to the effective memory location plus one. BRM also stores the status of the Overflow Indicator in bit 0 of the effective location and EM3 and EM2 in bits 3-5 and 6-8, respectively. The contents of bits 1-2 of the effective location are unpredictable. The content of bit 9 is zero.

EXAMPLE:


Location	Instruction	EM3	EM2	Overflow Indicator	Location 0522	P Register
01517	BRM 522	3	2			
Before Execution		1 (on)	---		01517	
After Execution		1 (on)	43201517		00523	

Note: Use this instruction to enter subroutines where a return to the main program is desired after the subroutine has been completed. Use RETURN BRANCH (51) to return to the main program.

Registers Affected: M

Timing: 2

BRR RETURN BRANCH



BRR copies the contents of the effective memory location into an internal register and increments the contents by one. The instruction then stores the least significant 14 bits in the P Register. It also performs a logical OR between bit 0 and the Overflow Indicator; and places the result in the Overflow Indicator. There is no change in the contents of the effective memory location.

EXAMPLE:

Location	Contents
2100	BRR 2000
2000	00003220

If the computer executes the instruction in location 2100, it takes the next instruction from location 3221. Location 2000 still contains 00003220.

Note: Use BRR to return to the main program after completion of a subroutine in conjunction with MARK PLACE AND BRANCH (43).


The Memory Extension registers are unaffected by BRR.

Registers Affected: Overflow Indicator

Timing: 2

TEST AND SKIP INSTRUCTIONS

SKE SKIP IF A EQUALS MEMORY




SKE compares the contents of the A Register with the contents of the effective memory location. If the contents of A equal the contents of the effective location, the computer skips the next instruction in sequence and executes the following instruction. If the contents of A do not equal the contents of the effective location, the computer executes the next instruction in sequence. SKE alters neither A nor memory.

Registers Affected: None

Timing: 2, if no skip
3, if skip

SKG SKIP IF A GREATER THAN MEMORY




SKG algebraically compares the contents of the A Register with the contents of the effective memory location. If the contents of A are greater than the contents of the effective location, the computer skips the next instruction in sequence and executes the following instruction. If the contents of A are less than or equal to the contents of the effective location, the computer executes the next instruction in sequence. SKG alters neither A nor memory.

Registers Affected: None

Timing: 2, if no skip
3, if skip

SKM SKIP IF A EQUALS MEMORY ON B MASK



SKM compares selected bits of the contents of the A Register with the corresponding bits in the contents of the effective memory location. If the selected bits in A are identical to the selected bits in the contents of the effective memory location, the computer skips the next instruction in sequence and executes the following instruction. If the selected bits in the contents of the A Register are not identical to the contents of the effective location, the computer executes the next instruction in sequence.

The programmer selects the bits in A to be compared by placing ones in the corresponding bit positions of the B Register and zeros in the remaining bit positions of B.

SKM considers the contents of A, B, and the effective location to be unsigned, 24-bit, non-numeric quantities, and does not alter them.


EXAMPLE:

<u>A</u>	<u>B</u>	<u>Memory</u>
00043007	00177000	57643240

Since SKM compares bit positions 8-14 only (as determined by B), and (A) = (M) in these positions, a skip occurs. Note that if (B) = 0, a skip occurs regardless of (A) and (M). Note also that if (B) = 77777777, instruction SKM functions identically like instruction SKE.

Registers Affected: None Timing: 2, if no skip
3, if skip

SKA SKIP IF A AND MEMORY DO NOT COMPARE ONES



SKA compares the contents of the A Register, bit by bit, with the contents of the effective memory location. If the contents of the A Register and the contents of the effective location do not have any one pair of ones in corresponding bit positions, the computer skips the next instruction in sequence and executes the following instruction. If the contents of the A Register and the contents of the effective location do have at least one pair of 1-bits in corresponding bit positions, the computer executes the next instruction in sequence.

The instruction logically ANDs corresponding bits in A and Memory, based on the following table:

<u>A</u>	<u>Memory</u>	<u>Result</u>
0	0	0
0	1	0
1	0	0
1	1	1

If the result produces a "1" in any bit position, a skip does not occur.


Note: Different configurations of the memory word result in a wide variety of conditional instructions for use by the programmer. Some representative configurations are:

<u>Memory Configuration</u>	<u>Instruction</u>
40000000	Skip if A is Positive
77777777	Skip if A = 0
00000001	Skip if A is Even

<u>Contents of A Register</u>	
40000000	Skip if Memory is Positive
77777777	Skip if Memory = 0
00000001	Skip if Memory is Even

Registers Affected: None Timing: 2, if no skip
3, if skip


SKB SKIP IF B AND MEMORY DO NOT COMPARE ONES



This instruction functions identically like SKA but operates on the B Register.

Registers Affected: None Timing: 2, if no skip
3, if skip


SKN SKIP IF MEMORY NEGATIVE



If the contents of the effective memory location are negative, i.e., if (M₀) = 1, the computer skips the next instruction in sequence and executes the following instruction. If the contents of the effective location are positive or zero, the computer executes the next instruction in sequence.

Registers Affected: None Timing: 2, if no skip
3, if skip

SKR REDUCE MEMORY, SKIP IF NEGATIVE




SKR reduces the contents of the effective memory location by one, places the result in the same location, and then tests for negative. If the contents of the effective memory location are then negative, the computer skips the next instruction in sequence and executes the following instruction. If the contents of the effective location are positive or zero, the computer executes the next instruction in sequence.

An overflow occurs if the initial contents of memory are 40000000. The result in memory in this case is 37777777.

Registers Affected: M, Overflow Indicator Timing: 3

SKD DIFFERENCE EXPONENTS AND SKIP



SKD subtracts the contents of bits 15 through 23 of the effective memory location from bits 15 through 23 of the B Register. It then stores the absolute magnitude of the difference in bits 15 through 23 of the X Register and destroys the contents of bits 0 through 14 of the X Register. If the 9-bit contents of the effective location are less than or equal to the 9-bit contents of the B Register, the computer executes the next instruction in sequence. If not, the computer skips the next instruction in sequence and executes the following instruction.

Registers Affected: X Timing: 2, if no skip
3, if skip

SHIFT INSTRUCTIONS

The shift instructions operate on the contents of the A and B Registers and offer a complete facility for right and left shifting, cycling, and normalizing the contents of these two registers. The A and B Registers, in combination, form a double-length register whose double-length contents can be shifted, cycled, or normalized. This double-length register is named "AB."

When the contents of the AB Register shift right, bits from bit position 23 of the A Register shift into bit position 0 of the B Register. When the AB Register shifts left, bits from bit position 0 of the B Register shift into bit position 23 of the A Register.

The 48-bit contents of the AB Register may be cycled using the shift instructions. When the contents of the AB Register cycle, the bits that shift from one end of the one register copy into the other end of the other register.

These instructions use the instruction code to determine the direction of shift (66=right; 67=left); bits 10-11 (octal position 3) of the instruction address determine the method of shifting as follows:

Bits 10, 11	Octal Value	Function
00	0	AB Shift
10	2	AB Cycle
01	1	Normalize (Left only)

Indirect addressing is permissible with these instructions, bits 10 and 11 of the effective address determining the method of shifting.

Since the type of shift and number of shifts are determined by bits 10 through 23 of the effective address, indirect addressing and/or indexing drastically alter the action specified in a shift instruction. When procuring the effective location for a shift instruction,

14-bit indexing is performed with all indirectly addressed operands, and


9-bit indexing is performed with all directly addressed operands.

That is, indexing with a direct address can affect only the 9-bit shift count.

When the computer interprets a shift instruction, bit positions 15 through 23 of the effective address of the instruction determine the amount of the shift. The computer treats these nine bits as an unsigned count. If the initial count is equal to zero, no shifting occurs. If the initial count is greater than 48, it is set to 48 prior to shifting. Once the shift begins, the count reduces by one for each position shifted until it reaches zero. The count C in the following instructions indicates the number of places to be shifted. Shift timing is:

Left Shift and Normalize Count	Cycles	Right Shift Count
0 - 6	2	0 - 3
7 - 28	3	4 - 14
29 - 48	4	15 - 25
49 - 48	5	26 - 36
	6	37 - 47
	7	48

RSH RIGHT SHIFT AB



RSH shifts the contents of the AB Register (that is, A and B Registers) right the number of places specified in bits 15 through 23 of the effective address. The bit in the sign position of A does not shift, but its value copies into the vacated bit positions of the shifted number. The bit in the sign position of B shifts. Bits shifted out of A₂₃ shift into B₀. Bits shifting past position B₂₃ are lost.

Registers Affected: A, B

Timing: 2-7


EXAMPLE:

The instruction is: RSH 00022

	A	B
Before Execution	45261237	27651260
After Execution	77777745	26123727

Note: This instruction may perform scaling of floating-point numbers by use of indexing, where the difference of exponents is in the Index Register as positive quantity.

LRSH LOGICAL RIGHT SHIFT AB




LRSH performs a logical right shift. It shifts the contents of AB right the number of places specified in bits 15 through 23 of the effective address. The bits in the sign position of A and the sign position of B shift with the rest of the number. Vacated bits on the left fill with zeros. Bits shift out of A₂₃ into B₀. Bits shifting past B₂₃ are lost.

Registers Affected: A, B

Timing: 2-7

RCY RIGHT CYCLE AB



RCY shifts the contents of the AB Register right the number of places specified in bits 15 through 23 of the effective address. The bit in the sign position of B shifts like any other bit in B. Bits shifting out of A₂₃ shift into B₀. Bits from bit position 23

of B go into bit position 0 of A. The computer treats the double-length register as if it were circular and cycles it onto itself; it loses no bits.

Registers Affected: A, B


Timing: 2-7

EXAMPLE:

The instruction is: RCY 00017

	<u>A</u>	<u>B</u>
Before Execution	61235703	41537701
After Execution	37701612	45703416

LSH LEFT SHIFT AB



LSH shifts the contents of the AB Register left the number of places specified in bits 15 through 23 of the effective address. Bits shift left through the sign position of A, but when a bit, different in value from the original sign, shifts into the sign position, the computer sets the Overflow Indicator. Bits shifting out of B₀ go into A₂₃. Bits shifting past position 0 in A are lost. Zeros fill the vacated bit positions on the right end of the B Register.

Registers Affected: A, B, Overflow Indicator


Timing: 2-5

EXAMPLE:

The instruction is: LSH 00022

	<u>A</u>	<u>B</u>
Before Execution	46712370	64132711
After Execution	70641327	11000000

LCY LEFT CYCLE AB



LCY shifts the contents of the AB Register left the number of places specified in bits 15 through 23 of the effective address. The bits in the sign positions of A and B shift like any other bits in the number. Bits shifting out of B₀ shift into A₂₃. The instruction copies bits that shift from bit position 0 of A into bit position 23 of B. The computer treats the double-length register as if it were circular and cycles it onto itself. It loses no bits.

Registers Affected: A, B


Timing: 2-5

EXAMPLE:

The instruction is: LCY 00011

	<u>A</u>	<u>B</u>
Before Execution	71432560	34156723
After Execution	32560341	56723714

NOD NORMALIZE AND DECREMENT



NOD shifts the contents of the AB Register left until (1) a bit appears in position 1 of A that is not equal to the bit in the sign position of A, or (2) until C shifts occur. The computer keeps count of the number of places shifted and when the normalize operation is completed, it subtracts the count from the contents of the Index Register and places the result back into the Index. If, in the attempt to normalize, shifting exceeds 48 places, the contents of the AB Register were initially zero. In this case, the computer subtracts 48 from the Index Register. Zeros fill the vacated positions.

The number, C, placed in address bit positions 15 through 23, is an upper limit for the number of left shifts that will occur. The programmer must ensure that C is sufficiently large to permit a complete normalization.

EXAMPLE:


NOD 30

	<u>A</u>	<u>B</u>	<u>X</u>
Before Execution	00004632	76124035	00000000
After Execution	23153705	20164000	77777765

Registers Affected: A, B, X

Timing: 2-5

REO RECORD EXPONENT OVERFLOW



This instruction causes the Overflow Indicator to be turned on if the content of bit 14 of the Index Register is not equal to the content of bit 15 of the Index Register.


This instruction is normally used after a normalize operation to record a floating-point exponent overflow. See Floating-Point Operations, this section.

Registers Affected: Overflow

Timing: 1


CONTROL INSTRUCTIONS

HLT HALT



When the computer executes this instruction, it halts computation and lights the HALT indicator in the console. Before halting, the computer increments the P Register and brings the next

0 40 4000T



This instruction tests the contents of the extension register as follows:

<u>I</u>	<u>TEST</u>
----------	-------------

- 0 No test. The computer executes the next instruction in sequence.
- 1 Test EM2. If $(EM2) \neq 2$, the computer skips the next instruction in sequence. If $(EM2) = 2$, the computer executes the next instruction in sequence.
- 2 Test EM3. If $(EM3) \neq 3$, the computer skips the next instruction in sequence. If $(EM3) = 3$, the computer executes the next instruction in sequence.
- 3 Test EM3 and EM2. If $(EM3) \neq 3$ or $(EM2) \neq 2$, the computer skips the next instruction in sequence. When $(EM3) = 3$ and $(EM2) = 2$, the computer executes the next instruction in sequence.

Registers Affected: None

Timing: 1, if no skip
2, if skip

FLOATING POINT OPERATIONS

Floating-point operations are performed via Programmed Operator subroutines in either single or double-precision. Double-precision is used when accuracy of approximately 11 decimal digits must be maintained. Single-precision permits faster execution times with approximately seven decimal digits of accuracy.

These standard Programmed Operators assume that the most significant word is in A, or stored in location M + 1, while the less significant word is in B, or memory location M. See Section I, Floating-Point Format.

DOUBLE-PRECISION FLOATING-POINT OPERATIONS

Double-precision floating-point operations are performed using a fractional number of 39 bits (38 bits plus sign) and an exponent of nine bits (eight bits plus sign). Numbers are represented with a fraction equal to 11 decimal digits plus sign and a multiplier as high as $10^{\pm 77}$.

The Programmed Operator subroutines that perform double-precision, floating-point operations are:

<u>Design- ation</u>	<u>Name</u>	<u>Function</u>	<u>Approx. Execution Time</u>
FLA	Floating Add	Floating (A, B) $+ (M+1, M) \rightarrow A, B$	92 μ sec
FLS	Floating Subtract	Floating (A, B) $- (M+1, M) \rightarrow A, B$	101 μ sec
FLM	Floating Multiply	Floating (A, B) $\times (M+1, M) \rightarrow A, B$	147 μ sec
FLD	Floating Divide	Floating (A, B) $\div (M+1, M) \rightarrow A, B$	157 μ sec

SINGLE-PRECISION, FLOATING-POINT OPERATIONS

Single-precision, floating-point operations are performed using a fractional number of 24 bits (23 bits plus sign) and an exponent of nine bits (eight bits plus sign). Numbers are represented with a fraction equal to six decimal digits plus sign and an exponent as high as $10^{\pm 77}$.

The Programmed Operator subroutines that perform single-precision floating-point operations are:

Designation	Name	Function	Approx. Execution Time
FSA	Floating Add, Single-Precision	Floating (A) + (M+1) \Rightarrow A Exponent in B, M	77 μ sec
FSS	Floating Subtract, Single-Precision	Floating (A) - (M+1) \Rightarrow A Exponent in B, M	80 μ sec
FSM	Floating Multiply, Single-Precision	Floating (A) \times (M+1) \Rightarrow A Exponent in B, M	54 μ sec
FSD	Floating Divide, Single-Precision	Floating (A) \div (M+1) \Rightarrow A Exponent in B, M	101 μ sec

SDS 930 INSTRUCTIONS FOR FLOATING-POINT OPERATIONS

To maintain accuracy in floating-point operations, all fractional numbers must be in normalized form, that is, shifted to the left to eliminate leading insignificant digits. When a floating-point arithmetic operation has been performed, the fractional number must be normalized and the exponent adjusted to reflect the change in the fractional number. **NORMALIZE AND DECREMENT X** is used to:

- shift the fractional number to the left to eliminate leading insignificant digits.
- adjust the exponent (contained in the X Register) for each bit position shifted.

To determine whether the adjusted exponent has overflowed the 15th bit in the Index Register during the above normalize operation, the instruction, RECORD EXPONENT OVERFLOW (REO), is used. This instruction causes the Overflow Indicator to be turned on if $(X_{14}) \neq (X_{15})$.

When performing floating-point addition and subtraction, it is necessary to align the numbers so that the exponents are equal before the arithmetic is performed. The single instruction, **DIFFERENCE EXPONENTS AND SKIP (74)**:

- determines which of the numbers is to be shifted, and
- determines the number of positions to be shifted to align the numbers. Alignment is performed using SHIFT AB, Index bit equal to one, with the number of shifts located in the X Register.

Manipulation of the exponent is required in all floating-point operations. Capability is included in the Register Change instruction to:

- (a) transfer the exponent portion of the word to and from the A, B, and X Registers, and
- (b) clear exponent bits when arithmetic is to be performed.

These operations can be performed in effective combinations in one machine cycle.

III. INTERRUPT SYSTEM

PRIORITY INTERRUPT SYSTEM

SDS 900 Series Computers contain a priority interrupt system that provides added program control of input/output operations, aids in programming simultaneous input/output and compute operations, and allows immediate recognition of special external conditions.

Interrupts, as specified by the program, can signal when a single word or a block of words has been transmitted. When received, the internal logic examines the interrupt signal and causes the computer to interrupt the program sequence at the end of the execution cycle of the current instruction. Without disturbing the Program Counter Register, the computer transfers program control to one of a selected set of memory locations. A MARK PLACE AND BRANCH (BRM) instruction in this location saves the contents of the program counter, EM3, EM2, and overflow indicator and transfers to the particular interrupt servicing routine required. Entrance to the proper service routine occurs since each interrupt has a unique interrupt location. To exit from the routine, a BRANCH UNCONDITIONALLY (BRU) instruction using indirect addressing returns control to the next instruction in proper sequence in the main program; it also clears the interrupt. Note that when an interrupt occurs causing the execution of the BRM in the interrupt level, the address stored in the mark location is the location plus one of the instruction that was interrupted. In other words, the computer increments the program counter prior to inspecting its registers for an interrupt condition.

The priority interrupt system has up to 896 System interrupt levels. The levels are numbered upward from 200 and have priority according to number; the higher priority levels have a smaller number. See Table 3-1, Interrupt Locations, for the specific assignment.

The two standard as well as the additional interrupts obtained with SDS optional hardware are located at interrupt levels numbered from 30. In general, these have priority according to number like the System interrupts. Note that interrupts 30-77 have priority over any System interrupt (200 or more). The Power Fail-Safe option interrupts (in locations 36 and 37) are "out-of-order" interrupts; they have the highest priority of all.

When an interrupt has occurred and its service subroutine has been entered, an interrupt of higher priority can interrupt the subroutine and gain program control for the servicing of its more important operation. But an interrupt of lower priority cannot interrupt an interrupt-processing subroutine of a higher level. Thus, the priority interrupt system allows interrupts to be arranged according to their importance and/or according to their need for speedy servicing.

The above type of interrupt is called a normal priority interrupt to differentiate from another interrupt feature, the single-

instruction interrupt. This different kind of interrupt causes the execution of only one instruction before automatically clearing itself and returning to the program that it interrupted. For example, if an external clock source is connected to the computer so that it pulses an interrupt line at set intervals, the program can maintain a programmed real-time clock. Each time the external pulse causes an interrupt, the program executes the single instruction, MEMORY INCREMENT (MIN), to add one to the memory word selected for use as the programmed real-time clock. The main program can examine this memory location whenever necessary to determine how many time increments have elapsed since the clock was started.

If the single instruction that is executed is a branch instruction, and the branch occurs, the interrupt is cleared but there is no return to the program that was interrupted. This type of interrupt needs no branch instruction to clear it.

Since the single-instruction interrupt performs just one instruction and clears itself, it can be sandwiched into a priority system without disturbance. Any of the optional System interrupts (200-1777) can be single- or normal-instruction interrupts in any combination desired.

PRIORITY INTERRUPT OPERATIONS

A normal priority interrupt level has three operational states: Inactive, Waiting, and Active.

In the inactive state, no interrupt signal has been received into the level and none is currently being processed by its interrupt servicing subroutine.

In the waiting state, an interrupt has been received into the level, but is not being processed. This situation may be due to an interrupt of higher priority being processed at this time. When all higher waiting interrupts have been processed, this level goes to the active state.

In the active state, the interrupt has caused the main program to recognize its presence and has transferred to its assigned interrupt location where it is being processed. When the interrupt processing is completed, a BRANCH UNCONDITIONALLY (BRU) instruction with indirect addressing exits from the service subroutine by transferring control to the proper return location. This branch instruction also sets the interrupt level to the inactive state.

A single-instruction interrupt operates in the same way as the normal priority interrupt in the inactive and waiting states. However, when acknowledged, this interrupt enters the active state, and remains there during the execution of one instruction. At the completion of the one instruction, the single-instruction interrupt returns to the inactive state without the aid of a branch instruction. The single instruction must have a two-cycle or greater execution time.

INTERRUPT CONTROL

Two program control features are available in the interrupt system. These features are Arm/Disarm and Enable/Disable. Arm/Disarm controls whether an interrupt can proceed from the inactive state to the waiting state. When armed, an interrupt signal sets the interrupt to the waiting state. The disarmed condition causes that level to retain no record of an interrupt signal entering the level.

Enable/Disable operates on the entire interrupt system. When the interrupt system is enabled, the System interrupts (200-1777) are enabled; when the interrupt system is disabled, the system interrupts are disabled. Enable/Disable operates differently for the interrupts obtained with SDS options (30-77). Enable/Disable has no effect on the Power Fail-Safe interrupts; they are always enabled and armed. See the last two subsections of this section for a description of how the channel interrupts are affected.

The control of the optional Arm/Disarm feature operates on individual System interrupt levels, that is, any chosen interrupt

level may be selectively armed or disarmed. But the instruction structure for Arm/Disarm allows operation on these interrupts in groups of sixteen.

NON-INTERRUPTABLE INSTRUCTIONS

Three instructions prohibit interrupts following their execution. If a branch occurs, an interrupt cannot occur between the execution of INCREMENT INDEX AND BRANCH (BRX) and the instruction to which BRX branches. An interrupt cannot occur between the execution of ENERGIZE OUTPUT M (EOM) and the instruction following it or between the execution of ENERGIZE OUTPUT TO DIRECT ACCESS CHANNEL (EOD) and the instruction following it.

ENABLE/DISABLE INTERRUPT INSTRUCTIONS


Three instructions are available for setting, resetting, and testing the state of the INTERRUPT ENABLED indicator.

(COMPTON)

Table 3-1. Interrupt Location Assignments

30	Channel Y	Count Equals Zero (End-of-Word)
31	Channel W	Count Equals Zero (End-of-Word)
32	Channel Y	End-of-Record (End-of-Transmission)
33	Channel W	End-of-Record (End-of-Transmission)
36	Power ON	Power Fail-safe interrupt: Power Return
37	Power OFF	Power Fail-safe interrupt: Power below safe limit
60	Channel C	Count Equals Zero (End-of-Word)
61	Channel C	End-of-Record (End-of-Transmission)
62	Channel D	Count Equals Zero (End-of-Word)
63	Channel D	End-of-Record (End-of-Transmission)
64	Channel E	Count Equals Zero
65	Channel E	End-of-Record
66	Channel F	Count Equals Zero
67	Channel F	End-of-Record
70	Channel G	Count Equals Zero
71	Channel G	End-of-Record
72	Channel H	Count Equals Zero
73	Channel H	End-of-Record
74	Clock Sync. }	Locations 74, 75 are for the real-time clock
75	Clock Pulse }	
200 } 217 }	Group 0 Optional General-Purpose Interrupts	
220 } 237 }	Group 1 Optional General-Purpose Interrupts	
...	etc.	

EIR ENABLE INTERRUPT




EIR unconditionally sets the INTERRUPT ENABLED indicator and enables the interrupt system. If any interrupt levels are waiting, the one with the highest priority becomes active.

Registers Affected: None

Timing: 1

DIR DISABLE INTERRUPT




DIR unconditionally resets the INTERRUPT ENABLED indicator and disables the interrupt system. This instruction does not change the current state of any interrupt level.

Registers Affected: None

Timing: 1

IET INTERRUPT ENABLED TEST; SKIP IF INTERRUPT SYSTEM ENABLED




If the priority interrupt system is enabled, the computer skips the next instruction in sequence and executes the following instruction. If the priority interrupt system is disabled, the computer executes the next instruction in sequence.

Registers Affected: None

Timing: 1, if no skip
2, if skip

IDT INTERRUPT DISABLED TEST; SKIP IF INTERRUPT SYSTEM DISABLED



If the priority system is disabled, the computer skips the next instruction in sequence and executes the following instruction. If the priority interrupt is enabled, the computer executes the next instruction in sequence.


Registers Affected: None

Timing: 1, if no skip
2, if skip

ARMING FEATURE (Optional)

The arming feature is controlled for a group of 16 interrupts by a word sent to the group with the ARM INTERRUPTS (AIR) instruction followed by the PARALLEL OUTPUT (POT) instruction. AIR operates only on System interrupts (200-1777).

AIR ARM INTERRUPTS




AIR prepares the arm interrupt control unit to receive a control word for a group of 16 interrupt levels. A PARALLEL OUTPUT (POT) must always follow AIR, or an unpredictable operation results.

Registers Affected: None

Timing: 1

Section IV, Input/Output System, contains a discussion of PARALLEL OUTPUT (POT). The word that the POT instruction addresses has the following format:



The address field in bit positions 0 through 5 identifies which group of 16 interrupts in the system is being addressed. Address 00 refers to the group of locations 200-217. The C field controls what is done to the particular interrupt levels selected in bit positions 8 through 23. Bit position 8 refers to the lowest-numbered level of the group, therefore the one with highest priority. Bit position 23 refers to the last or highest-numbered level, the one with lowest priority. For example, a word of 00240000 arms level number 201.

The control operations are:

Bit Position	Octal Position	Octal Value	Function
6-7	02		
00		0	Not used
01		2	Arm all interrupt levels that are selected by a 1 in bit positions 8 - 23
10		4	Disarm all interrupt levels that are selected by a 0 in bit positions 8 - 23
11		6	Arm all interrupts selected by a 1 and disarm all interrupts selected by a 0 in bit positions 8 - 23.

CHANNEL INTERRUPT DESIGNATIONS

As shown in the Interrupt Location Table, each I/O channel has two interrupt levels. These reflect the two distinct uses of interrupts during channel input and output. Also, each W, Y, C, and D channel level has two names that reflect their use in the Extended or Compatible I/O Modes (see Section IV, Compatible/Extended Input/Output Modes).

END-OF-WORD/END-OF-TRANSMISSION INTERRUPT OPERATIONS; COMPATIBLE MODE

A program can use Channels W and Y as single-word, direct, program-controlled, input/output buffers. Special I/O instructions applicable to Channels W and Y control this type of operation (see Section IV). In this mode, the program can specify that interrupts occur as each word is transferred from the buffer to the peripheral device on output, or as soon as the buffer is filled from the peripheral device on input. This is the End-of-Word interrupt. The program can specify that an End-of-Transmission interrupt occurs when the buffer detects a signal such as End-of-Record from magnetic tape. During both input and output operations, this interrupt occurs when the peripheral device used in the transmission disconnects and the buffer becomes ready for another input/output operation.

These two interrupts also can control input/output termination for any communication channel when the program is operating the buffers in the block transmission or "interlaced" compatible mode (optional system). The End-of-Transmission interrupt operates in the fashion described above. In this mode, the End-of-Word interrupt only occurs on input. The End-of-Word interrupt occurs after the channel has read the number of words specified and then another word fills the buffer. If the program encounters the last word before an End-of-Transmission interrupt, the End-of-Word interrupt occurs after the next word is read. If an End-of-Record condition occurs first, the End-of-Transmission interrupt occurs. No End-of-Word interrupt occurs during output.

The Enable or Disable instructions "enable and arm" or "disable and disarm" the End-of-Word and End-of-Transmission interrupts when the channel is not operating in the extended interlace mode. When the EIR instruction is executed, the interrupt system is enabled and these interrupts are also armed; when DIR is executed, the system is disabled and these interrupts are also disarmed.

COUNT EQUALS ZERO/END-OF-RECORD; EXTENDED MODE

When the SDS 930 Input/Output System uses channels within its full capabilities, SDS 930 input/output functions control interlaced block transmission operations (see Input/Output Functions, Section IV). The interrupts used with the extended input/output function control are Count Equals Zero and End-of-Record. The Count Equals Zero interrupt occurs when the last of the number of words specified is placed into or brought

from memory. The End-of-Record interrupt occurs when the channel receives an End-of-Record signal (gap). Input/output functions can alter this latter occurrence for use with magnetic tapes.

EFFECTS OF THE ENABLE/DISABLE FEATURE ON ARMABLE INTERRUPTS

When operating an Input/Output Channel in the extended mode, the interrupt Enable feature controls the Armable interrupts (Count Equals Zero and End-of-Record). If a channel generates an extended mode I/O interrupt while the system is disabled, the designated interrupt level goes to the Waiting state. When the program again enables the interrupt system, the interrupt goes to the Active state when its priority allows.

This feature allows the programmer great ease in handling multiple channel operations. The interrupt processing subroutine for one channel can disable the interrupt system while it processes the interrupt. During this time, the system receives all other interrupts in their respective levels and goes to the Waiting state until the system is again enabled.




Figure 3-1. Interrupt Arm-Enable Response

IV. INPUT/OUTPUT INSTRUCTIONS

INTRODUCTION

The SDS 930 has a flexible, input/output system to complement its high, internal processing speed and versatile instructions. This system can transmit data in word, character, or single-bit form to and from the computer at the speed of internal computation. The input/output system assumes control of conditions imposed by different characteristics of a wide variety of devices, but leaves a high degree of input/output control to the programmer.

This system includes the following types of input/output:

Buffered input/output of data words, each under direct program control

Communication channel input/output of characters or words, time-shared with memory and multiplexed with computation.

Communication channel input/output of characters or words, fully buffered and simultaneous with computation.

Direct parallel input/output of up to 24 bits of information to and from external equipment, completely controlled and sequenced externally.

Direct parallel input/output of up to 24-bit words to and from external static registers under program control.

Single-bit input/output, such as equipment on/off status, sense switches, and pulsing and sensing of special devices.

DATA FLOW PATHS

The SDS 930 includes as standard equipment one Time-Multiplexed Communication Channel (TMCC), without interlacing capability, as well as provision for three additional channels. The interlace unit is available as an option. The W and Y channels are available with or without interlace; the C and D channels are available only with interlace. These channels are capable of automatically controlling the flow of data to and from memory at rates up to one word every 3.5 microseconds. These channels run independently of the central processor and only communicate with it to transfer data to or from memory.

In addition to the Time-Multiplexed Channels, a Direct Memory Access System is available. This system uses a path to memory separate from those used by the central processor. Up to four Direct Access Communication Channels (with direct access memory connections) can be attached to the Direct Access System. These channels operate like the time-multiplexed Channels except that they are faster and provide for a true overlap of input/output with processing.

A Data Multiplex System, which uses the direct access memory connection, is also available as an option. This system consists of a Data Multiplex Channel that accepts/transmits data words and memory addresses from many external devices or subchannels, all of which may be in operation at the same time. The system is capable of transmitting up to 572,000 words per second simultaneous with computation (see Appendix A-11).

COMMUNICATION CHANNELS

Using Channels W and Y, characters and words can be transmitted between memory and peripheral devices under the direct control of single instructions. Each channel has associated with it two instructions to facilitate direct control operations. For Channel W, W INTO MEMORY (WIM) causes a word from a peripheral transmission to be taken from the Channel W buffer register and placed directly in the specified memory location without disturbing any internal registers. MEMORY INTO W (MIW) causes a word to be taken from a specified memory location and placed in the Channel W buffer register to be read out to the currently operating peripheral device connected to the channel. WIM and MIW are preceded by instructions from the EOM group that set up the input/output operation. YIM and MIY instructions function in an analogous manner for channel Y. The general test instruction, SKIP IF SIGNAL NOT SET (SKS) provides the facility for testing error indications and/or for testing various peripheral device indicators.

Additionally, using any channel including Channels W and Y with interlace, data can be transmitted to and from core storage under channel control. Operation of a channel is initiated by the execution of a sequence of instructions in the central processor. Once started, the channel operates independently of the central processor, automatically transferring each word at the correct time.

Four instructions control the process of transmitting and receiving data between channel peripheral equipment and the central processor. These instructions are:

EOM	ENERGIZE OUTPUT M
EOD	ENERGIZE OUTPUT TO DIRECT ACCESS CHANNELS
POT	PARALLEL OUTPUT
SKS	SKIP IF SIGNAL NOT SET

EOM instructions activate one of Channels W, Y, C, or D, to select the peripheral device to be used, and to set up the initial conditions of the data transmission, including the peripheral operation to be performed. EOD instructions activate one of Channels E, F, G, or H. The other functions of EOD are similar to EOM. An EOM (EOD) instruction also specifies terminal conditions for an operation.

PARALLEL OUTPUT (POT) sends out to the channel the number of words in the transmission and the address at which the output begins.

SKIP IF SIGNAL NOT SET (SKS) can test the Error indicators, End-of-Transmission indicators, and other input/output control indicators, such as printer end-of-form or card hopper empty.

The general order of use of these instructions for interlaced operation is:

Instruction	Function
EOM	to address the channel, connect the peripheral device, specify various input/output conditions, and alert the optional channel interlace (see Communication Channel Input/Output)

<u>Instruction</u>	<u>Function</u>
EOM	to specify the terminal conditions and interrupts desired during the transmission
POT	to transmit to the channel a word containing the transmission starting address and block length

Bits 0 through 9 of this latter word contain the ten lower order bits of the word count; bits 10 through 23 contain the 14 bits of the starting address. The second EOM contains the high-order bits of the word count and starting address when needed.

DIRECT PARALLEL INPUT/OUTPUT

The direct parallel input/output (POT/PIN) facility allows any word in core memory to be presented, in parallel, at any special system connector or applicable standard peripheral connector; or, conversely, allows signals sent to a connector to be stored in any core memory location. EOM and SKS instructions control parallel input/output operations in the same way as in channel operations. POT/PIN instructions also generate or check for correct parity with each word transmitted.

See Direct Parallel Instructions, this section, for a detailed description of parallel input/output.

SINGLE-BIT INPUT/OUTPUT

EOM and SKS instructions also perform single-bit input/output and testing for special or standard devices. The execution of an EOM transmits a single signal of approximately 1.4 microseconds duration to an external connector and also provides the connector with a 15-bit address for the destination of this signal. SKS tests whether a similar signal is present on an external connector and skips accordingly. See Single-Bit Transmission, this section, for further description of single-bit input/output.

DIRECT MEMORY ACCESS SYSTEM

This optional system provides direct transmission between peripheral devices and core memory. Two access paths to the memory module are available. The standard path connects to the central processor; the other path connects to Direct Access Communication Channels on the Direct Memory Access Connection. Direct memory access allows data to be transmitted at the rate of one 24-bit word every 1.75 microseconds, thus sustaining an input/output rate of 572,000 words (equivalent to 2,284,000 characters) per second in parallel with full-speed computation.


Communication Channels, E, F, G, and H, if present in a system, require the Direct Memory Access System, and therefore, are called Direct Access Communication Channels. Operation of these channels is discussed in Communication Channel Input/Output, this section.

Note that the Direct Memory Access System may be obtained separately and used to incorporate special-purpose input/output equipment instead of the standard Direct Access Channels. Ex-

ternally controlled and sequenced devices may present data and addresses to the direct access connectors, thus allowing input/output operations or other memory accesses to be performed independently of the computer.

These special input/output systems present an address and various timing and control signals to the connector. External data may be stored in any specified location, or read from any location specified by the external unit. For example, the external equipment may provide an interface register, thereby allowing an entire block of data to be entered into or read from memory. Telemetry data may be automatically decommutated, thus obviating sorting and sequencing within the computer.

PRIMARY INPUT/OUTPUT INSTRUCTIONS



The major instruction for preparing Channel W (or Y, C, D) and an attached peripheral device to perform a data transmission or other peripheral activity is the multi-purpose instruction, ENERGIZE OUTPUT M (EOM). It operates in four distinct modes with many functional configurations. These modes are Buffer Control, Input/Output Control, Internal Control, and System Control. In the third and fourth modes, EOM controls and initiates non-communication channel operations such as special systems transmissions. Each of the frequently used EOM instruction configurations has a mnemonic tag used with standard SDS assemblers. These mnemonics appear in this manual with the description of the specified configurations. The different modes of operation are program-selectable by the setting of two bits (10, 11 of octal position 3) within the EOM instruction format:

<u>Octal Value</u>	<u>Bit Position 10</u>	<u>Bit Position 11</u>	<u>Area</u>
0	0	0	Buffer Control
1	0	1	Input/Output Control
2	1	0	Internal Control
3	1	1	System Control

A Buffer Control mode EOM operates essentially as a set-up or preparation facility for data transmissions or other peripheral activities using the channel. The channel to be used, the peripheral unit on that channel, the operation to be performed, and the type of character format to be used are all detailed within this EOM. It also details the use of BCD or binary data transmission, the allowance or not of a leader (as in paper tape), and the direction of operation (as in forward direction for magnetic tape). Execution of such an EOM "connects" the specified peripheral unit to the channel. An EOM in this mode can also alert the interlace, which is the optional, automatic buffer control for input/output.

An EOM in the Input/Output mode directs peripheral devices to perform non-transmitting operations such as rewind magnetic tape and upspace the printer. This EOM selects certain channel operations such as interrupt response and input/output terminal function desired. It alerts peripheral devices that a PARALLEL INPUT (PIN) or PARALLEL OUTPUT (POT) instruction follows. It also can give an extension of the word count to 15 bits for the number of words to be transmitted and an extension of the address specification to 15 bits. Without disturbing the associated channel, this EOM can also set up the interlace unit. It is with the input/output mode EOM that the user selects his I/O operation as compatible or extended I/O modes (described later in this section).

This coding sequence initiates such an interlaced channel operation (compatible mode):

<u>Instruction</u>	<u>Function</u>
EOM (Input/Output Control Mode)	Alert the interlace
POT	transmit starting address and block length to interlace
EOM (Buffer Control Mode)	address channel, connect peripheral device, specify various input/output conditions, start transmission


Initiating an interlaced input/output operation via this sequence of instructions facilitates checkout by allowing the programmer to single-step through this portion of the program. The first two instructions, EOM (Ioc) and POT, set up the interlace with data address and block length. Therefore, single-stepping through the sequence allows the interlaced channel to complete the input/output operation. When a single EOM (Buffer Control mode) sets up the channel and interlace with a POT instruction following, the programmer cannot step through the sequence since the input/output operation proceeds before the next stepped instruction (POT) places the address and block length in the interlace.

An EOM in the Internal Control mode enables and disables the interrupt system. EOM in this mode also can prepare the system for the selective arming and disarming of the system interrupt levels. This mode does not directly concern the input/output programmer.

An EOM in the System Control mode is specifically coded for a given installation and system. Address capability is 15 bits or 32,768 combinations for these special system designations.


Note: If an interrupt occurs during the execution of an EOM in any mode, no acknowledgement occurs until the completion of the execution of the instruction following the EOM.

EOD ENERGIZE OUTPUT TO DIRECT ACCESS CHANNEL



The EOD instruction operates in the Buffer Control and Input/Output Control modes. It refers to Channels E, F, G, and H, when present, and performs the same functions and operations as an EOM on these channels.

SKS SKIP IF SIGNAL NOT SET



The principal instruction for testing the states and responses of data channels and their attached peripheral devices, as well as testing internal and external indicators, is the multi-purpose instruction, SKIP IF SIGNAL NOT SET (SKS). SKS is a "skip class" instruction yielding a decision and transfer capability to all channels, devices, indicators, and systems that require it. It operates in four distinct modes: Special Internal Test, Channel and Device Test, Internal Test, and Special System Test. In the second mode, SKS tests channel-oriented, input/output functions. Each of the frequently used SKS instruction configurations has a mnemonic tag, used with SDS assemblers. These mnemonics appear in this manual with the description of the specific configuration.

These different modes of operation are program-selectable by the setting of two bits (10, 11 of octal position 3) within the SKS instruction format:

Bit Positions	Octal	Value	Area	Timing
10	11			
0	0	0	Special Internal Test	1, 2
0	1	1	Channel and Device Test	2, 3
1	0	2	Internal Test	1, 2
1	1	3	Special System Test	2, 3

In the Channel and Device Test mode, SKS tests a channel for channel Ready (not active), interlace Word Count Equal to Zero, and Error. This mode also tests peripheral devices directly. These include testing indicators in a magnetic tape unit such as Beginning-of-Tape, End-of-Tape, File-Protect Ring present, and End-of-File. For example, an SKS instruction might address an indicator within the printer to determine whether the paper is at the End-of-Form.

In the Internal Test mode, SKS tests whether the interrupt system is enabled or disabled, whether a breakpoint switch is set, and whether Overflow is set.

In the Special Internal and Special System Test modes, SKS tests signals of special configuration as the specific system requires.

COMMUNICATION CHANNEL INPUT/OUTPUT

GENERAL INFORMATION

SDS Communication Channels provide fully buffered, input/output control and transmission, multiplexed or simultaneous with computation. Up to eight data channels can connect to the central processor, all operating independently of each other.

Each channel can control as many as 30 input/output devices and automatically handles character, word assembly and disassembly, input/output parity detection and generation, data transmission to and from memory, and End-of-Transmission detection.

All channels are bi-directional and can communicate with 6-bit character devices or word devices of up to 24 bits. In the case of character-oriented devices, the program specifies the number of characters to be contained in each word during the transmission.

A channel buffer assembles and disassembles data words as they are transmitted between core memory and the peripheral equipment. The buffer maintains control of operations such as characters per word transmitted and direction of peripheral operation (as in magnetic tape forward/reverse).

A Buffer Control mode EOM or EOD sets up the channel buffer for operation. The execution of this EOM sets the operation controls, places the unit address in the buffer, and initiates data assembly/disassembly. The presence of the unit address activates the buffer, causing it to look for data coming from the peripheral device or from memory, as determined by the unit address.

When in use, a channel interlace controls the transfer of the data words going through the associated channel buffer. This interlace supplies the memory address of data coming from or going to memory and maintains the word count determining the number of words transferred. The terminal interrupts, End-of-Record and Zero Word Count, come from the interlace and are under its control. The interlace controls input/output termination functions during interlaced operation.

Two EOM instructions and a POT instruction alert and set up a channel interlace. The first EOM alerts the interlace, that is, activates the interlace and instructs it to expect a word count and starting address to be sent to it by the POT instruction. The second EOM is an Input/Output mode EOM that specifies the interrupt and the terminal function to be used. This EOM also can specify a 15th address bit and five more high-order word count bits expanding the word count from 10 bits to 15. This sequence is written: EOM (Alert), EOM (I/O), and POT. When the channel buffer is being set up at the same time, the buffer control EOM can alert the interlace. When the buffer is already set up, during a continuing I/O operation, the programmer may use the I/O EOM, ALERT CHANNEL (00250000), to alert the interlace.

When the programmer does not desire to program the Extended Mode with the input/output terminal functions, interrupts, and additional count or address, only the EOM (Alert) and the POT are necessary to set up the channel interlace (Compatible mode).

In the Extended Mode, the eight channels are programmed in the same way, though there is a distinction between Channels W through D and Channels E through H. The former group are Time-Multiplexed Channels; the latter are Direct Access Channels.

The Time-Multiplexed Channels use the memory logic of the central processor to facilitate input and output of data words. The transfer of each word between a time-multiplexed channel buffer and memory requires two memory cycles. During this time, computation stops in the central processor. Priority for the use of the word input/output logic is in the order: Channel D, C, Y, W. Any Time-Multiplexed Channel operating with interlace has priority over the central processor for memory access.

Each Direct Access Channel has its own independent memory logic. When memory access is needed to read or store a data word, computation stops for one cycle. When two or more Direct Access Channels require memory access simultaneously, determination of priority is as described in Appendix A-19.

Transmission to and from Direct Access Channels and core memory are under the control of the channel. At the onset of each memory cycle, the control unit interrogates all Direct Access Channels to determine whether any channel requires a transfer to or from computer memory; each channel gets priority on the basis of need. If, during a channel transmission, a transfer to or from computer memory is to take place, the computer connects the memory bank to the selected Direct Access Channel. If, simultaneously, the computer requires access to the same memory bank, the channel takes precedence and there is a delay of one memory cycle. If the computer is not accessing the same memory bank as the direct access channel, the transfer takes place without affecting computation speed. Thus, internal computation and direct access channel transmissions occur simultaneously and independently when the computer and channel are accessing separate memory banks. Channel control logic permits the transfer of only one word per memory cycle to and from the computer memory independent of the number of operating channels connected to the computer. Thus, the maximum transfer rate for the channel system is equal to one word every memory cycle, or approximately 572,000 words per second, or in excess of two and one-quarter million characters per second for direct access channels.

COMMUNICATION CHANNEL DESCRIPTION

Figures 4-1 and 4-2 contain block diagrams of the channels, the functional control of information between the channels, the Data Multiplexing System, the memory bank, and the external devices.

Up to 30 peripheral devices may be connected to one channel. Each of these devices has a unique, two-digit, octal address by which it is selected for an input/output operation. To select the peripheral device, the program loads the proper unit address into the 6-bit Unit Address Register (UAR) in the channel buffer. This address selects both the device and, if appropriate, the function to be performed. Placing a non-zero unit address in the Unit Address Register "connects" the peripheral unit addressed to the channel and it becomes "active". When the UAR contains a zero address, or any time that a terminal or initial condition clears the contents of UAR, the channel is "inactive." The zero in UAR also means that it is not connected to a peripheral unit.

When the channel and the peripheral unit to be used have been connected, the channel must have information pertaining to the location in memory of the data to be transmitted or received and pertaining to the number of data words in the transfer.





Figure 4-1. SDS 930 Time-Multiplexed Communication Channel, Block Diagram

TIME-MULTIPLEXED CHANNEL REGISTERS


In the Time-Multiplexed Channels W through D, there are two registers important to the programmer, the Word Assembly Register (WAR) and the Single-Character Register (SCR). The WAR, a 24-bit, word-sized buffer, contains the word of data actively being received or transmitted during an input or output operation. During input, 6-bit characters (plus parity) enter the Single-Character Register where the channel buffer assembles them, one at a time, into the WAR. Then the completed word is placed in memory. Depending on the number of characters per word specified, the word assembled and placed in memory during input has the form:

Word in Memory


One character per word mode




Two characters per word mode



Three characters per word mode



Four characters per word mode



The unfilled character positions contain unpredictable data. When assembled during a single-word operation, a WIM instruction places the word into memory. Under interlace control,

the interlaced channel automatically places the word in memory when assembled.

When the end of an information record is detected by a buffer, the buffer automatically disengages from the device and is then "ready" for another operation. The buffer logic is reset, except that the state of the error indicator is maintained and the last word of the input is still in the word register. If the number of characters in the input record was not a multiple of the number of characters assembled into each computer word, then zeros are automatically forced into the least significant positions of the last word. This last word can then be stored in memory by a BUFFER INTO M WHEN READY WIM or YIM instruction after the buffer has disengaged. If the number of characters in the input record was a multiple of the number of characters assembled into each computer word, then the word remaining in the W buffer is either the last group of characters from the input device, if they were not previously transferred to memory by a BUFFER INTO M WHEN READY WIM or YIM, or zeros if the last group of characters had been transferred to memory. In either case, it is safe to issue one such instruction after the buffer has disengaged without "hanging up" the computer.

During output, words come from memory into the WAR where the channel buffer disassembles them into the SCR one 6-bit character at a time. Depending on the characters per word mode specified, the 6-bit characters within the word are output as follows:


Function	Mode
Output one character from bits 0 through 5	One character per word
Output two characters from bits 0 through 5, 6 through 11	Two characters per word
Output three characters from bits 0-5, 6-11, 12-17	Three characters per word
Output four characters from bits 0-5, 6-11, 12-17, 18-23	Four characters per word

As required, the characters are transferred into the Single-Character Register and output with generated parity. After each character transfer, the word in the WAR is shifted left six bits to be ready for the next transfer. Only those characters needed from each word are used; when required, a new word is brought to the WAR for the next character. For special applications, a Time-Multiplexed Channel may be equipped with a 12- or 24-bit Single-Character Register. The external device which has a character size greater than 6 bits specifies to the channel what its size is, 12 or 24 bits. Standard 6-bit devices are unaffected by the installation of a wider SCR.

Interlace Registers

A channel interlace contains two working registers, the Word Count Register (WCR) and the Memory Address Register (MAR). In the set-up sequence -- EOM, EOM, POT -- for an interlaced input/output operation, the POT instruction transmits to the interlace a data word made up of the word count (that is, length) and the starting address of the data block. The 15-bit Word Count Register (WCR) contains the data word count during a data transfer. The number of data words is decremented by one and the new count replaces the old one in the WCR for each word transmitted.

The count is assembled into the WCR from two places: the least significant 10 bits is from the "POTted" word and the most significant 5 bits is from the "HI COUNT" field of the second EOM. The form of the "POTted" word is:



When the word count is equal to zero, the transmission is complete. During output, this causes a termination; during input,

the interlace allows any further data to fill the channel buffer and generates the End-of-Word interrupt, if enabled.

The Memory Address Register (MAR) contains the starting destination or source address in memory of the transmitted data. The memory locations to or from which data words are to be transmitted enter the MAR at the same time the word count does. During transmission of data, the interlace increments the contents of the MAR after each word as it decrements the contents of the WCR. These two registers provide the interlace control of block transmissions. The high-order 15th address bit comes from the second EOM, also.

DIRECT ACCESS CHANNEL REGISTERS

In the Direct Access Channels E through H, two other important registers are the Word Assembly Register (WAR) and the Input/Output Register (IOR). The Word Assembly Register is a 24-bit word-sized buffer which, during a transmission, contains the information actively being transmitted to, or received from, the external device. Information is assembled into, or disassembled from, the WAR in one of four character sizes, 6, 8, 12 or 24 bits. The 6-bit mode is the normal mode of operation. A device with a larger character size will send the channel a signal to indicate its character size. It is the programmer's responsibility to select a character/word count suitable for the character size.

(Time-Multiplexed channels can handle only 6-bit characters, standard. There are, however, two options which will increase the acceptable character size to 12 bits and to 24 bits. As with the DACCs the external device signals the TMCC with its character size.)

When receiving 6-bit characters from a peripheral device (operation is similar for other character sizes), the first character of a word enters the WAR into bit positions 18 through 23. When the WAR receives the next character, the first




Figure 4-2. SDS 930 Direct Access Communication Channel, Block Diagram

The Input/Output Register (IOR) is a 24-bit register which is a full-word buffer between the WAR and memory. The Direct Access Channel control unit places words into the IOR, awaiting their transfer to the WAR to be output. During input, the IOR receives full words from the WAR and places them into memory under control of the word count and memory address being used in the transmission. During multiple data word transfers, the WAR and the IOR simultaneously contain data information.

The **ENERGIZE OUTPUT M (EOM)** used in the Buffer Control mode addresses and connects the specified Channel W, Y, C, or D, and selects the desired unit address. The detailed instruction format is:





Table 4-1. Unit Address Codes

00	Disconnect	40	-
01	Type Input No. 1	41	Type Output No. 1
02	Type Input No. 2	42	Type Output No. 2
03	Type Input No. 3	43	Type Output No. 3
04	Paper Tape Input No. 1	44	Paper Tape Punch Output No. 1
05	Paper Tape Input No. 2	45	Paper Tape Punch Output No. 2
06	Card Reader Input No. 1	46	Card Punch Output No. 1
07	Card Reader Input No. 2	47	Card Punch Output No. 2
10	Magnetic Tape Input No. 0	50	Magnetic Tape Output No. 0
11	Magnetic Tape Input No. 1	51	Magnetic Tape Output No. 1
12	Magnetic Tape Input No. 2	52	Magnetic Tape Output No. 2
13	Magnetic Tape Input No. 3	53	Magnetic Tape Output No. 3
14	Magnetic Tape Input No. 4	54	Magnetic Tape Output No. 4
15	Magnetic Tape Input No. 5	55	Magnetic Tape Output No. 5
16	Magnetic Tape Input No. 6	56	Magnetic Tape Output No. 6
17	Magnetic Tape Input No. 7	57	Magnetic Tape Output No. 7
20	-	60	High-Speed Printer Output No. 1
21	-	61	High-Speed Printer Output No. 2
22	-	62	-
23	-	63	-
24	-	64	Incremental Plotter Output No. 1
25	-	65	Incremental Plotter Output No. 2
26	Disc File Input No. 1	66	Disc File Output No. 1
27	Disc File Input No. 2	67	Disc File Output No. 2
30	Scan Magnetic Tape No. 0	70	Magnetic Tape Erase No. 0
31	Scan Magnetic Tape No. 1	71	Magnetic Tape Erase No. 1
32	Scan Magnetic Tape No. 2	72	Magnetic Tape Erase No. 2
33	Scan Magnetic Tape No. 3	73	Magnetic Tape Erase No. 3
34	Scan Magnetic Tape No. 4	74	Magnetic Tape Erase No. 4
35	Scan Magnetic Tape No. 5	75	Magnetic Tape Erase No. 5
36	Scan Magnetic Tape No. 6	76	Magnetic Tape Erase No. 6
37	Scan Magnetic Tape No. 7	77	Magnetic Tape Erase No. 7

EOD ENERGIZE OUTPUT TO DIRECT ACCESS CHANNEL

The EOD instruction used in the Buffer Control mode alerts and connects the specified Direct Access Channel (E, F, G, H) and the desired unit address. The instruction format is:




Bit Designation	Octal Position	Octal Value	Function
B1	00	2	Bit positions 1 and 17 specify the channel to be activated. Channel E is numbered 00, Channel F is 01, Channel G is 10, and Channel H is 11.
B2	05	1	

All other indicators in the EOD are identical with EOM and function in the same way.

STANDARD EOM AND EOD CHANNEL INSTRUCTIONS

Several EOM and EOD function configurations have standard uses. These have standard, assembler-type mnemonics and are separate instructions.

ALC ALERT CHANNEL



ALC alerts the channel interlace. This instruction does not disturb the channel buffer in any way. ALC has no effect on W or Y Buffers without interlace.


The channel Alerts are:

Mnemonic	Alert Channel	Instruction
ALC 0	W	0 02 50000
ALC 1	Y	0 02 50100
ALC 2	C	2 02 50000
ALC 3	D	2 02 50100
ALC 4	E	0 06 50000
ALC 5	F	0 06 50100
ALC 6	G	2 06 50000
ALC 7	H	2 06 50100

Registers Affected: None

Timing: 1

DSC DISCONNECT CHANNEL




DSC disconnects the channel. It unconditionally sets the Unit Address Register to 00 regardless of whether the channel is currently addressing a device. This instruction disconnects any device which may be connected to the channel. It also unconditionally makes the channel Ready (Inactive) and clears the Error indicator.

Mnemonic	Disconnect Channel	Instruction
DSC 0	W	0 02 00000
DSC 1	Y	0 02 00100
DSC 2	C	2 02 00000
DSC 3	D	2 02 00100
DSC 4	E	0 06 00000
DSC 5	F	0 06 00100
DSC 6	G	2 06 00000
DSC 7	H	2 06 00100

Registers Affected: None

Timing: 1

ASC ALERT TO STORE ADDRESS FROM CHANNEL



ASC alerts an interlaced channel so the PIN instruction that follows can store the contents of the Memory Address Register. This instruction affects the operation of the channel in no other way. See Direct Parallel Instructions, this section, for a detailed discussion of PIN.

ASC is always used in conjunction with PIN to determine the current status of a peripheral operation being performed by the selected channel. The two instructions are written together:

ASC n

PIN m, x

When the program executes these two instructions, the contents of the effective memory location designated by the PIN instruction are:


Bit Positions	Contents
0 through 9	Zero
10 through 23	Contents of channel's Memory Address Register

Mnemonic	Channel	Instruction
ASC 0	W	0 02 12000
ASC 1	Y	0 02 12100
ASC 2	C	2 02 12000
ASC 3	D	2 02 12100
ASC 4	E	0 06 12000
ASC 5	F	0 06 12100
ASC 6	G	2 06 12000
ASC 7	H	2 06 12100

Registers Affected: None

Timing: 1

TOP TERMINATE OUTPUT OF CHANNEL



When the last word of a block enters the channel, TOP terminates channel output. After the execution of this instruction, the following occurs. When the channel buffer delivers the last character to the peripheral device, the buffer disconnects.

TOP always terminates a non-interlaced channel output operation. It may be used with all communication channels if the particular function selected is terminal function 11 but no further data output is required (see Terminal Functions, this section).

Mnemonic	Terminate Output on Channel	Instruction
TOP 0	W	0 02 14000
TOP 1	Y	0 02 14100
TOP 2	C	2 02 14000
TOP 3	D	2 02 14100
TOP 4	E	0 06 14000
TOP 5	F	0 06 14100
TOP 6	G	2 06 14000
TOP 7	H	2 06 14100

Registers Affected: None

Timing: 1

COMPATIBLE/EXTENDED INPUT/OUTPUT MODES

The termination of an I/O operation and the interrupts that may be associated with that termination fall into two classes: Compatible and Extended. The choice of one of these two "modes" of input/output operation determines how the system behaves when the termination of an I/O operation occurs.

As mentioned in Section III, Interrupt System, interrupts occurring at the same level (e.g., location 30, 31, etc.) can have different names (e.g., Count Equal Zero and End-of-Word). These names reflect the different I/O mode in operation when the interrupt occurs. The differences include the timing of interrupt occurrence relative to the I/O operation and type of interrupt requested.

The Compatible mode of operation for channels W, Y, C, D is directly compatible with the SDS 920 Computer mode of I/O operation. The types of interrupts that can be requested are the End-of-Word and End-of-Transmission interrupts.

The Extended mode for all channels expands the I/O capabilities to include the "terminal functions" discussed below. The types of interrupts that can be requested are the Count Equal Zero and End-of-Record interrupts.

The I/O mode is selected in the Input/Output EOM (EOD) via bit 12, the Interrupt Arm bit. A 0-bit makes the system operate in the Compatible mode; a 1-bit sets the system in the Extended mode.

In particular, the Interrupt Arm (IA) bit determines whether any of the Extended functions operate; that is, a "0" in IA means that the other Extended mode controls, bits 13, 14, 15 and 16, have no effect.

INPUT/OUTPUT CLASS EOM/EOD

The Input/Output EOM (EOD) selects the I/O operation mode. When the Extended mode is selected, this EOM also selects (arms) which interrupts are to be operational and selects the desired terminal function. This EOM applies to Channels W, Y, C, and D. EOD applies to Channels E, F, G, and H.

0	B1	0	02/06	0	0	1	I	E	Z	F	C	B2	A	H1	Count
0	1	2	3	8	9	10	11	12	13	14	15	16	17	18	19
00	01	02	03	04	05	06	07								

Bit Designation	Octal Position	Octal Value	Function
0			Bit positions 0 and 2 are not used with this EOM.
B1	00	2	Bit positions 1 and 17 specify the channel.
B2	05	1	
02/06	01-02	02/06	Bit positions 3 through 8 contain 02/06, the instruction code for EOM/EOD.
01	03	1	Bit positions 10 and 11 contain the EOM/EOD indicator for the Input/Output control mode.
IA	04	4	Bit position 12 selects the mode of I/O operation. A "0" specifies the Compatible mode. The operation of bits 13, 14, 15, and 16 are disallowed. Channels W, Y, C and D operate in this mode which is completely SDS 920-compatible. If interrupts are required, the user enables the Interrupt System, thus enabling and arming the End-of-Word and End-of-Transmission interrupts. A "1" specifies the Extended mode. All channels can operate in this mode. This allows the use of bits 13, 14, 15, and 16. If interrupts are required, the user arms the associated ones by placing 1-bits in bit 13 and/or 14. The "terminal function" to be used is selected via bits 15 and 16.

Note: A 1-bit in 13 and/or 14 does the following:

1. Arms that interrupt during this complete I/O operation; disconnecting this channel disarms the interrupt.
2. Once armed by bits 13 and/or 14, the interrupt can be enabled or disabled by the Enable/Disable feature of the Interrupt System. If a channel generates an extended mode I/O interrupt while the system is disabled, the designated interrupt level goes to the Waiting state. When the program again enables the interrupt system, the interrupt goes to the Active state when its priority allows.

Direct Access Communication Channels operate only in the Extended mode; therefore, a DACC does not examine bit 12, but assumes it to be a 1. Note that with the complete omission of this second EOM, a DACC operates in the IORD or terminal function 00 mode.

Bit Designation	Octal Position	Octal Value	Function
ER		2	Bit position 13 controls the arming of the End-of-Record interrupt. A 1-bit arms the interrupt. A 0-bit disarms the interrupt.
ZC		1	Bit position 14 controls the arming of the Zero Word Count interrupt. A 1-bit arms the interrupt. A 0-bit disarms the interrupt.
FC	05	0	Bit positions 15 and 16
		2	specify the terminal condition function to be performed with the transmission
		4	These are defined in the next topic in this section.
		6	
A			Bit position 18 is the high-order address bit.
HI Count			Bit positions 19 through 23 contain the most significant four bits of the 15-bit word count. These positions specify a word count greater than 1023.

TERMINAL FUNCTIONS; EXTENDED MODE

A 2-bit function code in the Input/Output EOM (EOD) controls the termination of input/output operation in the extended mode. These functions are described below with the letter C representing the specified word count of the transmission.

		Bit <u>Configuration</u>	Octal <u>Value</u>
IORP	INPUT/OUTPUT OF A RECORD AND DISCONNECT	00	0
	<u>Input</u>	Read C words. If C equals zero before the End-of-Record is detected, the rest of the record is ignored. At the End-of-Record, the peripheral device is disconnected and the channel becomes inactive.	
	<u>Output</u>	Write C words. When C equals zero, output is terminated (i.e., the device is signaled that the last characters have been transmitted). When the peripheral device has generated the end of record and, if necessary, checked the validity of the record, it sends an End-of-Record response to the Channel buffer. When received by the buffer, the End-of-Record signal generates an End-of-Record interrupt (if armed) and disconnects the channel.	
		The line printer generates the End-of-Record response when it completes the printing of a line. If the printer encounters any print errors or faults, it sends a signal to the channel that sets the channel error indicator; this can occur since the printer has	

not disconnected from the channel. The IORD is useful when the program is to print several lines and the program is not otherwise to use the channel between lines. When the printer completes each line, it causes an End-of-Record interrupt (assumed to be armed), notifying the program that it can immediately transmit the next paper control instruction and the next line image.

The unbuffered card punch operates similarly. It generates the End-of-Record response after punching each row. If any faults occur during the punching of the entire card, the card punch sends a signal to the channel that sets the channel error indicator; this occurs after punching the last row (row 9).

NOTE: A program should not use IORD with devices that do not have End-of-Record conditions on input (e.g., typewriter) or generate End-of-Record responses upon output termination, (e.g., devices such as the paper tape punch and typewriter). These devices do terminate output but give the program no indication when they receive the last characters.

		Bit Configuration	Octal Value
IOSD	INPUT/OUTPUT UNTIL SIGNAL THEN DISCONNECT	01	2
	<u>Input</u>	Read C words. When C equals zero or when the End-of-Record is encountered, the device is disconnected and the channel becomes inactive. If the channel disconnects because of a zero count, an EOR interrupt (if armed) will be generated in addition to the count equal zero interrupt. If both are armed, C=0 will occur first.	
	<u>Output</u>	Write C words. When C equals zero and when the last character has been transmitted, the channel disconnects the device and becomes inactive. If an End-of-Record signal is received before the count reaches zero, the channel will disconnect immediately.	
NOTE:	The IOSD is designed for use on devices which are normally operated on the basis of the word count only. Typewriters and paper tape devices are of this type, as are the printer and card punch when the user does not wish to stay connected until the operation is complete.		
IORP	INPUT/OUTPUT OF A RECORD AND PROCEED	10	4
	<u>Input</u>	Read C words. If the channel counts C down to zero before the peripheral device encounters the End-of-Record (EOR), the channel ignores the rest of the record (to the End-of-Record). When the peripheral device sends the End-of-Record signal to the channel, the channel sets its End-of-Record Indicator; this signal sets the End-of-Record interrupt (if armed). The channel does not disconnect. The channel is now in an "Inter-record" condition.	

When the peripheral device is magnetic tape, the tape continues to move when the tape handler encounters the End-of-Record. The End-of-Record occurs when the tape read-heads encounter tape gap; this also causes a Tape Gap signal to "come high". If the program executes a new read tape or scan tape EOM during the inter-gap time (approximately .75 millisecond while the Tape Gap signal is high), the tape remains in motion and proceeds to read or scan the next record. If the program executes no such EOM before the Tape Gap signal drops, the channel disconnects and the tape comes to a stop. No additional interrupt occurs. This is the only condition that causes a channel to disconnect automatically.

All other input devices remain connected until the program takes further action. The paper tape reader remains in motion; the program should issue a "disconnect channel" instruction if the program is not reading any more tape. To proceed after the End-of-Record occurs, the program first executes a Buffer Control mode EOM to re-initialize the Channel Unit Address Register and then reloads the interlace portion of the channel (the program can alert the Interlace via the Buffer Control EOM). Otherwise, the channel immediately terminates any attempt to use its interlace portion since the channel is aware that it is still active and in the End-of-Record condition. When the program continues from an Inter-record condition, the program should use an extended mode terminal function. An IORP should not be used to read devices which do not have EOR signals (e.g., the typewriter and paper tape reader).

Output Write C words. When the channel interlace counts C down to zero, the Interlace notifies the channel buffer that it has received the last word that is to be output; when the buffer outputs this last word, it sends a signal to the connected peripheral device indicating that the device has the last word now. When the peripheral device "receives, outputs and checks the validity of" this last word, it sends an End-of-Record response to the channel buffer. When received by the buffer, the End-of-Record signal generates an End-of-Record interrupt (if armed) and sets the Inter-record indicator; the channel does not disconnect.

When the peripheral device is magnetic tape, the tape continues to move after it signals End-of-Record. As in reading tape, the signal causes the Tape Gap signal to come high. If the program executes a new write tape or erase tape EOM during the inter-gap time (approximately one millisecond), the tape remains in motion and proceeds to write or erase a new record. If the program executes no such EOM before the Tape Gap signal drops, the channel disconnects and the tape comes to

a stop. No interrupt occurs at this time. This is the only condition which causes a channel to disconnect automatically.

To proceed after the End-of-Record occurs, the program first executes a Buffer Control mode EOM to re-initialize the Channel Unit Address Register and then reloads the interlace portion of the channel (the program can alert the Interlace via the Buffer Control EOM). Otherwise, the channel immediately terminates any attempt to use its interlace portion, since the channel is aware that it is still active and in the End-of-Record condition. When the program continues from an Inter-record condition, the program should use an extended mode terminal function.

A program should not use IORP with devices that do not generate End-of-Record responses upon output termination; such devices are paper tape and typewriter. These devices do terminate output but give the program no indication when they receive the last characters.

The IORP should also not be used with the printer and card punch since these devices expect the channel to disconnect after they send EOR.

IOSP	INPUT/OUTPUT UNTIL SIGNAL THEN PROCEED	Bit	Octal
		Configuration	Value
		11	6
<u>Input</u>	Read C words. If the channel counts C down to zero before the peripheral device encounters the End-of-Record, the channel generates a Count Equals Zero interrupt (if armed). The program should reload the interlace portion of the channel to continue reading the record. As far as the peripheral device knows, nothing happens at this time. Failure to reload the Interlace before the peripheral device sends enough characters to overfill the channel buffer causes a rate error; this sets the channel error indicator.		
	When the peripheral device encounters the End-of-Record, IOSP operates identically like the IORP command.		
<u>Output</u>	Write C words. When the channel counts C down to zero, the channel generates a Count Equals Zero interrupt (if armed); the channel does not terminate output. The program should reload the interlace portion of the channel to continue writing in the same record. Failure to reload the Interlace before the buffer transmits all of the characters in its registers and before the peripheral device requests the next character from the buffer results in a rate error; this sets the channel error indicator.		
	If the program executes a TERMINATE OUTPUT (TOP) instruction after the channel has counted C down to zero, the channel terminates the output and operates identically like the IORP from this point on.		

CHANNEL AND DEVICE SKS

The Channel and Device Test mode SKIP IF SIGNAL NOT SET (SKS) tests the indicators in a channel as well as devices attached to it. To test the channel, use unit address 00. The instruction format is:

CHANNEL TESTS

0	C	0		40		C	0	1	R	C	E	I	0	C	3		00	
0	1	2	3			8	9	10	11	12	13	14	15	16	17	18		23
O0			O1		O2			O3		O4			O5			O6		O7
Bit Designation			Octal Position	Octal Value	Function													
40			O1-O2	40	Bit positions 3 through 8 contain 40, the SKS instruction code.													
01			O3	1	Bit positions 10 and 11 contain the mode selection.													
C1			O3	4	Bits C1, C2, C3, used as an octal address, specify the channel to be tested. Channel W is 0, Channel Y is 1, and so on, Channel H being 7.													
C2			O0	2														
C3			O5	1														
R					Test for ready. A 1-bit selects the test. Skip if Ready or Inactive.													
C			O4	2	Test if indicator for Word Count Equal to Zero is set. A 1-bit selects the test. Skip if word count zero.													
E				1	Test for error indicator reset. A 1-bit selects the test. Skip if no error.													
I			O5	4	Test for Inter-record condition.													
00					Bit positions 18 through 23 are zero to specify a channel test. Each of these tests causes a skip when the test condition is true.													

STANDARD SKS INSTRUCTIONS

Several SKS function configurations have standard uses. These have standard, assembler-type mnemonics and are always used as shown.

CAT CHANNEL ACTIVE TEST;

SKIP IF CHANNEL NOT ACTIVE

0	40	14000								
0	2	3	8	9						23

If the channel is ready to accept a new input/output instruction, the computer skips the next instruction in sequence and executes the following instruction. If the channel is active, or in the process of disconnecting a peripheral unit, the computer executes the next instruction in sequence.

Mnemonic	Channel Active Test	Instruction
CAT 0	W	0 40 14000
CAT 1	Y	0 40 14100
CAT 2	C	2 40 14000
CAT 3	D	2 40 14100
CAT 4	E	0 40 54000
CAT 5	F	0 40 54100
CAT 6	G	2 40 54000
CAT 7	H	2 40 54100

Registers Affected: None

Timing: 2, if no skip
3, if skip

The following SDS 920-compatible instructions make the identical test as the above instructions on Channels W and Y;

BRTW 0 40 21000 W BUFFER READY TEST

BRTY 0 40 22000 Y BUFFER READY TEST

Registers Affected: None

Timing: 1, if no skip
2, if skip

The indicator that CAT tests is reset only by the next EOM that connects and alerts the same channel.

CET CHANNEL ERROR TEST;

SKIP IF NO ERROR ON CHANNEL

0	40	11000			
0	2	3	8	9	23

CET tests the error indicator in the channel for being in the set condition. If the error indicator has not been set, the computer skips the next instruction in sequence and executes the following instruction. If the error indicator has been set, the computer executes the next instruction in sequence.

Mnemonic	Channel Error Test	Instruction
CET 0	W	0 40 11000
CET 1	Y	0 40 11100
CET 2	C	2 40 11000
CET 3	D	2 40 11100
CET 4	E	0 40 51000
CET 5	F	0 40 51100
CET 6	G	2 40 51000
CET 7	H	2 40 51100

Registers Affected: None

Timing: 2, if no skip
3, if skip

The following SDS 920-compatible instructions make the identical test of Channels W and Y:

BETY 0 40 20020 Y BUFFER ERROR TEST

BETW 0 40 20010 W BUFFER ERROR TEST


Registers Affected: None

Timing: 1, if no skip
2, if skip

The indicator that CET tests is reset only by the next EOM that connects and alerts the same channel.

CZT CHANNEL ZERO COUNT TEST;

SKIP IF CHANNEL WORD COUNT IS ZERO



CZT tests whether the contents of the Word Count Register in the channel have been reduced to zero. If the contents of WCR are zero, the computer skips the next instruction in sequence and executes the following instruction. If the contents of the WCR are non-zero, the computer executes the next instruction in sequence.


<u>Mnemonic</u>	<u>Channel Zero</u> <u>Count Test</u>	<u>Instruction</u>
CZT 0	W	0 40 12000
CZT 1	Y	0 40 12100
CZT 2	C	2 40 12000
CZT 3	D	2 40 12100
CZT 4	E	0 40 52000
CZT 5	F	0 40 52100
CZT 6	G	2 40 52000
CZT 7	H	2 40 52100

[illegible]

The indicator that CZT tests is reset only by a POT instruction to set up the word count and data address in the same channel.

CIT CHANNEL INTER-RECORD TEST;

SKIP IF INTER-RECORD INDICATOR IS SET



CIT tests the Inter-record indicator in the selected channel. If the Inter-record indicator is set, the computer skips the next instruction in sequence and executes the following instruction. If the indicator is reset, the computer executes the next instruction in sequence. (See IORP instruction description under **TERMINAL FUNCTIONS** for Inter-record definition).


Channel Inter-		
<u>Mnemonic</u>	<u>Record Test</u>	<u>Instruction</u>
CIT 0	W	0 40 10400
CIT 1	Y	0 40 10500
CIT 2	C	2 40 10400
CIT 3	D	2 40 10500
CIT 4	E	0 40 50400
CIT 5	F	0 40 50500
CIT 6	G	2 40 50400
CIT 7	H	2 40 50500

[illegible]

The Inter-record indicator is set only during extended mode operation when using a Proceed Function; the indicator is set for an inter-record or zero count condition. The indicator is reset by the next alert and connect EOM.

DEVICE TESTS

The SKIP IF SIGNAL NOT SET (SKS) below, used in the Channel and Device Test mode, tests the condition of the peripheral devices in the system directly. The peripheral device sections contain the individual instruction descriptions.



C1	O3	4	Bit positions 9, 1, and 17 are used as an octal digit to specify the channel.
C2	O0	2	Channel W is 0, Channel Y is 1, and so on.
C3	O5	1	
40	O1-O2	40	Bit positions 3 through 8 contain the SKS instruction code 40.
01	O3	1	Bit positions 10 and 11 contain the mode selection.
Unit Tests	O4-O5		Bit positions 12 through 16 select the particular test and are system dependent.
Unit Address	O6-O7		Bit positions 18 through 23 specify the unit address.


SINGLE-WORD DATA TRANSFER VIA CHANNELS W AND Y

INSTRUCTIONS

Channels W and Y can be programmed as single-word input/output buffers. Data transfer is performed under direct program control or with the aid of the interrupt system. Interlace is not used with these instructions.

The following two instructions perform data transfer using Channel W.

MIW MEMORY INTO CHANNEL W WHEN EMPTY




MIW transfers the contents of the effective memory location into the Channel W word buffer. If necessary, the central processor "hangs up" until the buffer is empty and ready to accept the data word.

The W buffer must be connected to the desired peripheral device by a previous "connect" EOM instruction that selects the buffer, the unit address, and all appropriate control functions.

Registers Affected: None Timing: 2 + wait

WIM CHANNEL W INTO MEMORY WHEN FULL




WIM transfers contents of the Channel W word buffer into the effective memory location. If necessary, the central processor "hangs up" until the buffer is full and ready to deliver the data word.

Registers Affected: M

Timing: 3 + wait

MIY MEMORY INTO CHANNEL Y WHEN EMPTY




MIY transfers the contents of the effective memory location into the Channel Y word buffer. If necessary, the central processor "hangs up" until the buffer is empty and ready to accept the data word.

Registers Affected: None

Timing: 2 + wait

YIM CHANNEL Y INTO MEMORY WHEN FULL



YIM transfers the contents of the Channel Y word buffer into the effective memory location. If necessary, the central processor "hangs up" until the buffer is full and ready to deliver the data word.

Registers Affected: M

Timing: 3 + wait

SINGLE-WORD OPERATIONS

The single-word buffer operations are used in two ways. Data words transfer between the channel and memory under direct program control. The "connect" EOM and the input or output channel instruction are in sequence and the computer "hangs up" until the buffer is ready to perform the transfer. This delay is usually due to buffer tie-up while the buffer is actively transmitting or receiving the previously requested data word.

Use of the priority interrupt system eliminates the tie-up of the central processor. The interrupt system allows the program to connect the device to be used in the transfer, to enable the interrupt, and then to continue processing in the main program. When the buffer is ready to receive from, or transfer to, memory, the End-of-Word interrupt to the corresponding interrupt location notifies the program that the buffer is Ready. A service routine entered via a BRANCH AND MARK PLACE (BRM) instruction in the appropriate interrupt location processes the interrupt. This routine contains the instruction (MIW or WIM, for example) that can execute immediately without computer tie-up.

During single-word operations, a parity error or incorrect timing error sets the buffer error indication in the channel. The incorrect timing error occurs when characters enter the buffer during input before the removal of the previous word; during output, buffer error indication occurs if characters are needed for output before the buffer receives the next word. The transmission does not terminate upon detection of any of these errors.

The interrupt system can detect an End-of-Record termination. During output, use of TERMINATE OUTPUT (TOP) after the final MIW (MIY) causes an interrupt to the appropriate End-of-Transmission location when that final data word has been processed by the buffer. This interrupt takes the place of the End-of-Word interrupt; the End-of-Transmission condition inhibits the End-of-Word interrupt. During input, the End-of-Transmission interrupt is sent to the End-of-Transmission location when the End-of-Record is detected. During input from devices which do not generate an End-of-Record, an EOM disconnects (DSC) the channel to terminate the transmission. This termination generates no End-of-Transmission interrupt.

EXAMPLE: WIM

This program reads a block of binary paper tape of any length, using the W buffer without interlace. There is an integral multiple of four characters in the block. This subroutine uses the End-of-Word and End-of-Transmission interrupts of the W buffer and reads data into memory beginning in a table at location 1024.

<u>Location</u>	<u>Instruction</u>	<u>Address</u>	<u>Comments</u>
H	PZE		This is an assembler instruction used to reserve the entry location by filling H with Zero.
	EIR		This instruction enables the interrupts. An End-of-Word interrupt will be received after each word is assembled in the W buffer.
	RPT	0, 1, 4	This instruction initiates the paper tape read on Channel W, four characters per word (see Paper Tape Input/Output, this section).
	BRR	H	Return to the main program while awaiting the filling of the buffer with the first word read from tape.
TABLE	00002000		This location contains the input table starting address.
When the buffer fills with the first word, it generates the End-of-Word interrupt to location 31.			
31	BRM	H1	This branch and mark instruction transfers to the read routine.
H1	PZE		Reserved entry location.
	WIM	*TABLE	This instruction transfers the contents of the W buffer into the location specified in the contents of location TABLE. The * indicates indirect addressing. If desired, indexing can be used.
	MIN	TABLE	This instruction increments the location for the next input word.
	BRU	*H1	This instruction transfers indirectly back to the main program to await the next End-of-Word interrupt and clears the currently active interrupt.
The above procedure continues until the end of the block. When gap is detected, the remaining character positions of the word being assembled in the buffer fill with zeros, and the End-of-Transmission interrupt to location 33 inhibits the End-of-Word interrupt.			
33	BRM	H2	This instruction transfers and marks to location H2.
H2	PZE		This instruction reserves an entry location.
	BET	0	This instruction tests for the occurrence of an error during the input operation. If there were none, the next instruction is skipped and the following one is executed.
	BRM	ERR	This instruction transfers to an assumed error routine.
	BRU	*H2	This instruction returns to the main program. The read operation is complete.

Since in this example the input record has integral word-length, no characters are in the buffer when the End-of-Record is reached. If there are one, two, or three characters in the buffer when it detects the gap, an additional WIM has to be executed to place these characters into memory.


DIRECT PARALLEL INPUT/OUTPUT INSTRUCTIONS

Two instructions, PARALLEL OUTPUT (POT) and PARALLEL INPUT (PIN), permit any word in core memory to be presented in parallel at a connector; or, inversely, permit signals sent to a connector to be stored in any core memory location. The execution of a POT or PIN instruction causes a signal to be sent to the external device involved in the input/output operation. This signal notifies the device to send its data word as soon as it is operational. When the device becomes operational during a Read or PIN operation, it transmits a Ready signal to the central processor while at the same time presenting its data word. The computer places the received data word into a specified memory location without disturbing any arithmetic registers. The computer "hangs up" during the execution of PIN until it receives the Ready signal from the external device.

During the execution of a POT instruction, the central processor transmits a signal to the external device, alerting it to receive a data word. When the device becomes operational, it transmits a Ready signal to the central processor, which releases the data word to the external device. The computer "hangs up" during the execution of POT until it receives the Ready signal from the external device.

For special system requirements, POT and PIN can be used effectively with other instructions to produce high-speed, synchronized, data transfers between the central processor and external devices without the use of a communication channel. Selective input/output to and from these devices is accomplished by preceding POT or PIN with an EOM to alert the desired device by specific address. By preceding the POT or PIN with an SKS, the Ready signal of the special device can be tested after the execution of the EOM but prior to execution of the parallel transfer instruction; a possible computer "hang-up" can thereby be avoided. If the Ready signal from the external device sets one of the priority interrupts, parallel input/output operation can occur as soon as the external device is able to transmit or receive. Since the Ready signal initiating the interrupt is present through the POT or PIN execution, no computer "hang-up" occurs.

PIN PARALLEL INPUT




PIN stores the contents of 24 input lines in parallel in the effective memory location.

Registers Affected: M

Timing: 4 + wait

POT PARALLEL OUTPUT



POT transmits the contents of the effective memory location in parallel to 24 output lines of an external device.

Registers Affected: None


Timing: 3 + wait

SINGLE-BIT INPUT/OUTPUT

Operating in the System mode, the two instructions, ENERGIZE OUTPUT M (EOM) and SKIP IF SIGNAL NOT SET (SKS), provide single-bit input/output transmissions.

Execution of a System Mode EOM causes a signal of approximately 1.4 microseconds to be transmitted to one of a possible 16,384 signal destinations. The System Mode EOM format is:

EOM ENERGIZE OUTPUT M



Bit position 3 through 8 contain the EOM instruction code, 02.

Bit positions 10 and 11 contain the System Mode indicator.

Bit positions 12 through 23 contain the 12-bit address field that specifies the special system destinations.

Bit position 2 contains 0.

Bit positions 0 and 1 are reserved for special system address bits.


Registers Affected: None

Timing: 1

Execution of a System Test Mode SKS causes a 14-bit address to be presented to the collection of special system devices. If the addressed external device is supplying a set signal to the central processor, the computer executes the next instruction in sequence from the SKS. If no signal is set, the computer skips the next instruction in sequence and executes the following instruction.

The SKS System Test format, which has each corresponding bit-set identical to the System EOM format, is:

SKS SKIP IF SIGNAL NOT SET



Registers Affected: None

Timing: 2, if no skip
3, if skip

COMMUNICATION CHANNEL PROGRAMMING

EXTENDED MODE

Programming a block transmission of data using the full facility of the input/output system includes these instructions: EOM (Alert), EOM (I/O Control), and POT (PARALLEL OUTPUT).

A sample sequence of instructions from a magnetic tape read operation follows. The octal configuration of each instruction is given.

<u>Location</u>	<u>Instruction</u>	<u>Comments</u>
1000	0 02 42610	This EOM specifies Channel W, bits 1 and 17, (no 2 in O0, no 1 in O5) alerts the interlace, bit 9 (a 4 in O3) is in the Buffer Control mode (no 2 or 1 in O3) specifies forward direction of tape motion with no leader and BCD character format, bits 12, 13, 14, (a 4, no 2 and no 1 in O4) selects four characters per word assembly mode, bits 15, 16, (a 6 in O5) and connects the unit function address 10 to read tape number 0.
1001	0 02 15001	This EOM is in the Input/Output Control mode, selects the channel interrupt mode, bit 12, (a 4 in O4) disarms the End-of-Record interrupt, bit 13, (no 2 in O4) arms the Zero Count interrupt, bit 14, (a 1 in O4) selects terminal function 00, bits 15, 16, (no 4 or 2 in O5) and specifies high order word count of 01 (bits 20 through 23).
1002	0 31 01020	This POT transmits to the channel the contents of location 1020. The location contains the word count and the starting location for data input.
1020	0 03 13500	Bit positions 0 through 9 of this location contain the low order 10 bits of the word count. Bit positions 10 through 23 contain the 14 bits of the starting address

The channel assembles the starting address from the EOM, bit 18, and from the word transmitted by the POT. In this sample, the starting address for the read operation is 13500₈. The word count is assembled from the same EOM, bits 19 through 23, and from the word transmitted by the POT. In this sample, the word count is 02006₈. This is assembled as follows. Bits 19 through 23 of the EOM in location 1001 are 000 01; bits 0 through 9 of the transmitted word are 0 000 000 110. Assembling these bits into one 15-bit count, 000 010 000 000 110, the word count becomes 02006₈.

These three instructions read one magnetic tape record of 2006-word length into memory starting at location 13500. When the word count equals zero during the transmission, an interrupt is sent to Channel W interrupt level 31. Any further information

is ignored and when the tape reaches the End-of-Record, it is stopped, disconnected, and the channel becomes inactive.

COMPATIBLE MODE

In the Compatible mode of channel operation, the second EOM may be omitted if the word count is less than 1023 (1777₈) words and the starting addresses are less than 16383 (37777₈). The End-of-Word and End-of-Transmission interrupts are used when interrupts are desired. They can be armed/enabled or disarmed/disabled by the Enable/Disable instructions. Since the Extended input/output functions that are specified in the second EOM cannot be used, the latter two interrupts are used along with SKS tests to determine the terminal conditions of input/output transmissions. This I/O mode operates only for Channels W, Y, C, D.

A sample line print sequence programmed in the compatible mode follows:

<u>Location</u>	<u>Instruction</u>	<u>Comments</u>
1000	0 02 42660	This EOM specifies Channel W, alerts the interlace, specifies four characters per word, and connects the unit function address 60 for Printer Number 1.
1001	0 31 01030	This POT transmits to the channel the contents of location 1030.
1030	0 20 42000	The location contains the word count and the starting address for output. Bits 0 through 9 contain the word count of 41 ₈ ; the starting address is 2000 ₈ .

Since the input/output facility is less comprehensive in this mode, the user should be aware of the terminal conditions that will occur. For output, the mode is equivalent to functions 00 and 01; that is, when C words have been transmitted, the output terminates, and when the last character has been sent, the device disconnects. If the interrupt system is enabled, an End-of-Transmission interrupt to location 33 occurs when the device disconnects. No interrupt occurs on level 31.

For input, this mode is equivalent to functions 00 and 01 if the End-of-Record is encountered before the word count is reduced to zero. If the word count is reduced to zero before the End-of-Record is encountered, the interlace portion of the channel disengages all control of the channel buffer. The buffer con-

tinues to assemble characters until a word is completed. If the interrupt system is enabled, the buffer then generates an End-of-Word interrupt on level 31. The program has approximately 1.5 character times to reload the interlace if reading is to continue. On Channel W (or Y) the contents of the buffer at this time can be stored with the WIM (YIM) instruction.

If this form (EOM, POT) is used with Channels E through H, the Terminal Function mode is 00 with no interrupts armed.

This mode of channel operation should generally not be used on input unless the record length of the input records is fixed and known.

CONTROL CONSOLE

The basic SDS 930 Computer System provides a console for operator control. This console connects directly to the central processor, contains switches for operation, and displays the contents of operational registers.

DISPLAYS

The registers displayed on the console directly reflect the contents of the hardware registers. If the operator changes or clears a display, the contents of the actual register also change identically.

PROGRAM LOCATION

The program counter is a 14-bit register that contains the location of the next instruction to be executed. The programmer may change the counter by inserting a BRU into the Instruction Register and executing it. When the computer is in the IDLE state, this register displays the location of the instruction to be executed next.

INPUT/OUTPUT

The UNIT lights contain the unit address of the peripheral device currently connected to the selected channel.

The ERROR light reflects the status of the channel error indicator. Setting the I/O DISPLAY SELECT thumbwheel switch selects the channel to be displayed.

MEMORY EXTENSION

There are two memory extension indicators. The left one lights when EM3 does not contain three (3); the right one lights when EM2 does not contain two (2).

HALT

The HALT light is on whenever the computer executes an HLT instruction while in the RUN position. To clear this indicator, set the RUN-IDLE-STEP switch to IDLE.

OVERFLOW

This display shows the status of the Overflow Indicator.

REGISTER DISPLAY

This display consists of 24 binary indicators with a clear button for the entire register and a set button for each indicator. The REGISTER thumbwheel switch selects the internal register whose contents are to be displayed. The selectable registers are:

- C C Register, which contains the full instruction immediately prior to its execution
- A A Register
- B B Register
- X Index Register X

To change the contents of the selected register, press the indicator button(s) in the corresponding bit positions. The computer must be in the IDLE state and the register previously cleared. Pressing a button places a 1-bit into the selected position of the register.

MEMORY PARITY

If an operand or instruction access from memory encounters a parity error, this light turns on. Setting the MEMORY PARITY switch to CONTINUE clears the indicator and turns off the light.

INTERRUPT ENABLED

The INTERRUPT ENABLED light is on whenever the interrupt system is enabled.

SWITCHES

POWER

The POWER switch turns the computer system power on or off. When power is on, the switch is lit.

FILL

The operator has the option of four input media to initially load or "fill" the computer. The pair of three-position, spring-loaded, center-return, toggle FILL switches are labeled: PAPER TAPE - MAG TAPE and CARDS-DRUM. For example, to select and initiate filling from paper tape on Channel W, set the first toggle switch to PAPER TAPE and release.

The fill procedure is:

- a) Set up the selected input device with the input program. The initial portion of the program contains the "bootstrap" (the short-load program).
- b) Set the RUN-IDLE-STEP switch in the IDLE position.
- c) Press the START switch.
- d) Set the RUN-IDLE-STEP switch in the RUN position.
- e) Press one of the four FILL switches. This will cause a WIM 2 (03200002) instruction to be inserted into the Instruction Register and will load the Index Register with 77777771. Depending on which switch is pressed, activation of one of the following four devices on Channel W will occur:

Paper Tape Reader No. 1 - Unit Address 04

Card Reader No. 1 - Unit Address 06

Disc File No. 1 - Unit Address 26

Magnetic Tape Unit No. 0 - Unit Address 10

The FILL switch also prepares the channel to operate in the forward, binary, four characters per word mode.

A "bootstrap" program must be in position to be read as the first input from the device. A typical bootstrap program is:




Figure 4-3. SDS 930 Control Panel

Location	Instruction	Address
00002	WIM	00012, 2
00003	BRX	00002
00004	LDX	00011
00005	WIM	00000, 2
00006	SKS	21000
00007	BRX	00005
00010	BRU	BEGIN
00011	OCT	Starting address with indirect address "tag"

The WIM 00002 instruction that is forced into the Instruction Register stores the first word of the "bootstrap" program in location 2. The computer then executes the contents of location 2. The Index Register, which contains -7, modifies the WIM in 2. The effective address of the WIM is then 00003 so that the second word is stored in 3. This word is a BRX back to the WIM.

These two instructions then load the remainder of the "bootstrap" program. The remaining six words can be those needed for the specific loading that is to be done. The one shown loads a record of any length. The Buffer Ready test in location 6 skips when the End-of-Record has been reached. In "bootstrapping" from paper tape or magnetic tape, the record may be of any length. From cards, the record is 40 words.

RUN-IDLE-STEP Switch

This is a three-position, toggle switch with two stationary positions and a spring-loaded, momentary position in STEP. In the RUN position, computation occurs at machine speed. In the IDLE position, the computer idles immediately after an instruction has been read from memory. If the REGISTER switch is in the "C" position, the REGISTER DISPLAY shows the complete instruction. In the STEP position, the computer executes the instruction and returns to the Idle state. Release the switch to the IDLE position before performing another step.

HOLD Switch

When the HOLD switch is on, the current contents of the program counter are held. Instructions inserted into the C Register and executed do not step the program counter (i.e., it is inhibited from counting).

START Switch

This switch initializes the control section of the computer. It resets all channels, clears the P Register, Overflow Indicator, Memory Parity Error Indicator, and sets up a HALT (00) instruction in the C Register. The RUN-IDLE-STEP switch must be in IDLE and the REGISTER SELECT switch must be at C when pressing this switch. It clears all interrupts and disables the interrupt system. The EM3 register is set to 3 and the EM2 register is set to 2.

REGISTER Select Switch

This four-position, thumbwheel switch selects the register to be shown on the Register Display lights.

I/O DISPLAY SELECT Switch

This eight-position, thumbwheel switch selects the channel from which the unit address and error indicator are displayed in the INPUT-OUTPUT lights.

INTERRUPT ENABLED Switch

If this switch is in the COMPUTER position, the Interrupt System may be enabled or disabled under program control. Placing the switch in the ENABLE position enables the Interrupt System regardless of program operations. The switch is stationary in the COMPUTER position and momentary in the ENABLE position.

MEMORY PARITY Switch

If this switch is in the HALT position, the computer enters an Idle state whenever a memory parity error occurs. If this switch is in the CONTINUE position, the computer does not change state when memory parity occurs.

BREAKPOINT Switches

The program may detect the status of these four switches by using a breakpoint test. The switches, labeled RESET and SET, control pre-determined options within the program.

MEMORY CLEAR Switches

To clear first 16 K words of memory, press the START switch and then press both MEMORY CLEAR switches simultaneously. To clear from 16 K through 24 K, set the Extend Memory Registers EM2 = 4 and EM3 = 5, then press these two switches simultaneously. To clear from 24 K to 32 K, set EM2 = 6 and EM3 = 7, then press both switches simultaneously.

INPUT/OUTPUT TYPEWRITER

The control console contains an electric, input/output typewriter for operator control, error or status messages, and similar functions. The Typewriter is connected to Channel W, has the input unit address 01, and the output unit address 41. Appendix A-1 lists the typewriter codes.

The typewriter control instructions follow. These sample instructions use Typewriter Number 1 on Channel W with four characters per word mode.

RKB 0, 1, 4 READ KEYBOARD W1,
4 characters/word 0 02 02601

This instruction alerts Channel W and connects Typewriter Number 1 to it. RKB prepares the channel to read input from the keyboard. It also lights the input indicator on the typewriter.

TYP 0, 1, 4 WRITE TYPEWRITER W1,
4 characters/word 0 02 02641

This instruction alerts Channel W and connects it to Typewriter Number 1. TYP prepares the channel to write output to the typewriter.

PROGRAMMING EXAMPLES

These examples present a straightforward sample of reading and writing with the typewriter under program control.

EXAMPLE: Typewriter Output

This routine causes the following message

ASSEMBLY DONE
ENTER NEW PROGRAM

to be typed out under program control. The computer stores the internal codes for these characters in memory beginning in location 2000. The routine inserts the carriage return code, 52, and the space code, 12, where needed and requests End-of-Record interrupt. It is written as a closed subroutine using interrupts, and uses Channel W and Typewriter Number 1.

<u>Location</u>	<u>Instruction</u>	<u>Address</u>	<u>Comments</u>
1000	PZE		This instruction is an assembler instruction, used here as a convenient way to reserve the entry location for sub-routine use.
	CLR		This clears the A and B Registers.
	STA	SWICH	This clears the location called SWICH. SWICH later indicates to the main program that output is complete.
	TYP	*0, 1, 4	This instruction connects Typewriter Number 1 to Channel W for output, specifies four characters per word mode, and alerts Channel W interlace. The instruction is an EOM with octal configuration, 0 02 42641.
	EXU	WRITE	This instruction causes the Input/Output EOM in location WRITE to be executed.
	POT	WRITE + 1	This instruction sends the word count and starting address in WRITE + 1 to the channel.
	BRR	1000	This instruction branches back to the main program.
WRITE	EOM 00403720	16200	This EOM specifies terminal output function code 01 (IOSD) and the End-of-Record interrupt. The word in WRITE + 1 specifies that eight words will output from memory beginning in location 2000. According to terminal function 01, when the word count equals zero during the transmission, the output terminates, and when the last character is out, the device disconnects; at this time, the interrupt occurs.

The computer processes the main program while the channel performs the output operation. When finished with the output, an interrupt to interrupt level 33, the End-of-Record location for Channel W, occurs.

33	BRM	OKAY	This instruction, placed in location 33, branches and marks to location OKAY elsewhere in memory.
OKAY	PZE		This instruction saves the entry location.
	MIN	SWICH	This instruction increments location SWICH as an indicator for the main program.
	BRU	* OKAY	This instruction branches to the main program and clears the active interrupt.

This is the internal code for the output message:

	A	S	S	E	M	B	L	Y	Sp	D	O	N	E	C/R	E	N
2000	21	62	62	25	44	22	43	70	12	24	46	45	25	52	25	45
	T	E	R	Sp	N	E	W	Sp	P	R	O	G	R	A	M	Sp
2004	63	25	51	12	45	25	66	12	47	51	46	27	51	21	44	12

EXAMPLE: Typewriter Input

The operator requests control to input four control characters. The subroutine is assumed to have been entered under program control. There is no request for terminal interrupts in this example.

<u>Location</u>	<u>Instruction</u>	<u>Address</u>	<u>Comments</u>
INPUT	PZE		This instruction saves the entry location.
	RKB	*0, 1, 4	This instruction connects Channel W to Typewriter Number 1, specifies the four characters per word mode, and alerts the interlace. The input request light is lit. The octal configuration of the instruction is 0 02 42601. The asterisk prefixed to the address of read and write controlling EOM instructions indicates the setting of the interlace alert bit (9).
	EXU	CHARS	This instruction executes the instruction at location CHARS.
	POT	CHARS + 1	This instruction transmits to the channel the word count and starting address.
	CAT	0	This instruction tests for channel not active. If the channel is active when the computer executes CAT, it executes the next instruction in sequence. If the channel is inactive, the computer skips the next instruction and executes the following one.
	BRU	\$-1	This instruction branches to the CAT instruction. The dollar sign and accompanying signed integer in the address field is an assembler declaration for the indicated number of locations prior to or following the current one. Plus indicates following.
	BRU	CHECK	This instruction branches to an assumed routine to determine what characters were typed in.
CHARS	EOM 00047640	14200	This EOM specifies terminal input function 01 and no interrupt at the end of transmission. The word in CHARS + 1 specifies that one word can be input into location 4000. Only one word is accepted before the channel disconnects and goes inactive. The Count Equals Zero causes channel disconnect.

PERIPHERAL EQUIPMENT DESCRIPTION


Communication channels facilitate a wide range of input/output operations. Combinations of input/output functions can perform Scatter-Read and Gather-Write operations. A channel may read many records into one contiguous area of memory, or skip portions of records and read subsequent portions.

This section describes some of the input/output devices, available in the computer system and explains their use.

PAPER TAPE INPUT/OUTPUT

Format

Paper tape used with the computer is one-inch wide, affording space for eight data holes and a sprocket hole in each frame of information. There are ten frames per inch of paper tape. Six hole positions contain information, one contains the odd parity check, and the eighth is unused.



The organization of information on the tape is in blocks. A block is a group of frames set off by a gap of at least one blank frame (in which only the sprocket hole is punched) at either end. Blocks may be of variable lengths.

For some operations a tape may consist of only one block, such as a source language tape prepared off-line. In this case, the program need not read the entire block at one time, but may stop the reader between frames, and then start again to read the remainder or another portion of the block.

Reading

All channel functions may be used in reading paper tape. An input/output function that terminates because of a zero count stops the tape between frames. A subsequent paper tape "read" starts the reader and allows the next frame to be read. An input/output function that terminates because of gap (End-of-Record) stops the tape after the first blank frame of the gap. When the tape starts, the tape reader ignores any leading blank frames. After reading information from the tape, the reader recognizes a blank frame as gap and signals the channel with an End-of-Record indication.

Punching

When a channel addresses the paper tape punch, the punch motor also starts (if not already on). If the punch instruction so indicates, the punch unit punches a segment of leader (gap, or blank frames). Bit position 13 of a Channel EOM or EOD instruction, which addresses the punch, contains a "0" to punch leader; bit position 13 contains a "1" to punch without leader.

EXAMPLES:

This instruction

PPT 0, 1, 1 0 02 02644

prepares the punch on Channel W to punch without leader. It sets the channel to operate with one character per word.

This instruction

PTL 0, 1, 4 0 02 00644

prepares the punch and produces about 12 frames of leader. It sets the channel to operate with four characters per word.

No channel terminal function produces End-of-Record gap after punching a block. The EOM instruction that addresses the punch can only generate a gap.

The punch operates at 60 characters per second, asynchronously. If the channel does not supply characters to the punch fast enough for operation at 60 cps, the punch waits for each character, losing no data and making no errors.

Programming

There are no status tests for the Paper Tape Reader or Punch, that is, they are always ready for operation. When a channel addresses either device, the device starts to send or accept data within approximately one character time. The reader and punch operate only in the binary mode and the forward direction; they ignore any different mode specified, and use the forward-binary mode. Unit addresses of 04 and 05 are for Paper Tape Readers 1 and 2, respectively, and unit addresses 44 and 45 are for Paper Tape Punches 1 and 2.

Paper Tape Instructions

The following instructions use Channel W, Paper Tape Number 1, with four characters per word format.

RPT 0, 1, 4 READ PAPER TAPE 0 02 02604

RPT initiates a paper tape read operation on tape read station number 1 connected to Channel W in the four characters per word format.

PTL 0, 1, 4 PUNCH PAPER TAPE WITH LEADER 0 02 00644

PTL initiates a paper tape punch operation on tape punch station number 1 connected to Channel W in the four characters per word mode. It generates approximately twelve frames of leader preceding the first punched frame.

PPT 0, 1, 4 PUNCH PAPER TAPE WITH NO LEADER 0 02 02644

PPT initiates a paper tape punch operation on tape punch station number 1 connected to Channel W in the four characters per word format. It generates no leader preceding the first punched frame.

The desired EOM, POT combination follows each of these instructions to control the input/output of data.

EXAMPLE: Punch Paper Tape

This program punches one block of 20 words beginning in location 2000. A twelve-frame leader precedes the block. The routine is a closed subroutine that uses interrupts.

<u>Location</u>	<u>Instruction</u>	<u>Address</u>	<u>Comments</u>
1000	PZE		This instruction saves a place for the entry location.
	CLR		This instruction clears the A and B Registers.
	STA	WHERE	This instruction clears a switch location used as an indicator to the main program for completion of the punch operation.
	PTL	*0, 1, 4	This instruction connects Channel W to Paper Tape Punch Number 1, specifies four characters per word mode, and alerts the interlace. The instruction specifies leader to be punched, and if not already on, turns the punch motor on. The octal configuration of this EOM is 0 02 40644.
	EXU	PUN20	This instruction executes the I/O Control EOM that sets the interrupt and selects output function 00.
	POT	PUN20 + 1	This instruction transmits to the channel the word count and starting address of the transmission.
	BRR	1000	This instruction branches back to the main program.
PUN20	EOM 01202000	16000	The EOM specifies terminal output function 00 (IORD) and the End-of-Record interrupt. The word in PUN20 + 1 specifies 20 words of output from memory to the punch beginning at location 2000 (0120 is 024g shifted right one place; it is merged with 02000 to make the "POTted" control word). According to terminal output function 00, when the word count equals zero during the transmission, the output terminates. The last word has not been fully transmitted at this time. When it is and the output is complete, the channel disconnects and the interrupt occurs.

When the Count Equals Zero interrupt occurs:

<u>Location</u>	<u>Instruction</u>	<u>Address</u>	<u>Comments</u>
33	BRM	END	This instruction branches and marks to END.
END	PZE		This instruction saves a place for the entry location.
	MIN	WHERE	This instruction increments WHERE as a flag.
	BRU	* END	This instruction returns to the main program and clears the interrupt level.

EXAMPLE: Read Paper Tape

This program reads a block of 64 characters from paper tape. The routine uses the four characters per word mode, making the input 16 words. It turns the tape station on and requests a Count Equals Zero interrupt, level 31, for the operation on Channel W. The routine is a closed subroutine.

<u>Location</u>	<u>Instruction</u>	<u>Address</u>	<u>Comments</u>
1000	PZE		This instruction saves a place for the entry location.
	CLR		This instruction clears the A and B Registers.
	STA	SWICH	This instruction clears location SWICH used as an input-finished indicator.
	RPT	* 0, 1, 4	This instruction connects Paper Tape Reader Number 1 to Channel W, specifies the four characters per word mode, and alerts the interlace. The octal configuration of this EOM instruction is 0 02 42604.
	EXU	REED	This instruction executes the EOM at location REED.
	POT	REED + 1	This instruction transmits to the channel the word count and starting address.
	BRR	1000	This instruction branches back to the main program for processing while the input operation is in progress.
REED	EOM 01003720	15200	This EOM specifies terminal input function 01 (IOSD) and the Count Equals Zero interrupt. The word in REED + 1 specifies that input into memory begins in location 2000 and that 16 words will be read before the operation terminates. When the word count equals zero, the interrupt occurs. Then the channel disconnects. When the tape read operation is complete, the Count Equals Zero interrupt occurs at level 31.
31	BRM	FNISH	This instruction, in location 31 for this example, branches and marks to location FNISH.
FNISH	PZE		This instruction saves the entry location.
	MIN	SWICH	This instruction sets an input-finished switch for use by the main program.
	BRU	*FNISH	This instruction branches back to the main program and clears interrupt level 31 from the active state.

The programmer can make a test to the channel, CET, for parity error during the read operation before the BRU instruction.

CARD INPUT/OUTPUT

Format

The computer uses 80-column cards in two formats. The card reader reads Hollerith-coded information from cards and transmits the corresponding SDS character codes to memory. In this mode, each column contains the equivalent of one 6-bit internal character. Appendix A-1 lists the character codes.

The card reader reads binary-coded information from the card with two 6-bit characters per column. In binary mode, two columns form a word. The top six rows (12-3) of column 1, for example, form the first character and the bottom six (4-9) the next character. The reader reads from column 1 to 80 in this top-bottom order. A single card holds 160 characters or 40 binary words.

Figure 4-4 shows the relation of Hollerith information on a card and in memory. Hollerith output to the punch is identically the reverse.

Reading

The card reader scans the card, column by column, starting with column one, and transmits either 80 or 160 characters to the channel depending on the mode of operation. When power is on and cards are in the hopper, the operator makes the card ready by pressing the START button. During program operation, the program must test for the ready condition before initiating a card read operation. Once an EOM instruction starts the card read, the desired channel function (EOM, POT) may control the flow of information into memory. In the Hollerith mode, any column read that is not punched in one of the 64 combinations listed in Appendix A-1 results in a Validity check. The presence of a Validity check causes an error signal to be sent to the channel and lights the VALIDITY CHECK light on the reader.

If the stacker should become full, or the hopper empty, the reader is not ready and the NOT READY indicator lights. The card reader remains in the NOT READY state until the operator corrects the situation and presses the START button. Upon reading the last card, the reader sets an End-of-File signal if the EOF ON switch is on. The central processor can test the End-of-File condition to determine if more cards are in the hopper.




Figure 4-4. Card Read Into Memory in Hollerith

Punching

The card punch punches cards a row at a time, starting with row 12. The punch coupler, in both the Hollerith and binary modes, automatically rearranges the information to be punched. The card punch program must present the entire card image, 80 or 160 characters, to the punch 12 times for each card. This is necessary because of the way the punch operates. As each row of the card approaches the punch station, the coupler examines every character of the image to determine which column positions in that row should be punched. After the 12th output, the card punch punches row 9 and completes the card cycle.

The card punch is Ready to punch if there are cards in the magazine, the stacker is not full, and the operator has pressed the START button. The punch remains Ready as long as the above conditions are true. A Punch Card instruction given when the punch is Ready causes a card to feed past the punch station. The program must then address the punch and give the same instructions 12 times to transmit the card image to the coupler.

Programming Instructions

The Card Reader and Punch instructions follow. They use unit number 1 on Channel W with the four characters per word transmission mode.

Card Read Instructions

CRT 0, 1 CARD READER READY TEST 0 40 12006

This test determines if the selected card reader is Ready to read. If so, the computer skips the next instruction in sequence and executes the following instruction. If the reader is Not Ready, the computer executes the next instruction in sequence.

FCT 0, 1 FIRST COLUMN TEST 0 40 14006

This test determines if the first column is about to be read by the card reader. Since the time elapsing between the execution of a card reader EOM and the reading of the first column is approximately 85 milliseconds (48,450 computer cycles), this test allows the computer to perform other operations during this time. If FCT is executed less than 1.2 milliseconds (approximately 685 computer cycles) before the first column is due to be read, the computer skips the next instruction in sequence and executes the following instruction. If FCT is executed 1.2 milliseconds (or more) before the first column is due to be read, the computer executes the next instruction in sequence (does not skip).

CFT 0, 1 CARD READER END-OF-FILE TEST 0 40 11006

This test determines if the End-of-File condition from the card reader has been detected. If not, the computer skips the next instruction in sequence and executes the following instruction. If the EOF condition has been detected, the computer executes the next instruction in sequence.

The reader remains in the End-of-File condition until the operator adds cards to the hopper or turns off the EOF ON switch.

RCD 0, 1, 4 READ CARD DECIMAL (Hollerith) 0 02 02606

RCD alerts the card reader, causes a card to feed from the hopper, and selects the Hollerith mode (as each column is read it is translated to an SDS internal code). This mode can read up to 80 characters (20 words) from a card.

RCB 0, 1, 4 READ CARD BINARY 0 02 03606

RCB alerts the card reader, causes a card to feed from the hopper and selects the binary mode (as each column is read it is transmitted as two 6-bit binary characters). This mode can read up to 160 characters (40 words) from a card.

SRC 0, 1 SKIP REMAINDER OF CARD 0 02 12006

This instruction causes the reader to stop transmission of characters to the channel. The remaining characters are not checked for validity, but a read check, feed check, or end-of-record condition still cause an End-of-Record interrupt and disconnect the card reader from the channel.

Card Punch Instructions

PBT 0, 1 PUNCH BUFFER TEST 0 40 12046

This instruction is used to test the status of the punch buffer. If the punch buffer is clear (empty) and ready for loading when PBT is executed, the computer skips the next instruction in sequence and executes the following instruction. If the punch buffer is not clear when PBT is executed, the computer executes the next instruction in sequence (does not skip). The punch buffer is always clear if the punch is ready to feed and punch.

CPT 0, 1 CARD PUNCH READY TEST 0 40 14046

This test determines if the selected card punch is Ready to punch. If so, the computer skips the next instruction in sequence and executes the following instruction. If the punch is Not Ready, the computer executes the next instruction in sequence.

Before the punch is Ready, the operator must place blank cards in the magazine and press the START button.

PCD 0, 1, 4 PUNCH CARD DECIMAL (Hollerith) 0 02 02646

PCD alerts the punch, causes a card to feed past the punch station, and selects the Hollerith mode. A transmission of 80 characters (20 words) must follow this instruction. The instruction PCD followed by the transmission instructions for 80 characters per card is repeated 12 times.

PCB 0, 1, 4 PUNCH CARD BINARY 0 02 03646

PCB alerts the punch, causes a card to feed past the punch station, and selects the binary mode. A transmission of 160 characters (40 words) must follow this instruction. The instruction PCB followed by the transmission instructions for 160 characters per card is repeated 12 times.

EXAMPLE: Card Read

This program reads one card in Hollerith mode. It is a closed subroutine that uses interrupts; assume the interrupt system is enabled.

<u>Location</u>	<u>Instruction</u>	<u>Address</u>	<u>Comments</u>
1000	PZE		This is an assembler instruction. It conveniently reserves a location for the subroutine entry.
	CRT	0, 1	This instruction is the card reader Ready test for Card Reader Number 1 on Channel W. If Not Ready, the computer executes the next instruction. If Ready, the computer skips the next one and executes the following instruction. The octal configuration is 0 40 12006.
	BRU	\$-1	This instruction branches back to the test on Not Ready. The programmer can put an exit to a Not-Ready corrective routine here.
	RCD	* 0, 1, 4	This instruction connects Card Reader 1 to Channel W, alerts the interlace, starts a card moving toward the read station, and specifies Hollerith mode. The octal configuration for this instruction is 0 02 42606.
	EXU	READ	This instruction executes the I/O Control EOM at location READ.
	POT	READ + 1	This instruction transmits to the channel the word count, and starting address.
	BRR	1000	This instruction branches back to the main program.
READ	EOM 01203720	15200	This EOM specifies terminal input function 01 (IOSD) and the Count Equals Zero interrupt. The word in READ + 1 specifies that a record will be read into memory beginning at location 2000 and specifies a 20-word limit.

The computer processes the main program while the channel performs the card read operation. When finished with the input, transmission of an interrupt will occur to the interrupt level 31, the Count Equals Zero location for Channel W.

31	BRM	TEST	This instruction, placed in location 31 for this example, branches and marks to location TEST.
TEST	PZE		This instruction saves a location for the routine entry.
	CET	0	This instruction tests for an error on Channel W. Its octal configuration is 0 40 11000.
	BRM	ERR	The computer executes this instruction if there is an error on Channel W. Assume that ERR is the entry to a corrective subroutine.
	BRU	* TEST	This instruction returns control to the main program and clears interrupt level 31. The computer executes this instruction if no error is detected.

EXAMPLE: Card Punch

This program punches one card in Hollerith mode. It is a closed subroutine that uses interrupts. The Index Register counts the 12 times the program presents the card image to the punch.

<u>Location</u>	<u>Instruction</u>	<u>Address</u>	<u>Comments</u>
1000	PZE		Saves the location for the subroutine entry.
	CLR		Clears the A and B Registers.
	STA	SWICH	Clears a switch for later use.
	LDA	1000	This pair of LDA and STA place the main program mark address in location ENTR2.
	STA	ENTR2	
	MIN	ENTR2	MIN adds one to the stored contents.
MCRDS	LDX	ROWS	Initializes the Index Register with 00077765 (octal), which is -11 decimal.
	CPT	0, 1	Tests the card punch for a Ready condition. The card punch is Number 1 on Channel W.
	BRU	\$-1	The computer executes this instruction if the punch is Not Ready. It branches back to the test, CPT 0, 1. The programmer can place an exit to a time loop here with the facility to tell the operator that the card punch will not become Ready.
GETRW	PCD	* 0, 1, 4	The computer executes this instruction if the punch is Ready. It alerts Channel W with interlace, connects Card Punch Number 1 to Channel W, starts a card moving toward the punch station, and specifies four characters per word and Hollerith mode.
	EXU	PNCH	Executes the EOM located in PNCH.
	POT	PNCH + 1	Transmits to the channel the word count and starting address.
	BRU	ENTR2	Branches back to the main program.
PNCH	EOM 01203720	16000	This EOM specifies terminal output function 00 (IORD) and the End-of-Record interrupt. The word in PNCH + 1 specifies that 20 words will be output from memory beginning in location 2000.
ROWS	00077765		Note that the program must send the card image to the channel twelve times to punch a card.
The computer processes the main program while the channel performs the output. When finished with the output, transmission of an interrupt will occur to the interrupt level 33, the End-of-Record location for Channel W.			
33	BRM	ENTR2	
ENTR2	PZE		Saves a location for routine entry.
	BRX	GETRW	Increments the index by one. If the base has not been incremented through zero, the next instruction executed is at location GETRW. When the base increments to zero, the computer executes the next instruction in sequence. The Index counts row times on the card.
	MIN	SWICH	Sets a switch to indicate to the main program that the punch operation is complete.
	BRU	* ENTR2	Returns control to the main program and clears the interrupt.

MAGNETIC TAPE INPUT/OUTPUT

Format

Magnetic tape units used in SDS computer systems are IBM-compatible. The tape is one-half inch wide, Mylar base material, 1.5 mils thick. Tape reels (10 1/2-inch, plastic) contain up to 2400 feet of tape. A reflective marker, placed on the back of the tape approximately ten feet from the beginning of it, indicates the load point. The leading ten feet leave space for threading tape through the guides on the unit. The load point marker is on the Mylar side of the tape along the edge nearest the operator when the tape is mounted. A similar marker is along the other edge of the tape to mark the end-of-reel. About 14 feet of tape are reserved between the End-of-Reel marker and the end of the tape. This space includes at least ten feet of leader and enough tape to hold a record of 9,600 characters in 200 bpi density after sensing of the End-of-Reel marker.

Character recording on tape is in seven parallel tracks. A change in the magnetic flux in a track records a 1-bit for a given character position. No change in magnetic flux indicates a 0-bit. Six of the tracks are for information; the seventh track is a parity check. The system allows both even and odd parity, as needed. Binary recording uses odd parity. In this mode, the tape unit records the six-bit characters from the channel without change. Binary-coded decimal (BCD) recording uses even parity. In this mode, the tape control unit transforms characters from the channel to conform to standard IBM, BCD interchange code (see Appendix A-1).

Arrangement of information on tape is in blocks that may contain one or more records. Only the capacity of available core storage in the computer limits block length. An inter-record gap (section of blank tape) about 3/4-inch long separates blocks of records on tape. In writing, the tape unit automatically produces gap at the end of a record or block. Reading begins with the first character sensed after the gap and continues until encountering the next gap.

An inter-record gap, followed by a special, single-character record, marks the end of a file of information. The character is a Tape Mark (0001111). Writing a one-word record in BCD with one-character-per-word format can record such a mark. A reel of tape may contain one or more files. On reading an End-of-File record, the tape control unit stops the tape and sets its End-of-File indicator, which the program may test.

The tape control unit considers any record that contains only Tape Mark (0001111) characters an End-of-File. The tape unit reads such characters into memory like any other characters.

As the tape unit writes information it makes an odd-even count of the number of 1-bits in each track. At the end of each record it writes a bit for each track such that the total number of 1-bits in each track is even. This parity check sum is always even whether the character parity is even or odd. The character containing these check bits is the longitudinal parity character; the tape unit writes it slightly past the end of recorded information in the block.

The longitudinal check character always reflects an even parity check for each channel. In the BCD mode, the check character itself always has an even number of 1-bits. In the binary mode, however, the check character may have either an even or an odd number of 1-bits. This means that a reverse scan over a binary record may result in turning on the error indicator

in the channel even though the record is correct. As a general rule, the program ignores the error indicator after a reverse operation.

It is possible to write tape in a 1-, 2-, or 3-character-per-word mode provided that the rate of characters is sufficient. On reading, however, the tape unit uses the character count to ascertain when it has read two characters and can look for gap. If a 1-character-per-word "read" is in operation, a single noise character will stop the tape. In reverse scan a 1-character-per-word operation causes the tape to stop after detecting the longitudinal check character at the end of the record. This means that the tape stops in the recorded information.

All scan operations must be in 3- or 4-character-per-word mode or the tape does not stop when it reaches gap.

As a general rule, the user should program tape units for three or four characters per word, if possible. The write-tape-mark operation is an exception to this rule.

Use of the TAPE READY TEST (TRT) between tape operations of opposite direction ensures that the tape unit stops and reverses. It is an advisable programming practice to terminate tape writing by several inches of erasure whenever subsequent resumption of recording is anticipated. This eliminates the effects of a possible extraneous character that might arise through subsequent tape repositioning.

Reading

Once a tape starts with a Read Binary or Read BCD EOM or EOD, it continues until the tape unit detects an End-of-Record gap. If the computer does not instruct the tape unit to continue, it stops in the middle of that gap. When the tape stops, the tape unit disconnects from the channel. If the tape encounters an End-of-File, the tape control unit sets its EOF indicator. The central processor can test this indicator, which remains set until the tape unit control receives a new EOM/EOD on that channel. The tape always stops after the Tape Mark.

At the end of the file the program reads the EOF character (0001111) into memory along with its check character. In a four-character-per-word "read", this appears in the first word of the input area as a 17170000 word.

When the tape unit is writing on tape, it may transmit flux disturbing surges ahead of the current writing positions; these surges affect previously written records further down the tape. This means that a record in the middle of a file cannot be updated or rewritten if the records that follow it are to be read.

Any errors detected either by the channel in the character parity check or by the control unit with longitudinal parity check sets the error indicator in the channel. When detecting such an error in reading, the routine should backspace the tape over the erroneous record and attempt to reread the record.

The tape unit backspaces over records using the Scan feature. A Scan reverse EOM or EOD starts the tape in reverse. The program then waits for the channel to become ready or waits for the End-of-Transmission (if enabled). When the buffer becomes ready or the End-of-Transmission interrupt occurs, the

tape stops in front of the backwardly traversed record. If the program has enabled the interrupts, the End-of-Word (I1) interrupt occurs prior to the End-of-Transmission interrupt; executing a WIM to a dummy location and clearing the interrupt with a BRU indirect ignore the interrupt.

A Scan operation is similar to a Read operation except that the channel shifts the characters read through its Word Assembly Register, but does not consider a word complete until it encounters a tape gap. When the tape reaches the gap, the channel uses the last four characters in the word assembly as the only word read from the record. When scanning in reverse, the word consists of the last four characters scanned, which are the first four logical characters of the record. This operation assembles these characters in reverse. For example, if the first four characters of the record are 1234 and the tape is scanning the record in reverse, these appear as 4321 in the word stored for that record.

The same operation occurs in the forward scan with the last four characters of the record forming the word stored. The Scan is useful for reverse searching on the first word of the records in the file being searched. In this case, the routine starts the tape in a reverse scan and loads the channel interlace with a terminal function 10 with a word count of 1 and arms the Count Equals Zero interrupt. When the tape reaches the beginning of the record, the channel stores the first word and interrupts the program which checks the key word against a search key. If they agree, then the program need only wait for the channel to become inactive (ready) and the routine reads the record forward. If the record is not the desired one, the program gives another "scan reverse" without waiting for the channel to become inactive, and reloads the channel interlace to scan the next record.

If the tape encounters the End-of-Reel marker while reading, the tape logic sets the End-of-Reel indicator in the tape unit; the program can test this at any time. An End-of-File normally indicates the end of recorded information on tape. It is possible, however, to use the End-of-Reel indicator to mark the last record on the reel.

Writing

Once a tape unit is ready and the file-protect ring is on the tape reel, that is, the file-protect test is false, a Write operation can begin. The write tape EOM starts tape motion; the tape remains in motion until it receives the termination signal from the buffer. The tape control unit then writes the remaining characters of the record and writes the longitudinal check character. When the read-after-write head reads this check character, the tape signals the channel it has reached gap. If the unit receives no further write instruction within one millisecond, the tape stops and disconnects.

If the user wishes to backspace or rewind and then to return at some later time to record additional information at the end of the previous series of records, the routine should write an End-of-File character or erase a segment of tape after the series of written records. This practice provides positive identification of the end of a record and facilitates return to a specific location on the tape. If the programmer does not use this method, the tape may not subsequently stop in the same location at the end of the series of records as it did when writing the last record. This would leave a segment of tape in the gap which has not been written and may cause erroneous operation when reading the tape.

In addition to writing under program control, the program can also erase magnetic tape. When using an erase EOM with an erase unit address, the tape unit operates as though it were in a Write mode, except that it records no information. The program or interlace supplies the count of the number of words to be erased.

This type of erase is useful for the correction of a write error. When a write error occurs, an ERASE TAPE REVERSE (ERT) starts the tape in reverse. The same count, used to write the record originally, controls the erase. This procedure ensures that the tape always returns to the beginning of the erroneous record, even if a bad spot on the tape might appear as a gap. The routine may now rewrite the record. If the Write still produces an error, the routine erases the record backward and then erases it forward, using the same count, and by-passes the section of tape where the difficulty occurred. The routine may now rewrite the record on a new section of tape.

The erase procedure can produce the required 3.75 inches of blank tape between the load point and the first record. This is done by erasing 150 words at 200 bpi density, 417 words at 556 bpi density, or 600 words at 800 bpi density.

Use of a one-character-per-word, BCD, Write instruction writes an End-of-File record. Then the program loads the channel interlace with a count of 1 and loads the address of a word containing the Tape Mark character (17) in the left-most position. EOM or EOD instructions to the tape units specify start-without-leader since the tape unit automatically generates gap at the end of all records for leader. A magnetic tape program should never include a leader instruction because an attempt to generate leader may cause an erroneous operation.

Programming

The SKS and EOM instructions for normal tape operations follow. EOM instructions use four character per word format for units on Channel W.

TRT 0,n TAPE READY TEST 0 40 1041n

TRT 0 tests tape unit number n on Channel W for Not Ready. If the tape is Not Ready, it skips the next instruction in sequence and executes the following instruction. If the tape is Ready, it executes the next instruction in sequence.

A tape is Not Ready if: (1) there is no physical unit set to the logical unit number being tested, (2) the selected unit is not in the Automatic mode, or (3) the tape is in motion for any operation.

FPT 0,n FILE PROTECT TEST 0 40 1401n

Tests tape unit number n on Channel W for file protect. If the file-protect ring is present, the computer skips the next instruction in sequence and executes the following instruction. If not inserted, it executes the next instruction in sequence. The skip does not occur if there is no logical unit n on the channel.

BTT 0,n BEGINNING OF TAPE TEST 0 40 1201n

Tests tape unit number n on Channel W for the beginning of the tape. If not positioned on the load point marker, the computer skips the next instruction in sequence and executes the following instruction. If positioned on the load point marker, it executes the next instruction in sequence. The skip does not occur if there is no logical unit n on the channel.

ETT 0,n, END OF TAPE TEST 0 40 1101n

Tests whether tape unit number n on Channel W is not positioned at the end of the tape. If the tape unit has not sensed the End-of-Reel marker, the computer skips the next instruction in sequence and executes the following instruction. If the End-of-Reel marker has been sensed, it executes the next instruction in sequence. The End-of-Reel condition is reset when the tape unit moves the tape backward over the End-of-Reel marker. The skip does not occur if there is no logical unit n on the channel.

DT2 0,n DENSITY TEST, 200 BPI 0 40 1621n

Tests tape unit number n on Channel W for being set at 200 bpi density. If not, the computer skips the next instruction in sequence and executes the following instruction. If so, it executes the next instruction in sequence.

DT5 0,n DENSITY TEST, 556 BPI 0 40 1661n

Tests tape unit number n on Channel W for being set at 556 bpi density. If not, the computer skips the next instruction in sequence and executes the following instruction. If so, it executes the next instruction in sequence.

DT8 0,n DENSITY TEST, 800 BPI 0 40 1721n

Tests tape unit number n on Channel W for being set at 800 bpi density. If not, the computer skips the next instruction in sequence and executes the following instruction. If so, it executes the next instruction in sequence.

TFT 0 TAPE END-OF-FILE TEST 0 40 13610

Tests whether a tape under control of the tape control unit on Channel W encountered an End-of-File during the last Read or Scan operation. If not, the computer skips the next instruction in sequence and executes the following instruction. If so, it executes the next instruction in sequence.

The End-of-File indicator remains set until the program calls for another tape operation.

TGT 0,n TAPE GAP TEST 0 40 1261n

Tests whether tape unit n on Channel W has encountered gap since it received the last EOM/EOD instruction. If not, the computer will skip the next instruction in sequence and execute the following instruction. If so, it executes the next instruction in sequence. TGT will execute the next instruction during the approximately 0.75 millisecond that the tape-gap indicator is "true".

MAGPAK TEST 0 40 1021n

Tape unit n is tested for being a MAGPAK. If the tape unit is not a MAGPAK, the computer skips the next instruction in sequence and executes the following instruction. If the tape unit is a MAGPAK, the computer executes the next instruction in sequence.

WTB 0,n, 4 WRITE TAPE IN BINARY 0 02 0365n

Starts tape unit n on Channel W in a Binary Write mode.

WTD 0,n, 4 WRITE TAPE IN DECIMAL (BCD) 0 02 0265n

Starts tape unit n on Channel W in a BCD Write mode.

EFT 0,n, 4 ERASE TAPE FORWARD 0 02 0367n

Starts tape unit n on Channel W in an Erase mode.

ERT 0,n, 4 ERASE TAPE IN REVERSE 0 02 0767n

Starts tape unit n on Channel W in reverse in an Erase mode.

RTB 0,n, 4 READ TAPE IN BINARY 0 02 0361n

Starts tape unit n on Channel W in a Binary Read mode.

RTD 0,n, 4 READ TAPE IN DECIMAL (BCD) 0 02 0261n

Starts tape unit n on Channel W in a BCD Read mode.

SFB 0,n, 4 SCAN FORWARD IN BINARY 0 02 0363n

Starts tape unit n on Channel W forward in a Binary Scan mode.

SFD 0,n, 4 SCAN FORWARD IN DECIMAL (BCD) 0 02 0263n

Starts tape unit n on Channel W forward in a BCD Scan mode.

SRB 0,n, 4 SCAN REVERSE IN BINARY 0 02 0763n

Starts tape unit n on Channel W in reverse in a Binary Scan mode.

SRD 0,n, 4 SCAN REVERSE IN DECIMAL (BCD) 0 02 0663n

Starts tape unit n on Channel W in reverse in a BCD Scan mode.

REW 0,n REWIND 0 02 1401n

Starts tape unit n on Channel W in a Rewind. REW does not use the channel.

RTS 0 CONVERT READ TO SCAN 0 02 14000

The tape unit currently in a read mode on the channel is instructed to convert from the read mode of operation to the scan mode of operation.

SRR 0 SKIP REMAINDER OF RECORD[†] 0 02 13610

The tape unit currently on the channel is instructed to skip the remainder of the record being read.

[†]Note: This instruction applies only to 41.7-kc and 96-kc magnetic tape systems.

MAGNETIC TAPE EXAMPLE PROGRAMS

The following examples show samples of complete input/output programs for magnetic tape.

EXAMPLE: Magnetic Tape Read

This program reads one record from Magnetic Tape Number 1 on Channel W. It uses the End-of-Record interrupt. The tape is not at its beginning or end.

<u>Location</u>	<u>Instruction</u>	<u>Address</u>	<u>Comments</u>
1000	PZE		Saves a location for the subroutine entry.
	TRT	0, 1	Tests Ready Magnetic Tape 1 on Channel W. If Magnetic Tape 1 is ready to perform an input/output operation, the computer executes the next instruction in sequence. If not, it skips the next instruction and executes the following one. The octal configuration is 0 40 10411.
	BRU	\$+2	Skips one instruction.
	BRU	\$-2	Branches back to TRT 0, 1. The programmer can place here an exit to a routine that determines reasons for the Non-Ready condition.
	RTD	*0, 1, 4	Addresses Channel W, alerts the interlace, connects it to Magnetic Tape 1, specifies four characters per word and BCD modes, and starts tape motion.
	EXU	REDTP	Executes the EOM located in location REDTP.
	POT	REDTP+1	Transmits to the channel the word count and starting address.
	BRR	1000	Branches back to the main program.
REDTP	EOM 06203720	16000	This EOM specifies terminal input function 00 (IORD) and the End-of-Record interrupt. The word in REDTP+1 specifies that one record or 100 words, whichever is smaller, will be read into memory beginning in location 2000. Any remaining words in the record after the first 100 will be ignored. (0620 is equal to 144 ₈ shifted right one place; it is merged with 03720 to generate the "POTted" word.)
The main program continues while the channel performs the input operation. When finished, the End-of-Record interrupt goes to location 33.			
33	BRM	COMPL	This instruction in interrupt location 33 branches and marks to COMPL to finish the read operation.
COMPL	PZE		Saves a location for the routine entry.
	CET	0	Tests for error in Channel W. If it detects an error, the computer executes the next instruction in sequence. If not, it skips the next one and executes the following instruction. The octal configuration is 0 40 22000.
	BRM	ERTST	Branches to an assumed routine to re-read the block a number of times and, if the error continues, to notify the operator.
	BRU	* COMPL	Returns control to the main program and clears interrupt level 33.

EXAMPLE: Gather-Write Magnetic Tape

The program writes one record on magnetic tape. The gathering of the data written in that record is from three non-contiguous areas of memory. This program is a closed subroutine that uses the Count Equals Zero interrupt; it uses Channel W and Magnetic Tape Number 1 on Channel W with interlace.

A similar program can perform a scatter-read operation. The difference is the exchange of the read instruction (RTD) with the write instruction (WTD) and the deletion of the file-protect testing instruction.

<u>Location</u>	<u>Instruction</u>	<u>Address</u>	<u>Comments</u>
1000	PZE		Saves a location for the subroutine entry.
	CLR		Clears the A and B Registers.
	STA	COUNT	Clears location COUNT for use later as a switch.
	TRT	0, 1	Tests whether Magnetic Tape 1 on Channel W is Ready.
	BRU	\$ + 2	Branches two locations ahead. The computer executes it if the magnetic tape unit is Ready.
	BRU	\$ - 2	Branches back to the Ready test.
	FPT	0, 1	Tests whether the file-protect ring is present on the tape reel. If so, the computer skips the next instruction and executes the following one. The octal configuration is 0 40 14011.
	BRM	OPER	Branches and marks to an assumed routine to call the operator and instruct him to insert file-protect ring on Magnetic Tape 1.
	LDA STA MIN	1000 FAST FAST	These three instructions place the marked subroutine entry location plus one into location FAST.
	WTD	0, 1, 4	Connects Magnetic Tape 1 to Channel W, specifies BCD transfer mode and four characters per word, and starts the tape moving. The octal configuration is 0 02 02651.
	BRU	FAST + 1	Branches around location FAST.
FAST	PZE		Saves a location for entry to the multiple write area of the subroutine.
	LDX	COUNT	Loads the Index Register with the contents of COUNT, which picks up the proper input/output control instructions.
	LDA LDB SKM BRU BRU	OKAY MASK COUNT \$ + 2 * FAST	These five instructions determine when the write operation is complete. When it is, location COUNT contains the number 6 and the active interrupt, level 31, is cleared. Location MASK contains 77777777 ₈ .
	ALC	0	Alerts the interlace in Channel W for subsequent loading.
	EXU	A, 2	Executes the EOM located in address A modified by the Index.
	POT	A + 1, 2	Transmits to the channel the word count and starting address.
	MIN MIN	COUNT COUNT	These instructions add two to the contents of COUNT.
	BRU	* FAST	Branches back to the main program.

The main program continues while the channel performs the output. When finished, the Zero Word Count interrupt goes to interrupt location 31.

<u>Location</u>	<u>Instruction</u>	<u>Address</u>	<u>Comments</u>
31	BRM	FAST	Branches and marks at location FAST.

The routine repeats this for the output words in A + 2 and in A + 4. Then the test in location FAST + 4 causes a final Branch to clear interrupt (BRU) back to the main program.

<u>Location</u>	<u>Instruction</u>	<u>Address</u>	<u>Comments</u>
A	EOM 06203720	15600	This EOM specifies terminal output function 11 (IOSP) and the Count Equals Zero interrupt. The word in A + 1 specifies that 100 words will be read out from memory beginning in location 2000.
A + 2	EOM 14404740	15600	This EOM specifies terminal output function 11 (IOSP) and the Count Equals Zero interrupt. The word in A + 3 specifies 200 words from memory beginning in location 2500.
A + 4	EOM 06205670	15000	The EOM specifies terminal output function 00 (IORD) and the Count Equals Zero interrupt. The word in A + 5 specifies 100 words from memory beginning in location 3000. Upon completion of the output of this sub-record, the channel disconnects.
OKAY	00000006		This is the stored number 6 used in the completion test above.

NOTE: This sample program is for clarification of magnetic tape programming. It does not include extra programming to save the contents of the A or the Index Register for the main program.

LINE PRINTER

SDS buffered line printers are capable of printing up to 1000 lines per minute at 132 characters per line, with a standard set of 56 characters. Printing is accomplished by means of a rotating character drum and a bank of 132 print hammers. The drum passes 56 different characters, in lines of 132 each, past the hammer bank. Upon command from the computer, the selected print hammers drive the paper against the ribbon and onto the appropriate character typeface as it passes the print position. The characters are transmitted sequentially for storage in the printer buffer before printing. A programmable format tape loop provides fixed (or preselected) space control. Upspacing of 1 to 7 lines, as well as page control, may be accomplished by program instructions.

An optional, off-line facility allows the program or the operator to initiate card-to-printer or magnetic tape-to-printer operations simultaneous with computation (see Off-Line Printing).

Printer Controls

The printer controls, Figure 4-5, for SDS line printers consist of eight switches and indicators.




Figure 4-5. Printer Control Indicator Lights and Switches

The POWER/ON switch is an alternate action switch. The computer must be turned on for this switch to be activated. Pressing POWER/ON lights the top half of the indicator, turns on the motors and hammer driver power supply, and starts a timer that allows the motors to reach proper speed. After 20 seconds the bottom half lights, indicating that the printer is operable.

When the printer is initially turned on, the READY indicator is off. When pressed, it is turned on if:

1. paper is loaded in the line printer,
2. the lower half of the POWER/ON switch is lighted, and
3. the hammer power supply is on.

This indicator automatically goes off when the above conditions are not realized. The printer is ready for either on-line or off-line operation when READY is turned on. Ready is reset to preclude computer intervention while changing paper or ribbon, or operating the TOP OF FORM or SINGLE SPACE switches.

Pressing TOP OF FORM causes the printer to position paper according to format tape channel 1. This indicator is lighted only when the format tape is positioned at channel 1, that is, top-of-form on a standard tape loop. This switch is operative when there is paper in the printer and the READY indicator is off.

Pressing SINGLE SPACE causes the printer to upspace paper one single space, independently of the vertical format tape. This switch is operative when there is paper in the machine and READY is off.

The FAULT indicator lights when the printer detects a parity error as information transfer from the buffer to the print hammers, or when it detects a parity error in incoming data from magnetic tape or cards during an off-line operation. It remains lighted until the next EOM addresses the printer. The condition of the light corresponds to the status of a program-testable fault indicator in the printer.

MANUAL/OFF LINE[†] is a combination of a switch and two independent indicators. The program or the operator may initiate off-line operation, which is indicated by the illumination of OFF LINE (the bottom half of this switch). If the operator presses this switch to initiate off-line operation, MANUAL (the top half of the switch) is also lighted and remains lighted until the operator presses the switch again. OFF LINE is normally reset when the end-of-file is detected from the input unit. Pressing READY also resets OFF LINE, that is, by switching the printer from the "ready" to the "not ready" state.

The FORMAT/SPACE[†] switch is used in off-line operation. The operator may use either mode, spacing a single space after each line of print, or using the first character stored on tape or cards as a vertical format character.

The TAPE/CARD[†] switch selects the desired input device.

Paper Tape Format Loop

A paper tape format loop, placed in the printer, allows upspacing to proceed to prespecified vertical positions on the print page. The format loop is an eight-channel paper tape. Putting a punch in the specified channel at the desired vertical spacing selects the channel upspace. Channel 1 is the top-of-form channel, channel 7 is the bottom-of-form channel, and channel 0 is the single-upspace channel. In the off-line mode with SPACE control, channel 0 controls single spacing. When printing with no format loop inserted in the printer, single upspacing occurs regardless of the channel specified.

[†]If an off-line coupler is not attached to the printer, the MANUAL/OFF LINE, FORMAT/SPACE, and TAPE/CARD indicators neither light nor affect printer operation.

Line Printer Instructions

PLP 0,1,4 PRINT LINE PRINTER 0 02 02660

This instruction connects the line printer to channel W and specifies a character transmission of 4 characters per word.

This instruction is followed by the transmission of up to 132 characters. If the character count is less than 132, the characters are printed left-justified on the page. If the character count is more than 132, the printer produces an undetectable error.

The following control instructions are coded for Channel W using unit number 1:

POL 0,1 PRINTER OFF-LINE 0 02 10260

This instruction places the printer off-line and initiates an off-line print operation. The selected input device (card reader 1 or magnetic tape unit 7) also goes off-line (See Off-Line Printing).

PSC 0,1,n	PRINTER SKIP TO FORMAT CHANNEL n	0 02 1n460
-----------	-------------------------------------	------------

This instruction causes the printer to eject paper until the paper tape format loop detects the first punched hole in the channel specified by the number *n* (0 to 7). (See PSP for timing.)

PSP 0,1,n PRINTER UPSPACE n LINES 0 02 1n660

This instruction causes the printer to upspace n (0 to 7) lines. Consecutive upspace instructions must be separated by a sufficient time delay. Otherwise, the two PSP instructions may be merged by the printer.

Approximate completion times for PSP (from initiation of instruction to paper stop) are:

Upspace 1 line: 25 milliseconds (14,275 cycles)

Upspace more than 1 line: add 10 milliseconds (5,690 cycles) for each additional line.

Line Printer Tests

The line printer tests to follow are coded for channel W using unit number 1:

PFT 0,1	PRINTER FAULT TEST (Skip if no Printer Fault)	0 40 11060
---------	--	------------

This test determines if the printer has detected a parity error during a transfer of information from the printer buffer to the print hammers. If such an error occurs, a fault detector is set and the FAULT indicator is lighted. If the fault detector is set when PFT is executed, the computer executes the next instruction in sequence (does not skip). If the fault detector is not set, the computer skips the next instruction in sequence and executes the following instruction.

PRT 0,1	PRINTER READY TEST (Skip if Printer Ready)	0 40 12060
---------	---	------------

This instruction tests the printer for a "ready" condition. The criteria for a printer "ready" condition are:

1. Paper is loaded in the machine,
2. The lower half of the POWER/ON switch is lighted, and
3. The hammer power supply is on.

If the printer is ready when PRT is executed, the computer skips the next instruction in sequence and executes the following instruction. If the printer is not ready, the computer executes the next instruction in sequence (does not skip). Since the printer tests ready while ejecting paper, the program should allow a definite time interval to pass (see PSP) after a PSC or PSP instruction before executing a new PSC or PSP. A dummy PLP instruction may be issued between two space instructions (PSC or PSP). This instruction will provide the timing required. A ready test may be used to determine when the second paper space instruction may be sent.

EPT 0, 1 END OF PAGE TEST 0 40 14060
(Skip if not End of Page)

This instruction tests the printer for paper position. If the paper is positioned at the end of page (specified by format channel 7) the computer executes the next instruction in sequence (does not skip). If the paper is not positioned at the specified end of page, the computer skips the next instruction in sequence and executes the following instruction.

Terminating Line Printer Output

When the single-word mode of transmission is used for printing on the line printer, each character transmission for a line must be followed by a TERMINATE OUTPUT (TOP) instruction. TOP is automatically generated with interlaced outputs.

Error Conditions

1. Print fault - parity error during transfer of character information from print buffer to print hammers.
2. Buffer error - parity of character rate error during transfer of information through buffer.
3. Input fault - parity error in incoming data from cards or magnetic tape (during off-line operation only).

Off-Line Printing

The optional, off-line facility allows the line printer to produce printed records from card or magnetic tape sources without computer attention. The character transmission proceeds directly from the source to the printer and the channel may still be used by the computer for other input/output operations (e.g., card reading on card reader 2, card punch, paper tape read/punch, disk read/write, etc.). Once initiated, the printing operation is controlled by the source and proceeds until the source generates an end-of-file signal (see card input and magnetic tape input for appropriate end-of-file conditions).

The **FAULT** indicator lights when a parity error is detected during the reading of a tape record; the off-line printer rereads the record in an attempt to read good data. If this reread record contains an error, **FAULT** lights, the off-line operation terminates, and the printer goes back on-line if physically connected

EXAMPLE: Print Two Lines

This program positions the paper at the top of the page and prints two lines with a single upspace between them. It assumes that the printer is ready to print or is becoming ready after a print operation. This program, written as a closed subroutine, uses channel W, Line Printer 1, and the Count Equals Zero and End-of-Record interrupts.

Location	Instruction	Address	Comments
1200	PZE		Reserves a location for subroutine entry.
	CLR		Clears the A and B Registers.
	STA	SWICH	Initializes a location, SWICH, which indicates that printing is completed.
	PRT	0, 1	Tests for printer ready. The octal configuration for this instruction is 0 40 12060.
	BRU	\$-1	Returns control to the ready test; if the printer is not ready, the computer executes this instruction.
	PSC	0, 1, 1	Instructs the printer to move paper to the top of the page. The octal configuration for this instruction is 0 02 11460.
	PLP	*0, 1, 4	Connects Printer 1 to Channel W, and specifies four characters per word transfer mode, and alerts the interlace. The octal configuration for this instruction is 0 02 42660.
	EXU	PRINT	Executes the EOM located in location PRINT.
	POT	PRINT + 1	Transmits the word count and starting address.
	BRR	1200	Branches back to the main program while the line is being printed.
PRINT	EOM 02043720	16200	This EOM specifies output function 01 and the End-of-Record interrupt. The word in PRINT + 1 specifies that 33 words will be output from memory beginning in location 2000.

The main program continues while the data transfer and printing is being completed. When completed, the End-of-Record interrupt goes to interrupt level 33. This indicates that all the data from memory has been obtained, and that the printing of the line has been completed.

33	BRM	UPSPC	Branches and marks to location UPSPC elsewhere in memory.
UPSPC	PZE		Reserves a location for an entry.
	PRT	0, 1	Tests for printer ready condition. Since the current line has been printed, the printer will be ready.
	BRU	*-1	Returns to the test.
	PSP	0, 1, 1	Causes the printer to upspace one line. The octal configuration is 0 02 11660.
HEAR	PLP	*0, 1, 4	Sets up the printer with interlace.
	EXU	PRNT	Executes the EOM in location PRNT.
	POT	PRNT + 1	Transmits to the channel the word count and starting address.
	BRU	*UPSPC	Branches and clears the interrupt to the main program to await completion of the data transfer.
31	BRM	DONE	Branches and marks to location DONE elsewhere in memory.
DONE	PZE		This pseudo operation reserves a location for an entry.
	MIN	SWICH	Sets the printing complete flag.
	BRU	*DONE	Branches back to the main program and clears interrupt 31. This is the final exit.
PRNT	EOM 02043761	15000	This EOM specifies terminal output function 00(IORD) and the Count Equals Zero interrupt. The word in PRNT + 1 specifies that 33 words will be read out from memory beginning in location 2033. The channel disconnects at the end of the output.

At location HEAR, note that the computer executes the instructions to print and control the printing before the printing has had time to completely upspace the paper as requested. The instructions cause an immediate transfer of data into the Print Buffer and printing begins immediately after completion of upspacing.

to the computer and the MANUAL indicator is off. When a validity check occurs during a card read, FAULT lights, the operation terminates, and the printer goes back on-line if the MANUAL indicator is off. The next EOM addressing the printer resets FAULT if the printer is on-line. If the MANUAL indicator is on, the error condition may be cleared by pressing READY off and then on again. If a fault occurs in an off-line operation initiated by the computer, the usual method for clearing the error is:

1. Press MANUAL on.
2. Press READY off.
3. Press READY on.
4. Press MANUAL off.

In a manually initiated off-line operation, steps 1 and 4 are not required.

Off-line printing can be formatted as desired through the use of a single upspace or the format control mode (see Table 4-2). Off-line printing terminates by an end-of-file indicator from either device. Upon termination of an off-line operation, a physically connected off-line printer system returns on-line, provided the MANUAL indicator is off.

Table 4-2. Format Control Characters

Code	Character	Function
00	0	Skip to format channel 0
01	1	Skip to format channel 1
02	2	Skip to format channel 2
03	3	Skip to format channel 3
04	4	Skip to format channel 4
05	5	Skip to format channel 5
06	6	Skip to format channel 6
07	7	Skip to format channel 7
40	- (hyphen)	Do not space
41	J	Upspace 1 line
42	K	Upspace 2 lines
43	L	Upspace 3 lines
44	M	Upspace 4 lines
45	N	Upspace 5 lines
46	O	Upspace 6 lines
47	P	Upspace 7 lines

Printing Off-Line Under Operator Control

The procedure for operator control of off-line printing is:

1. Switch on the desired input device. (Magnetic tape is selected by dialing it to logical tape number 7.)
2. Place paper at top of form, as desired, by means of the TOP OF FORM switch.
3. Select desired input device by means of the TAPE/CARD switch.
4. Select either the FORMAT or SPACE mode as required.
5. Press MANUAL/OFF LINE switch.
6. Press READY switch on, which initiates actual data transfer.

Printing Off-Line Under Computer Control

The procedure for computer control of off-line printing is:

1. Turn the equipment on.
2. Prepare the desired input device for operation.
3. Select desired input device by means of the TAPE/CARD switch.
4. Select either the FORMAT or SPACE mode as required.
5. Press the READY switch on.
6. Under program control, test the tape or card unit and the line printer for "ready" condition.
7. Then, to start transfer of data, give the POL instruction to print off-line.

Off-Line Print Termination

Off-line printing terminates when an end-of-file indicator from the magnetic tape unit or card reader occurs. When printing from magnetic tape, the print operation terminates when the first character read from a record is the end-of-file code, octal 17.

When printing from cards, the print operation terminates when the end-of-file signal comes from the reader. This occurs when the card hopper becomes empty and the EOF ON switch on the reader is on (END OF FILE indicator lights). If the hopper becomes empty when EOF ON is not lighted, the printer waits for more cards to be placed in the hopper and the reader to become ready. When the reader is again ready, printing resumes.

Characters		SDS Internal Code	Card Code	Magnetic Tape BCD Code on Tape	Characters		SDS Internal Code	Card Code	Magnetic Tape BCD Code on Tape
Typewriter	Printer				Typewriter	Printer			
Ø	0	00	0	12	-	-	40	11	40
1	1	01	1	01	J	J	41	11-1	41
2	2	02	2	02	K	K	42	11-2	42
3	3	03	3	03	L	L	43	11-3	43
4	4	04	4	04	M	M	44	11-4	44
5	5	05	5	05	N	N	45	11-5	45
6	6	06	6	06	O	O	46	11-6	46
7	7	07	7	07	P	P	47	11-7	47
8	8	10	8	10	Q	Q	50	11-8	50
9	9	11	9	11	R	R	51	11-9	51
Space	Blank	12	8-2	12 ⁽³⁾	Car. Ret. ! ⁽¹⁾	! ⁽⁵⁾	52	11-0 ⁽⁴⁾	52
# or =	=	13	8-3	13	\$	\$	53	11-8-3	53
@ or '	'	14	8-4	14	*	*	54	11-8-4	54
:	:	15	8-5	15]]	55	11-8-5	55
>	>	16	8-6	16	;	;	56	11-8-6	56
✓	✓	17	8-7	17	Δ	Δ	57	11-8-7	57
& or +	+	20	12	60	Blank	Blank	60	Blank	20
A	A	21	12-1	61	/	/	61	0-1	21
B	B	22	12-2	62	S	S	62	0-2	22
C	C	23	12-3	63	T	T	63	0-3	23
D	D	24	12-4	64	U	U	64	0-4	24
E	E	25	12-5	65	V	V	65	0-5	25
F	F	26	12-6	66	W	W	66	0-6	26
G	G	27	12-7	67	X	X	67	0-7	27
H	H	30	12-8	70	Y	Y	70	0-8	30
I	I	31	12-9	71	Z	Z	71	0-9	31
Backspace ? ⁽¹⁾	? ⁽⁵⁾	32	12-0 ⁽⁴⁾	72	Tab # ⁽¹⁾	# ⁽⁵⁾	72	0-8-2	32
.	.	33	12-8-3	73	,	,	73	0-8-3	33
Π or))	34	12-8-4	74	% or ((⁽⁵⁾	74	0-8-4	34
[[35	12-8-5	75	~	~ ⁽⁵⁾	75	0-8-5	35
<	<	36	12-8-6	76	\	\ ⁽⁵⁾	76	0-8-6	36
* Stop	* ⁽⁵⁾	37 ⁽²⁾	12-8-7	77	* Delete	* ⁽⁵⁾	77 ⁽²⁾	0-8-7	37

NOTES:

- (1) The characters ? ! and # are for input only. The functions Backspace, Carriage Return, or Tab always occur on output.
- (2) On the off-line paper tape preparation unit, 37 serves as a stop code and 77 as a code delete.
- (3) The internal code 12 is written on tape as a 12 in BCD. When read, this code is always converted to 00.
- (4) The codes 12-0 and 11-0 are generated by the card punch; however, the card reader will also accept 12-8-2 for 32 and 11-8-2 for 52 to maintain compatibility with earlier systems.
- (5) For the 64-character printers only.

TABLE OF POWERS OF TWO

2^n	n	2^{-n}
1	0	1.0
2	1	0.5
4	2	0.25
8	3	0.125
16	4	0.062 5
32	5	0.031 25
64	6	0.015 625
128	7	0.007 812 5
256	8	0.003 906 25
512	9	0.001 953 125
1 024	10	0.000 976 562 5
2 048	11	0.000 488 281 25
4 096	12	0.000 244 140 625
8 192	13	0.000 122 070 312 5
16 384	14	0.000 061 035 156 25
32 768	15	0.000 030 517 578 125
65 536	16	0.000 015 258 789 062 5
131 072	17	0.000 007 629 394 531 25
262 144	18	0.000 003 814 697 265 625
524 288	19	0.000 001 907 348 632 812 5
1 048 576	20	0.000 000 953 674 316 406 25
2 097 152	21	0.000 000 476 837 158 203 125
4 194 304	22	0.000 000 238 418 579 101 562 5
8 388 608	23	0.000 000 119 209 289 550 781 25
16 777 216	24	0.000 000 059 604 644 775 390 625
33 554 432	25	0.000 000 029 802 322 387 695 312 5
67 108 864	26	0.000 000 014 901 161 193 847 656 25
134 217 728	27	0.000 000 007 450 580 596 923 828 125
268 435 456	28	0.000 000 003 725 290 298 461 914 062 5
536 870 912	29	0.000 000 001 862 645 149 230 957 031 25
1 073 741 824	30	0.000 000 000 931 322 574 615 478 515 625
2 147 483 648	31	0.000 000 000 465 661 287 307 739 257 812 5
4 294 967 296	32	0.000 000 000 232 830 643 653 869 628 906 25
8 589 934 592	33	0.000 000 000 116 415 321 826 934 814 453 125
17 179 869 184	34	0.000 000 000 058 207 660 913 467 407 226 562 5
34 359 738 368	35	0.000 000 000 029 103 830 456 733 703 613 281 25
68 719 476 736	36	0.000 000 000 014 551 915 228 366 851 806 640 625
137 438 953 472	37	0.000 000 000 007 275 957 614 183 425 903 320 312 5
274 877 906 944	38	0.000 000 000 003 637 978 807 091 712 951 660 156 25
549 755 813 888	39	0.000 000 000 001 818 989 403 545 856 475 830 078 125
1 099 511 627 776	40	0.000 000 000 000 909 494 701 772 928 237 915 039 062 5
2 199 023 255 552	41	0.000 000 000 000 454 747 350 886 464 118 957 519 531 25
4 398 046 511 104	42	0.000 000 000 000 227 373 675 443 232 059 478 759 765 625
8 796 093 022 208	43	0.000 000 000 000 113 686 837 721 616 029 739 379 882 812 5
17 592 186 044 416	44	0.000 000 000 000 056 843 418 860 808 014 869 689 941 406 25
35 184 372 088 832	45	0.000 000 000 000 028 421 709 430 404 007 434 844 970 703 125
70 368 744 177 664	46	0.000 000 000 000 014 210 854 715 202 003 717 422 485 351 562 5
140 737 488 355 328	47	0.000 000 000 000 007 105 427 357 601 001 858 711 242 675 781 25
281 474 976 710 656	48	0.000 000 000 000 003 552 713 678 800 500 929 355 621 337 890 625

OCTAL-DECIMAL INTEGER CONVERSION TABLE

0000 0000
to to
0777 0511
(Octal) (Decimal)

Octal Decimal
10000 - 4096
20000 - 8192
30000 - 12288
40000 - 16384
50000 - 20480
60000 - 24576
70000 - 28672

	0	1	2	3	4	5	6	7
0000	0000	0001	0002	0003	0004	0005	0006	0007
0010	0008	0009	0010	0011	0012	0013	0014	0015
0020	0016	0017	0018	0019	0020	0021	0022	0023
0030	0024	0025	0026	0027	0028	0029	0030	0031
0040	0032	0033	0034	0035	0036	0037	0038	0039
0050	0040	0041	0042	0043	0044	0045	0046	0047
0060	0048	0049	0050	0051	0052	0053	0054	0055
0070	0056	0057	0058	0059	0060	0061	0062	0063
0100	0064	0065	0066	0067	0068	0069	0070	0071
0110	0072	0073	0074	0075	0076	0077	0078	0079
0120	0080	0081	0082	0083	0084	0085	0086	0087
0130	0088	0089	0090	0091	0092	0093	0094	0095
0140	0096	0097	0098	0099	0100	0101	0102	0103
0150	0104	0105	0106	0107	0108	0109	0110	0111
0160	0112	0113	0114	0115	0116	0117	0118	0119
0170	0120	0121	0122	0123	0124	0125	0126	0127
0200	0128	0129	0130	0131	0132	0133	0134	0135
0210	0136	0137	0138	0139	0140	0141	0142	0143
0220	0144	0145	0146	0147	0148	0149	0150	0151
0230	0152	0153	0154	0155	0156	0157	0158	0159
0240	0160	0161	0162	0163	0164	0165	0166	0167
0250	0168	0169	0170	0171	0172	0173	0174	0175
0260	0176	0177	0178	0179	0180	0181	0182	0183
0270	0184	0185	0186	0187	0188	0189	0190	0191
0300	0192	0193	0194	0195	0196	0197	0198	0199
0310	0200	0201	0202	0203	0204	0205	0206	0207
0320	0208	0209	0210	0211	0212	0213	0214	0215
0330	0216	0217	0218	0219	0220	0221	0222	0223
0340	0224	0225	0226	0227	0228	0229	0230	0231
0350	0232	0233	0234	0235	0236	0237	0238	0239
0360	0240	0241	0242	0243	0244	0245	0246	0247
0370	0248	0249	0250	0251	0252	0253	0254	0255

	0	1	2	3	4	5	6	7
0400	0256	0257	0258	0259	0260	0261	0262	0263
0410	0264	0265	0266	0267	0268	0269	0270	0271
0420	0272	0273	0274	0275	0276	0277	0278	0279
0430	0280	0281	0282	0283	0284	0285	0286	0287
0440	0288	0289	0290	0291	0292	0293	0294	0295
0450	0296	0297	0298	0299	0300	0301	0302	0303
0460	0304	0305	0306	0307	0308	0309	0310	0311
0470	0312	0313	0314	0315	0316	0317	0318	0319
0500	0320	0321	0322	0323	0324	0325	0326	0327
0510	0328	0329	0330	0331	0332	0333	0334	0335
0520	0336	0337	0338	0339	0340	0341	0342	0343
0530	0344	0345	0346	0347	0348	0349	0350	0351
0540	0352	0353	0354	0355	0356	0357	0358	0359
0550	0360	0361	0362	0363	0364	0365	0366	0367
0560	0368	0369	0370	0371	0372	0373	0374	0375
0570	0376	0377	0378	0379	0380	0381	0382	0383
0600	0384	0385	0386	0387	0388	0389	0390	0391
0610	0392	0393	0394	0395	0396	0397	0398	0399
0620	0400	0401	0402	0403	0404	0405	0406	0407
0630	0408	0409	0410	0411	0412	0413	0414	0415
0640	0416	0417	0418	0419	0420	0421	0422	0423
0650	0424	0425	0426	0427	0428	0429	0430	0431
0660	0432	0433	0434	0435	0436	0437	0438	0439
0670	0440	0441	0442	0443	0444	0445	0446	0447
0700	0448	0449	0450	0451	0452	0453	0454	0455
0710	0456	0457	0458	0459	0460	0461	0462	0463
0720	0464	0465	0466	0467	0468	0469	0470	0471
0730	0472	0473	0474	0475	0476	0477	0478	0479
0740	0480	0481	0482	0483	0484	0485	0486	0487
0750	0488	0489	0490	0491	0492	0493	0494	0495
0760	0496	0497	0498	0499	0500	0501	0502	0503
0770	0504	0505	0506	0507	0508	0509	0510	0511

1000 0512
to to
1777 1023
(Octal) (Decimal)

	0	1	2	3	4	5	6	7
1000	0512	0513	0514	0515	0516	0517	0518	0519
1010	0520	0521	0522	0523	0524	0525	0526	0527
1020	0528	0529	0530	0531	0532	0533	0534	0535
1030	0536	0537	0538	0539	0540	0541	0542	0543
1040	0544	0545	0546	0547	0548	0549	0550	0551
1050	0552	0553	0554	0555	0556	0557	0558	0559
1060	0560	0561	0562	0563	0564	0565	0566	0567
1070	0568	0569	0570	0571	0572	0573	0574	0575
1100	0576	0577	0578	0579	0580	0581	0582	0583
1110	0584	0585	0586	0587	0588	0589	0590	0591
1120	0592	0593	0594	0595	0596	0597	0598	0599
1130	0600	0601	0602	0603	0604	0605	0606	0607
1140	0608	0609	0610	0611	0612	0613	0614	0615
1150	0616	0617	0618	0619	0620	0621	0622	0623
1160	0624	0625	0626	0627	0628	0629	0630	0631
1170	0632	0633	0634	0635	0636	0637	0638	0639
1200	0640	0641	0642	0643	0644	0645	0646	0647
1210	0648	0649	0650	0651	0652	0653	0654	0655
1220	0656	0657	0658	0659	0660	0661	0662	0663
1230	0664	0665	0666	0667	0668	0669	0670	0671
1240	0672	0673	0674	0675	0676	0677	0678	0679
1250	0680	0681	0682	0683	0684	0685	0686	0687
1260	0688	0689	0690	0691	0692	0693	0694	0695
1270	0696	0697	0698	0699	0700	0701	0702	0703
1300	0704	0705	0706	0707	0708	0709	0710	0711
1310	0712	0713	0714	0715	0716	0717	0718	0719
1320	0720	0721	0722	0723	0724	0725	0726	0727
1330	0728	0729	0730	0731	0732	0733	0734	0735
1340	0736	0737	0738	0739	0740	0741	0742	0743
1350	0744	0745	0746	0747	0748	0749	0750	0751
1360	0752	0753	0754	0755	0756	0757	0758	0759
1370	0760	0761	0762	0763	0764	0765	0766	0767

	0	1	2	3	4	5	6	7
1400	0768	0769	0770	0771	0772	0773	0774	0775
1410	0776	0777	0778	0779	0780	0781	0782	0783
1420	0784	0785	0786	0787	0788	0789	0790	0791
1430	0792	0793	0794	0795	0796	0797	0798	0799
1440	0800	0801	0802	0803	0804	0805	0806	0807
1450	0808	0809	0810	0811	0812	0813	0814	0815
1460	0816	0817	0818	0819	0820	0821	0822	0823
1470	0824	0825	0826	0827	0828	0829	0830	0831
1500	0832	0833	0834	0835	0836	0837	0838	0839
1510	0840	0841	0842	0843	0844	0845	0846	0847
1520	0848	0849	0850	0851	0852	0853	0854	0855
1530	0856	0857	0858	0859	0860	0861	0862	0863
1540	0864	0865	0866	0867	0868	0869	0870	0871
1550	0872	0873	0874	0875	0876	0877	0878	0879
1560	0880	0881	0882	0883	0884	0885	0886	0887
1570	0888	0889	0890	0891	0892	0893	0894	0895
1600	0896	0897	0898	0899	0900	0901	0902	0903
1610	0904	0905	0906	0907	0908	0909	0910	0911
1620	0912	0913	0914	0915	0916	0917	0918	0919
1630	0920	0921	0922	0923	0924	0925	0926	0927
1640	0928	0929	0930	0931	0932	0933	0934	0935
1650	0936	0937	0938	0939	0940	0941	0942	0943
1660	0944	0945	0946	0947	0948	0949	0950	0951
1670	0952	0953	0954	0955	0956	0957	0958	0959
1700	0960	0961	0962	0963	0964	0965	0966	0967
1710	0968	0969	0970	0971	0972	0973	0974	0975
1720	0976	0977	0978	0979	0980	0981	0982	0983
1730	0984	0985	0986	0987	0988	0989	0990	0991
1740	0992	0993	0994	0995	0996	0997	0998	0999
1750	1000	1001	1002	1003	1004	1005	1006	1007
1760	1008	1009	1010	1011	1012	1013	1014	1015
1770	1016	1017	1018	1019	1020	1021	1022	1023

Octal-Decimal Integer Conversion Table

	0	1	2	3	4	5	6	7
2000	1024	1025	1026	1027	1028	1029	1030	1031
2010	1032	1033	1034	1035	1036	1037	1038	1039
2020	1040	1041	1042	1043	1044	1045	1046	1047
2030	1048	1049	1050	1051	1052	1053	1054	1055
2040	1056	1057	1058	1059	1060	1061	1062	1063
2050	1064	1065	1066	1067	1068	1069	1070	1071
2060	1072	1073	1074	1075	1076	1077	1078	1079
2070	1080	1081	1082	1083	1084	1085	1086	1087
2100	1088	1089	1090	1091	1092	1093	1094	1095
2110	1096	1097	1098	1099	1100	1101	1102	1103
2120	1104	1105	1106	1107	1108	1109	1110	1111
2130	1112	1113	1114	1115	1116	1117	1118	1119
2140	1120	1121	1122	1123	1124	1125	1126	1127
2150	1128	1129	1130	1131	1132	1133	1134	1135
2160	1136	1137	1138	1139	1140	1141	1142	1143
2170	1144	1145	1146	1147	1148	1149	1150	1151
2200	1152	1153	1154	1155	1156	1157	1158	1159
2210	1160	1161	1162	1163	1164	1165	1166	1167
2220	1168	1169	1170	1171	1172	1173	1174	1175
2230	1176	1177	1178	1179	1180	1181	1182	1183
2240	1184	1185	1186	1187	1188	1189	1190	1191
2250	1192	1193	1194	1195	1196	1197	1198	1199
2260	1200	1201	1202	1203	1204	1205	1206	1207
2270	1208	1209	1210	1211	1212	1213	1214	1215
2300	1216	1217	1218	1219	1220	1221	1222	1223
2310	1224	1225	1226	1227	1228	1229	1230	1231
2320	1232	1233	1234	1235	1236	1237	1238	1239
2330	1240	1241	1242	1243	1244	1245	1246	1247
2340	1248	1249	1250	1251	1252	1253	1254	1255
2350	1256	1257	1258	1259	1260	1261	1262	1263
2360	1264	1265	1266	1267	1268	1269	1270	1271
2370	1272	1273	1274	1275	1276	1277	1278	1279

	0	1	2	3	4	5	6	7
3000	1536	1537	1538	1539	1540	1541	1542	1543
3010	1544	1545	1546	1547	1548	1549	1550	1551
3020	1552	1553	1554	1555	1556	1557	1558	1559
3030	1560	1561	1562	1563	1564	1565	1566	1567
3040	1568	1569	1570	1571	1572	1573	1574	1575
3050	1576	1577	1578	1579	1580	1581	1582	1583
3060	1584	1585	1586	1587	1588	1589	1590	1591
3070	1592	1593	1594	1595	1596	1597	1598	1599
3100	1600	1601	1602	1603	1604	1605	1606	1607
3110	1608	1609	1610	1611	1612	1613	1614	1615
3120	1616	1617	1618	1619	1620	1621	1622	1623
3130	1624	1625	1626	1627	1628	1629	1630	1631
3140	1632	1633	1634	1635	1636	1637	1638	1639
3150	1640	1641	1642	1643	1644	1645	1646	1647
3160	1648	1649	1650	1651	1652	1653	1654	1655
3170	1656	1657	1658	1659	1660	1661	1662	1663
3200	1664	1665	1666	1667	1668	1669	1670	1671
3210	1672	1673	1674	1675	1676	1677	1678	1679
3220	1680	1681	1682	1683	1684	1685	1686	1687
3230	1688	1689	1690	1691	1692	1693	1694	1695
3240	1696	1697	1698	1699	1700	1701	1702	1703
3250	1704	1705	1706	1707	1708	1709	1710	1711
3260	1712	1713	1714	1715	1716	1717	1718	1719
3270	1720	1721	1722	1723	1724	1725	1726	1727
3300	1728	1729	1730	1731	1732	1733	1734	1735
3310	1736	1737	1738	1739	1740	1741	1742	1743
3320	1744	1745	1746	1747	1748	1749	1750	1751
3330	1752	1753	1754	1755	1756	1757	1758	1759
3340	1760	1761	1762	1763	1764	1765	1766	1767
3350	1768	1769	1770	1771	1772	1773	1774	1775
3360	1776	1777	1778	1779	1780	1781	1782	1783
3370	1784	1785	1786	1787	1788	1789	1790	1791

	0	1	2	3	4	5	6	7
2400	1280	1281	1282	1283	1284	1285	1286	1287
2410	1288	1289	1290	1291	1292	1293	1294	1295
2420	1296	1297	1298	1299	1300	1301	1302	1303
2430	1304	1305	1306	1307	1308	1309	1310	1311
2440	1312	1313	1314	1315	1316	1317	1318	1319
2450	1320	1321	1322	1323	1324	1325	1326	1327
2460	1328	1329	1330	1331	1332	1333	1334	1335
2470	1336	1337	1338	1339	1340	1341	1342	1343
2500	1344	1345	1346	1347	1348	1349	1350	1351
2510	1352	1353	1354	1355	1356	1357	1358	1359
2520	1360	1361	1362	1363	1364	1365	1366	1367
2530	1368	1369	1370	1371	1372	1373	1374	1375
2540	1376	1377	1378	1379	1380	1381	1382	1383
2550	1384	1385	1386	1387	1388	1389	1390	1391
2560	1392	1393	1394	1395	1396	1397	1398	1399
2570	1400	1401	1402	1403	1404	1405	1406	1407
2600	1408	1409	1410	1411	1412	1413	1414	1415
2610	1416	1417	1418	1419	1420	1421	1422	1423
2620	1424	1425	1426	1427	1428	1429	1430	1431
2630	1432	1433	1434	1435	1436	1437	1438	1439
2640	1440	1441	1442	1443	1444	1445	1446	1447
2650	1448	1449	1450	1451	1452	1453	1454	1455
2660	1456	1457	1458	1459	1460	1461	1462	1463
2670	1464	1465	1466	1467	1468	1469	1470	1471
2700	1472	1473	1474	1475	1476	1477	1478	1479
2710	1480	1481	1482	1483	1484	1485	1486	1487
2720	1488	1489	1490	1491	1492	1493	1494	1495
2730	1496	1497	1498	1499	1500	1501	1502	1503
2740	1504	1505	1506	1507	1508	1509	1510	1511
2750	1512	1513	1514	1515	1516	1517	1518	1519
2760	1520	1521	1522	1523	1524	1525	1526	1527
2770	1528	1529	1530	1531	1532	1533	1534	1535

	0	1	2	3	4	5	6	7
3400	1792	1793	1794	1795	1796	1797	1798	1799
3410	1800	1801	1802	1803	1804	1805	1806	1807
3420	1808	1809	1810	1811	1812	1813	1814	1815
3430	1816	1817	1818	1819	1820	1821	1822	1823
3440	1824	1825	1826	1827	1828	1829	1830	1831
3450	1832	1833	1834	1835	1836	1837	1838	1839
3460	1840	1841	1842	1843	1844	1845	1846	1847
3470	1848	1849	1850	1851	1852	1853	1854	1855
3500	1856	1857	1858	1859	1860	1861	1862	1863
3510	1864	1865	1866	1867	1868	1869	1870	1871
3520	1872	1873	1874	1875	1876	1877	1878	1879
3530	1880	1881	1882	1883	1884	1885	1886	1887
3540	1888	1889	1890	1891	1892	1893	1894	1895
3550	1896	1897	1898	1899	1900	1901	1902	1903
3560	1904	1905	1906	1907	1908	1909	1910	1911
3570	1912	1913	1914	1915	1916	1917	1918	1919
3600	1920	1921	1922	1923	1924	1925	1926	1927
3610	1928	1929	1930	1931	1932	1933	1934	1935
3620	1936	1937	1938	1939	1940	1941	1942	1943
3630	1944	1945	1946	1947	1948	1949	1950	1951
3640	1952	1953	1954	1955	1956	1957	1958	1959
3650	1960	1961	1962	1963	1964	1965	1966	1967
3660	1968	1969	1970	1971	1972	1973	1974	1975
3670	1976	1977	1978	1979	1980	1981	1982	1983
3700	1984	1985	1986	1987	1988	1989	1990	1991
3710	1992	1993	1994	1995	1996	1997	1998	1999
3720	2000	2001	2002	2003	2004	2005	2006	2007
3730	2008	2009	2010	2011	2012	2013	2014	2015
3740	2016	2017	2018	2019	2020	2021	2022	2023
3750	2024	2025	2026	2027	2028	2029	2030	2031
3760	2032	2033	2034	2035	2036	2037	2038	2039
3770	2040	2041	2042	2043	2044	2045	2046	2047

2000 1024
to to
2777 1535
(Octal) (Decimal)

Octal Decimal
10000 - 4096
20000 - 8192
30000 - 12288
40000 - 16384
50000 - 20480
60000 - 24576
70000 - 28672

3000 1536
to to
3777 2047
(Octal) (Decimal)

Octal-Decimal Integer Conversion Table

4000 2048
to
4777 2559
(Octal) (Decimal)

Octal Decimal
10000 - 4096
20000 - 8192
30000 - 12288
40000 - 16384
50000 - 20480
60000 - 24576
70000 - 28672

	0	1	2	3	4	5	6	7
4000	2048	2049	2050	2051	2052	2053	2054	2055
4010	2056	2057	2058	2059	2060	2061	2062	2063
4020	2064	2065	2066	2067	2068	2069	2070	2071
4030	2072	2073	2074	2075	2076	2077	2078	2079
4040	2080	2081	2082	2083	2084	2085	2086	2087
4050	2088	2089	2090	2091	2092	2093	2094	2095
4060	2096	2097	2098	2099	2100	2101	2102	2103
4070	2104	2105	2106	2107	2108	2109	2110	2111
4100	2112	2113	2114	2115	2116	2117	2118	2119
4110	2120	2121	2122	2123	2124	2125	2126	2127
4120	2128	2129	2130	2131	2132	2133	2134	2135
4130	2136	2137	2138	2139	2140	2141	2142	2143
4140	2144	2145	2146	2147	2148	2149	2150	2151
4150	2152	2153	2154	2155	2156	2157	2158	2159
4160	2160	2161	2162	2163	2164	2165	2166	2167
4170	2168	2169	2170	2171	2172	2173	2174	2175
4200	2176	2177	2178	2179	2180	2181	2182	2183
4210	2184	2185	2186	2187	2188	2189	2190	2191
4220	2192	2193	2194	2195	2196	2197	2198	2199
4230	2200	2201	2202	2203	2204	2205	2206	2207
4240	2208	2209	2210	2211	2212	2213	2214	2215
4250	2216	2217	2218	2219	2220	2221	2222	2223
4260	2224	2225	2226	2227	2228	2229	2230	2231
4270	2232	2233	2234	2235	2236	2237	2238	2239
4300	2240	2241	2242	2243	2244	2245	2246	2247
4310	2248	2249	2250	2251	2252	2253	2254	2255
4320	2256	2257	2258	2259	2260	2261	2262	2263
4330	2264	2265	2266	2267	2268	2269	2270	2271
4340	2272	2273	2274	2275	2276	2277	2278	2279
4350	2280	2281	2282	2283	2284	2285	2286	2287
4360	2288	2289	2290	2291	2292	2293	2294	2295
4370	2296	2297	2298	2299	2300	2301	2302	2303

	0	1	2	3	4	5	6	7
4400	2304	2305	2306	2307	2308	2309	2310	2311
4410	2312	2313	2314	2315	2316	2317	2318	2319
4420	2320	2321	2322	2323	2324	2325	2326	2327
4430	2328	2329	2330	2331	2332	2333	2334	2335
4440	2336	2337	2338	2339	2340	2341	2342	2343
4450	2344	2345	2346	2347	2348	2349	2350	2351
4460	2352	2353	2354	2355	2356	2357	2358	2359
4470	2360	2361	2362	2363	2364	2365	2366	2367
4500	2368	2369	2370	2371	2372	2373	2374	2375
4510	2376	2377	2378	2379	2380	2381	2382	2383
4520	2384	2385	2386	2387	2388	2389	2390	2391
4530	2392	2393	2394	2395	2396	2397	2398	2399
4540	2400	2401	2402	2403	2404	2405	2406	2407
4550	2408	2409	2410	2411	2412	2413	2414	2415
4560	2416	2417	2418	2419	2420	2421	2422	2423
4570	2424	2425	2426	2427	2428	2429	2430	2431
4600	2432	2433	2434	2435	2436	2437	2438	2439
4610	2440	2441	2442	2443	2444	2445	2446	2447
4620	2448	2449	2450	2451	2452	2453	2454	2455
4630	2456	2457	2458	2459	2460	2461	2462	2463
4640	2464	2465	2466	2467	2468	2469	2470	2471
4650	2472	2473	2474	2475	2476	2477	2478	2479
4660	2480	2481	2482	2483	2484	2485	2486	2487
4670	2488	2489	2490	2491	2492	2493	2494	2495
4700	2496	2497	2498	2499	2500	2501	2502	2503
4710	2504	2505	2506	2507	2508	2509	2510	2511
4720	2512	2513	2514	2515	2516	2517	2518	2519
4730	2520	2521	2522	2523	2524	2525	2526	2527
4740	2528	2529	2530	2531	2532	2533	2534	2535
4750	2536	2537	2538	2539	2540	2541	2542	2543
4760	2544	2545	2546	2547	2548	2549	2550	2551
4770	2552	2553	2554	2555	2556	2557	2558	2559

5000 2560
to
5777 3071
(Octal) (Decimal)

	0	1	2	3	4	5	6	7
5000	2560	2561	2562	2563	2564	2565	2566	2567
5010	2568	2569	2570	2571	2572	2573	2574	2575
5020	2576	2577	2578	2579	2580	2581	2582	2583
5030	2584	2585	2586	2587	2588	2589	2590	2591
5040	2592	2593	2594	2595	2596	2597	2598	2599
5050	2600	2601	2602	2603	2604	2605	2606	2607
5060	2608	2609	2610	2611	2612	2613	2614	2615
5070	2616	2617	2618	2619	2620	2621	2622	2623
5100	2624	2625	2626	2627	2628	2629	2630	2631
5110	2632	2633	2634	2635	2636	2637	2638	2639
5120	2640	2641	2642	2643	2644	2645	2646	2647
5130	2648	2649	2650	2651	2652	2653	2654	2655
5140	2656	2657	2658	2659	2660	2661	2662	2663
5150	2664	2665	2666	2667	2668	2669	2670	2671
5160	2672	2673	2674	2675	2676	2677	2678	2679
5170	2680	2681	2682	2683	2684	2685	2686	2687
5200	2688	2689	2690	2691	2692	2693	2694	2695
5210	2696	2697	2698	2699	2700	2701	2702	2703
5220	2704	2705	2706	2707	2708	2709	2710	2711
5230	2712	2713	2714	2715	2716	2717	2718	2719
5240	2720	2721	2722	2723	2724	2725	2726	2727
5250	2728	2729	2730	2731	2732	2733	2734	2735
5260	2736	2737	2738	2739	2740	2741	2742	2743
5270	2744	2745	2746	2747	2748	2749	2750	2751
5300	2752	2753	2754	2755	2756	2757	2758	2759
5310	2760	2761	2762	2763	2764	2765	2766	2767
5320	2768	2769	2770	2771	2772	2773	2774	2775
5330	2776	2777	2778	2779	2780	2781	2782	2783
5340	2784	2785	2786	2787	2788	2789	2790	2791
5350	2792	2793	2794	2795	2796	2797	2798	2799
5360	2800	2801	2802	2803	2804	2805	2806	2807
5370	2808	2809	2810	2811	2812	2813	2814	2815

	0	1	2	3	4	5	6	7
5400	2816	2817	2818	2819	2820	2821	2822	2823
5410	2824	2825	2826	2827	2828	2829	2830	2831
5420	2832	2833	2834	2835	2836	2837	2838	2839
5430	2840	2841	2842	2843	2844	2845	2846	2847
5440	2848	2849	2850	2851	2852	2853	2854	2855
5450	2856	2857	2858	2859	2860	2861	2862	2863
5460	2864	2865	2866	2867	2868	2869	2870	2871
5470	2872	2873	2874	2875	2876	2877	2878	2879
5500	2880	2881	2882	2883	2884	2885	2886	2887
5510	2888	2889	2890	2891	2892	2893	2894	2895
5520	2896	2897	2898	2899	2900	2901	2902	2903
5530	2904	2905	2906	2907	2908	2909	2910	2911
5540	2912	2913	2914	2915	2916	2917	2918	2919
5550	2920	2921	2922	2923	2924	2925	2926	2927
5560	2928	2929	2930	2931	2932	2933	2934	2935
5570	2936	2937	2938	2939	2940	2941	2942	2943
5600	2944	2945	2946	2947	2948	2949	2950	2951
5610	2952	2953	2954	2955	2956	2957	2958	2959
5620	2960	2961	2962	2963	2964	2965	2966	2967
5630	2968	2969	2970	2971	2972	2973	2974	2975
5640	2976	2977	2978	2979	2980	2981	2982	2983
5650	2984	2985	2986	2987	2988	2989	2990	2991
5660	2992	2993	2994	2995	2996	2997	2998	2999
5670	3000	3001	3002	3003	3004	3005	3006	3007
5700	3008	3009	3010	3011	3012	3013	3014	3015
5710	3016	3017	3018	3019	3020	3021	3022	3023
5720	3024	3025	3026	3027	3028	3029	3030	3031
5730	3032	3033	3034	3035	3036	3037	3038	3039
5740	3040	3041	3042	3043	3044	3045	3046	3047
5750	3048	3049	3050	3051	3052	3053	3054	3055
5760	3056	3057	3058	3059	3060	3061	3062	3063
5770	3064	3065	3066	3067	3068	3069	3070	3071

Octal-Decimal Integer Conversion Table

	0	1	2	3	4	5	6	7
6000	3072	3073	3074	3075	3076	3077	3078	3079
6010	3080	3081	3082	3083	3084	3085	3086	3087
6020	3088	3089	3090	3091	3092	3093	3094	3095
6030	3096	3097	3098	3099	3100	3101	3102	3103
6040	3104	3105	3106	3107	3108	3109	3110	3111
6050	3112	3113	3114	3115	3116	3117	3118	3119
6060	3120	3121	3122	3123	3124	3125	3126	3127
6070	3128	3129	3130	3131	3132	3133	3134	3135
6100	3136	3137	3138	3139	3140	3141	3142	3143
6110	3144	3145	3146	3147	3148	3149	3150	3151
6120	3152	3153	3154	3155	3156	3157	3158	3159
6130	3160	3161	3162	3163	3164	3165	3166	3167
6140	3168	3169	3170	3171	3172	3173	3174	3175
6150	3176	3177	3178	3179	3180	3181	3182	3183
6160	3184	3185	3186	3187	3188	3189	3190	3191
6170	3192	3193	3194	3195	3196	3197	3198	3199
6200	3200	3201	3202	3203	3204	3205	3206	3207
6210	3208	3209	3210	3211	3212	3213	3214	3215
6220	3216	3217	3218	3219	3220	3221	3222	3223
6230	3224	3225	3226	3227	3228	3229	3230	3231
6240	3232	3233	3234	3235	3236	3237	3238	3239
6250	3240	3241	3242	3243	3244	3245	3246	3247
6260	3248	3249	3250	3251	3252	3253	3254	3255
6270	3256	3257	3258	3259	3260	3261	3262	3263
6300	3264	3265	3266	3267	3268	3269	3270	3271
6310	3272	3273	3274	3275	3276	3277	3278	3279
6320	3280	3281	3282	3283	3284	3285	3286	3287
6330	3288	3289	3290	3291	3292	3293	3294	3295
6340	3296	3297	3298	3299	3300	3301	3302	3303
6350	3304	3305	3306	3307	3308	3309	3310	3311
6360	3312	3313	3314	3315	3316	3317	3318	3319
6370	3320	3321	3322	3323	3324	3325	3326	3327

	0	1	2	3	4	5	6	7
7000	3584	3585	3586	3587	3588	3589	3590	3591
7010	3592	3593	3594	3595	3596	3597	3598	3599
7020	3600	3601	3602	3603	3604	3605	3606	3607
7030	3608	3609	3610	3611	3612	3613	3614	3615
7040	3616	3617	3618	3619	3620	3621	3622	3623
7050	3624	3625	3626	3627	3628	3629	3630	3631
7060	3632	3633	3634	3635	3636	3637	3638	3639
7070	3640	3641	3642	3643	3644	3645	3646	3647
7100	3648	3649	3650	3651	3652	3653	3654	3655
7110	3656	3657	3658	3659	3660	3661	3662	3663
7120	3664	3665	3666	3667	3668	3669	3670	3671
7130	3672	3673	3674	3675	3676	3677	3678	3679
7140	3680	3681	3682	3683	3684	3685	3686	3687
7150	3688	3689	3690	3691	3692	3693	3694	3695
7160	3696	3697	3698	3699	3700	3701	3702	3703
7170	3704	3705	3706	3707	3708	3709	3710	3711
7200	3712	3713	3714	3715	3716	3717	3718	3719
7210	3720	3721	3722	3723	3724	3725	3726	3727
7220	3728	3729	3730	3731	3732	3733	3734	3735
7230	3736	3737	3738	3739	3740	3741	3742	3743
7240	3744	3745	3746	3747	3748	3749	3750	3751
7250	3752	3753	3754	3755	3756	3757	3758	3759
7260	3760	3761	3762	3763	3764	3765	3766	3767
7270	3768	3769	3770	3771	3772	3773	3774	3775
7300	3776	3777	3778	3779	3780	3781	3782	3783
7310	3784	3785	3786	3787	3788	3789	3790	3791
7320	3792	3793	3794	3795	3796	3797	3798	3799
7330	3800	3801	3802	3803	3804	3805	3806	3807
7340	3808	3809	3810	3811	3812	3813	3814	3815
7350	3816	3817	3818	3819	3820	3821	3822	3823
7360	3824	3825	3826	3827	3828	3829	3830	3831
7370	3832	3833	3834	3835	3836	3837	3838	3839

	0	1	2	3	4	5	6	7
6400	3328	3329	3330	3331	3332	3333	3334	3335
6410	3336	3337	3338	3339	3340	3341	3342	3343
6420	3344	3345	3346	3347	3348	3349	3350	3351
6430	3352	3353	3354	3355	3356	3357	3358	3359
6440	3360	3361	3362	3363	3364	3365	3366	3367
6450	3368	3369	3370	3371	3372	3373	3374	3375
6460	3376	3377	3378	3379	3380	3381	3382	3383
6470	3384	3385	3386	3387	3388	3389	3390	3391
6500	3392	3393	3394	3395	3396	3397	3398	3399
6510	3400	3401	3402	3403	3404	3405	3406	3407
6520	3408	3409	3410	3411	3412	3413	3414	3415
6530	3416	3417	3418	3419	3420	3421	3422	3423
6540	3424	3425	3426	3427	3428	3429	3430	3431
6550	3432	3433	3434	3435	3436	3437	3438	3439
6560	3440	3441	3442	3443	3444	3445	3446	3447
6570	3448	3449	3450	3451	3452	3453	3454	3455
6600	3456	3457	3458	3459	3460	3461	3462	3463
6610	3464	3465	3466	3467	3468	3469	3470	3471
6620	3472	3473	3474	3475	3476	3477	3478	3479
6630	3480	3481	3482	3483	3484	3485	3486	3487
6640	3488	3489	3490	3491	3492	3493	3494	3495
6650	3496	3497	3498	3499	3500	3501	3502	3503
6660	3504	3505	3506	3507	3508	3509	3510	3511
6670	3512	3513	3514	3515	3516	3517	3518	3519
6700	3520	3521	3522	3523	3524	3525	3526	3527
6710	3528	3529	3530	3531	3532	3533	3534	3535
6720	3536	3537	3538	3539	3540	3541	3542	3543
6730	3544	3545	3546	3547	3548	3549	3550	3551
6740	3552	3553	3554	3555	3556	3557	3558	3559
6750	3560	3561	3562	3563	3564	3565	3566	3567
6760	3568	3569	3570	3571	3572	3573	3574	3575
6770	3576	3577	3578	3579	3580	3581	3582	3583

	0	1	2	3	4	5	6	7
7400	3840	3841	3842	3843	3844	3845	3846	3847
7410	3848	3849	3850	3851	3852	3853	3854	3855
7420	3856	3857	3858	3859	3860	3861	3862	3863
7430	3864	3865	3866	3867	3868	3869	3870	3871
7440	3872	3873	3874	3875	3876	3877	3878	3879
7450	3880	3881	3882	3883	3884	3885	3886	3887
7460	3888	3889	3890	3891	3892	3893	3894	3895
7470	3896	3897	3898	3899	3900	3901	3902	3903
7500	3904	3905	3906	3907	3908	3909	3910	3911
7510	3912	3913	3914	3915	3916	3917	3918	3919
7520	3920	3921	3922	3923	3924	3925	3926	3927
7530	3928	3929	3930	3931	3932	3933	3934	3935
7540	3936	3937	3938	3939	3940	3941	3942	3943
7550	3944	3945	3946	3947	3948	3949	3950	3951
7560	3952	3953	3954	3955	3956	3957	3958	3959
7570	3960	3961	3962	3963	3964	3965	3966	3967
7600	3968	3969	3970	3971	3972	3973	3974	3975
7610	3976	3977	3978	3979	3980	3981	3982	3983
7620	3984	3985	3986	3987	3988	3989	3990	3991
7630	3992	3993	3994	3995	3996	3997	3998	3999
7640	4000	4001	4002	4003	4004	4005	4006	4007
7650	4008	4009	4010	4011	4012	4013	4014	4015
7660	4016	4017	4018	4019	4020	4021	4022	4023
7670	4024	4025	4026	4027	4028	4029	4030	4031
7700	4032	4033	4034	4035	4036	4037	4038	4039
7710	4040	4041	4042	4043	4044	4045	4046	4047
7720	4048	4049	4050	4051	4052	4053	4054	4055
7730	4056	4057	4058	4059	4060	4061	4062	4063
7740	4064	4065	4066	4067	4068	4069	4070	4071
7750	4072	4073	4074	4075	4076	4077	4078	4079
7760	4080	4081	4082	4083	4084	4085	4086	4087
7770	4088	4089	4090	4091	4092	4093	4094	4095

6000 3072
to to
6777 3583
(Octal) (Decimal)

Octal Decimal
10000 - 4096
20000 - 8192
30000 - 12288
40000 - 16384
50000 - 20480
60000 - 24576
70000 - 28672

7000 3584
to to
7777 4095
(Octal) (Decimal)

OCTAL-DECIMAL FRACTION CONVERSION TABLE

OCTAL	DEC.	OCTAL	DEC.	OCTAL	DEC.	OCTAL	DEC.
.000	.000000	.100	.125000	.200	.250000	.300	.375000
.001	.001953	.101	.126953	.201	.251953	.301	.376953
.002	.003906	.102	.128906	.202	.253906	.302	.378906
.003	.005859	.103	.130859	.203	.255859	.303	.380859
.004	.007812	.104	.132812	.204	.257812	.304	.382812
.005	.009765	.105	.134765	.205	.259765	.305	.384765
.006	.011718	.106	.136718	.206	.261718	.306	.386718
.007	.013671	.107	.138671	.207	.263671	.307	.388671
.010	.015625	.110	.140625	.210	.265625	.310	.390625
.011	.017578	.111	.142578	.211	.267578	.311	.392578
.012	.019531	.112	.144531	.212	.269531	.312	.394531
.013	.021484	.113	.146484	.213	.271484	.313	.396484
.014	.023437	.114	.148437	.214	.273437	.314	.398437
.015	.025390	.115	.150390	.215	.275390	.315	.400390
.016	.027343	.116	.152343	.216	.277343	.316	.402343
.017	.029296	.117	.154296	.217	.279296	.317	.404296
.020	.031250	.120	.156250	.220	.281250	.320	.406250
.021	.033203	.121	.158203	.221	.283203	.321	.408203
.022	.035156	.122	.160156	.222	.285156	.322	.410156
.023	.037109	.123	.162109	.223	.287109	.323	.412109
.024	.039062	.124	.164062	.224	.289062	.324	.414062
.025	.041015	.125	.166015	.225	.291015	.325	.416015
.026	.042968	.126	.167968	.226	.292968	.326	.417968
.027	.044921	.127	.169921	.227	.294921	.327	.419921
.030	.046875	.130	.171875	.230	.296875	.330	.421875
.031	.048828	.131	.173828	.231	.298828	.331	.423828
.032	.050781	.132	.175781	.232	.300781	.332	.425781
.033	.052734	.133	.177734	.233	.302734	.333	.427734
.034	.054687	.134	.179687	.234	.304687	.334	.429687
.035	.056640	.135	.181640	.235	.306640	.335	.431640
.036	.058593	.136	.183593	.236	.308593	.336	.433593
.037	.060546	.137	.185546	.237	.310546	.337	.435546
.040	.062500	.140	.187500	.240	.312500	.340	.437500
.041	.064453	.141	.189453	.241	.314453	.341	.439453
.042	.066406	.142	.191406	.242	.316406	.342	.441406
.043	.068359	.143	.193359	.243	.318359	.343	.443359
.044	.070312	.144	.195312	.244	.320312	.344	.445312
.045	.072265	.145	.197265	.245	.322265	.345	.447265
.046	.074218	.146	.199218	.246	.324218	.346	.449218
.047	.076171	.147	.201171	.247	.326171	.347	.451171
.050	.078125	.150	.203125	.250	.328125	.350	.453125
.051	.080078	.151	.205078	.251	.330078	.351	.455078
.052	.082031	.152	.207031	.252	.332031	.352	.457031
.053	.083984	.153	.208984	.253	.333984	.353	.458984
.054	.085937	.154	.210937	.254	.335937	.354	.460937
.055	.087890	.155	.212890	.255	.337890	.355	.462890
.056	.089843	.156	.214843	.256	.339843	.356	.464843
.057	.091796	.157	.216796	.257	.341796	.357	.466796
.060	.093750	.160	.218750	.260	.343750	.360	.468750
.061	.095703	.161	.220703	.261	.345703	.361	.470703
.062	.097656	.162	.222656	.262	.347656	.362	.472656
.063	.099609	.163	.224609	.263	.349609	.363	.474609
.064	.101562	.164	.226562	.264	.351562	.364	.476562
.065	.103515	.165	.228515	.265	.353515	.365	.478515
.066	.105468	.166	.230468	.266	.355468	.366	.480468
.067	.107421	.167	.232421	.267	.357421	.367	.482421
.070	.109375	.170	.234375	.270	.359375	.370	.484375
.071	.111328	.171	.236328	.271	.361328	.371	.486328
.072	.113281	.172	.238281	.272	.363281	.372	.488281
.073	.115234	.173	.240234	.273	.365234	.373	.490234
.074	.117187	.174	.242187	.274	.367187	.374	.492187
.075	.119140	.175	.244140	.275	.369140	.375	.494140
.076	.121093	.176	.246093	.276	.371093	.376	.496093
.077	.123046	.177	.248046	.277	.373046	.377	.498046

Octal-Decimal Fraction Conversion Table

OCTAL	DEC.	OCTAL	DEC.	OCTAL	DEC.	OCTAL	DEC.
.000000	.000000	.000100	.000244	.000200	.000488	.000300	.000732
.000001	.000003	.000101	.000247	.000201	.000492	.000301	.000736
.000002	.000007	.000102	.000251	.000202	.000495	.000302	.000740
.000003	.000011	.000103	.000255	.000203	.000499	.000303	.000743
.000004	.000015	.000104	.000259	.000204	.000503	.000304	.000747
.000005	.000019	.000105	.000263	.000205	.000507	.000305	.000751
.000006	.000022	.000106	.000267	.000206	.000511	.000306	.000755
.000007	.000026	.000107	.000270	.000207	.000514	.000307	.000759
.000010	.000030	.000110	.000274	.000210	.000518	.000310	.000762
.000011	.000034	.000111	.000278	.000211	.000522	.000311	.000766
.000012	.000038	.000112	.000282	.000212	.000526	.000312	.000770
.000013	.000041	.000113	.000286	.000213	.000530	.000313	.000774
.000014	.000045	.000114	.000289	.000214	.000534	.000314	.000778
.000015	.000049	.000115	.000293	.000215	.000537	.000315	.000782
.000016	.000053	.000116	.000297	.000216	.000541	.000316	.000785
.000017	.000057	.000117	.000301	.000217	.000545	.000317	.000789
.000020	.000061	.000120	.000305	.000220	.000549	.000320	.000793
.000021	.000064	.000121	.000308	.000221	.000553	.000321	.000797
.000022	.000068	.000122	.000312	.000222	.000556	.000322	.000801
.000023	.000072	.000123	.000316	.000223	.000560	.000323	.000805
.000024	.000076	.000124	.000320	.000224	.000564	.000324	.000808
.000025	.000080	.000125	.000324	.000225	.000568	.000325	.000812
.000026	.000083	.000126	.000328	.000226	.000572	.000326	.000816
.000027	.000087	.000127	.000331	.000227	.000576	.000327	.000820
.000030	.000091	.000130	.000335	.000230	.000579	.000330	.000823
.000031	.000095	.000131	.000339	.000231	.000583	.000331	.000827
.000032	.000099	.000132	.000343	.000232	.000587	.000332	.000831
.000033	.000102	.000133	.000347	.000233	.000591	.000333	.000835
.000034	.000106	.000134	.000350	.000234	.000595	.000334	.000839
.000035	.000110	.000135	.000354	.000235	.000598	.000335	.000843
.000036	.000114	.000136	.000358	.000236	.000602	.000336	.000846
.000037	.000118	.000137	.000362	.000237	.000606	.000337	.000850
.000040	.000122	.000140	.000366	.000240	.000610	.000340	.000854
.000041	.000125	.000141	.000370	.000241	.000614	.000341	.000858
.000042	.000129	.000142	.000373	.000242	.000617	.000342	.000862
.000043	.000133	.000143	.000377	.000243	.000621	.000343	.000865
.000044	.000137	.000144	.000381	.000244	.000625	.000344	.000869
.000045	.000141	.000145	.000385	.000245	.000629	.000345	.000873
.000046	.000144	.000146	.000389	.000246	.000633	.000346	.000877
.000047	.000148	.000147	.000392	.000247	.000637	.000347	.000881
.000050	.000152	.000150	.000396	.000250	.000640	.000350	.000885
.000051	.000156	.000151	.000400	.000251	.000644	.000351	.000888
.000052	.000160	.000152	.000404	.000252	.000648	.000352	.000892
.000053	.000164	.000153	.000408	.000253	.000652	.000353	.000896
.000054	.000167	.000154	.000411	.000254	.000656	.000354	.000900
.000055	.000171	.000155	.000415	.000255	.000659	.000355	.000904
.000056	.000175	.000156	.000419	.000256	.000663	.000356	.000907
.000057	.000179	.000157	.000423	.000257	.000667	.000357	.000911
.000060	.000183	.000160	.000427	.000260	.000671	.000360	.000915
.000061	.000186	.000161	.000431	.000261	.000675	.000361	.000919
.000062	.000190	.000162	.000434	.000262	.000679	.000362	.000923
.000063	.000194	.000163	.000438	.000263	.000682	.000363	.000926
.000064	.000198	.000164	.000442	.000264	.000686	.000364	.000930
.000065	.000202	.000165	.000446	.000265	.000690	.000365	.000934
.000066	.000205	.000166	.000450	.000266	.000694	.000366	.000938
.000067	.000209	.000167	.000453	.000267	.000698	.000367	.000942
.000070	.000213	.000170	.000457	.000270	.000701	.000370	.000946
.000071	.000217	.000171	.000461	.000271	.000705	.000371	.000949
.000072	.000221	.000172	.000465	.000272	.000709	.000372	.000953
.000073	.000225	.000173	.000469	.000273	.000713	.000373	.000957
.000074	.000228	.000174	.000473	.000274	.000717	.000374	.000961
.000075	.000232	.000175	.000476	.000275	.000720	.000375	.000965
.000076	.000236	.000176	.000480	.000276	.000724	.000376	.000968
.000077	.000240	.000177	.000484	.000277	.000728	.000377	.000972

Octal-Decimal Fraction Conversion Table

OCTAL	DEC.	OCTAL	DEC.	OCTAL	DEC.	OCTAL	DEC.
.000400	.000976	.000500	.001220	.000600	.001464	.000700	.001708
.000401	.000980	.000501	.001224	.000601	.001468	.000701	.001712
.000402	.000984	.000502	.001228	.000602	.001472	.000702	.001716
.000403	.000988	.000503	.001232	.000603	.001476	.000703	.001720
.000404	.000991	.000504	.001235	.000604	.001480	.000704	.001724
.000405	.000995	.000505	.001239	.000605	.001483	.000705	.001728
.000406	.000999	.000506	.001243	.000606	.001487	.000706	.001731
.000407	.001003	.000507	.001247	.000607	.001491	.000707	.001735
.000410	.001007	.000510	.001251	.000610	.001495	.000710	.001739
.000411	.001010	.000511	.001255	.000611	.001499	.000711	.001743
.000412	.001014	.000512	.001258	.000612	.001502	.000712	.001747
.000413	.001018	.000513	.001262	.000613	.001506	.000713	.001750
.000414	.001022	.000514	.001266	.000614	.001510	.000714	.001754
.000415	.001026	.000515	.001270	.000615	.001514	.000715	.001758
.000416	.001029	.000516	.001274	.000616	.001518	.000716	.001762
.000417	.001033	.000517	.001277	.000617	.001522	.000717	.001766
.000420	.001037	.000520	.001281	.000620	.001525	.000720	.001770
.000421	.001041	.000521	.001285	.000621	.001529	.000721	.001773
.000422	.001045	.000522	.001289	.000622	.001533	.000722	.001777
.000423	.001049	.000523	.001293	.000623	.001537	.000723	.001781
.000424	.001052	.000524	.001296	.000624	.001541	.000724	.001785
.000425	.001056	.000525	.001300	.000625	.001544	.000725	.001789
.000426	.001060	.000526	.001304	.000626	.001548	.000726	.001792
.000427	.001064	.000527	.001308	.000627	.001552	.000727	.001796
.000430	.001068	.000530	.001312	.000630	.001556	.000730	.001800
.000431	.001071	.000531	.001316	.000631	.001560	.000731	.001804
.000432	.001075	.000532	.001319	.000632	.001564	.000732	.001808
.000433	.001079	.000533	.001323	.000633	.001567	.000733	.001811
.000434	.001083	.000534	.001327	.000634	.001571	.000734	.001815
.000435	.001087	.000535	.001331	.000635	.001575	.000735	.001819
.000436	.001091	.000536	.001335	.000636	.001579	.000736	.001823
.000437	.001094	.000537	.001338	.000637	.001583	.000737	.001827
.000440	.001098	.000540	.001342	.000640	.001586	.000740	.001831
.000441	.001102	.000541	.001346	.000641	.001590	.000741	.001834
.000442	.001106	.000542	.001350	.000642	.001594	.000742	.001838
.000443	.001110	.000543	.001354	.000643	.001598	.000743	.001842
.000444	.001113	.000544	.001358	.000644	.001602	.000744	.001846
.000445	.001117	.000545	.001361	.000645	.001605	.000745	.001850
.000446	.001121	.000546	.001365	.000646	.001609	.000746	.001853
.000447	.001125	.000547	.001369	.000647	.001613	.000747	.001857
.000450	.001129	.000550	.001373	.000650	.001617	.000750	.001861
.000451	.001132	.000551	.001377	.000651	.001621	.000751	.001865
.000452	.001136	.000552	.001380	.000652	.001625	.000752	.001869
.000453	.001140	.000553	.001384	.000653	.001628	.000753	.001873
.000454	.001144	.000554	.001388	.000654	.001632	.000754	.001876
.000455	.001148	.000555	.001392	.000655	.001636	.000755	.001880
.000456	.001152	.000556	.001396	.000656	.001640	.000756	.001884
.000457	.001155	.000557	.001399	.000657	.001644	.000757	.001888
.000460	.001159	.000560	.001403	.000660	.001647	.000760	.001892
.000461	.001163	.000561	.001407	.000661	.001651	.000761	.001895
.000462	.001167	.000562	.001411	.000662	.001655	.000762	.001899
.000463	.001171	.000563	.001415	.000663	.001659	.000763	.001903
.000464	.001174	.000564	.001419	.000664	.001663	.000764	.001907
.000465	.001178	.000565	.001422	.000665	.001667	.000765	.001911
.000466	.001182	.000566	.001426	.000666	.001670	.000766	.001914
.000467	.001186	.000567	.001430	.000667	.001674	.000767	.001918
.000470	.001190	.000570	.001434	.000670	.001678	.000770	.001922
.000471	.001194	.000571	.001438	.000671	.001682	.000771	.001926
.000472	.001197	.000572	.001441	.000672	.001686	.000772	.001930
.000473	.001201	.000573	.001445	.000673	.001689	.000773	.001934
.000474	.001205	.000574	.001449	.000674	.001693	.000774	.001937
.000475	.001209	.000575	.001453	.000675	.001697	.000775	.001941
.000476	.001213	.000576	.001457	.000676	.001701	.000776	.001945
.000477	.001216	.000577	.001461	.000677	.001705	.000777	.001949

TWO'S COMPLEMENT ARITHMETIC

SDS computer systems hold negative numbers in memory in binary two's complement form. The two's complement of a binary number is formed by adding one to the one's complement (logical inverse) of the number. This convention allows the sign of a number to be used as an integral part of the number in all arithmetic operations and obviates the need for keeping track of a detached sign with computer logic.

In SDS systems, the sign bit is in the first bit position to the left of the most significant magnitude bit. Thus, if an SDS computer word was only 6 bits long instead of 24, some common decimal values would be represented in binary format as follows:

Decimal Number	Octal Equivalent	Complement Plus 1	Binary Equivalent
3	03	-	000 011
2	02	-	000 010
1	01	-	000 001
0	00	-	000 000
-1	(-)01	77	111 111
-2	(-)02	76	111 110
-3	(-)03	75	111 101
31	37	-	011 111
-31	(-)37	41	100 001

This table suggests the following algorithms:

1. To find the binary, two's complement of a negative decimal number:
 - a. Find the octal equivalent of the absolute of the number
 - b. Form the complement and add one
 - c. Express as a binary number.

The result is the binary, two's complement equivalent.

2. To find the decimal equivalent of a binary two's complement number:

- a. Express as an octal number
- b. Subtract one and form the complement
- c. Find the decimal equivalent.

The negative of the result is the decimal equivalent.

The following examples show how two's complement numbers automatically yield the correct result when used arithmetically in the computer.

Decimal Number	Binary Equivalent
+ 20	010 100
- 03	+ 111 101
+17	1010 011 = $21_8 = 17_{10}$
	← lost carry

Note that the carry out of the most significant (sign bit) position is lost. Nevertheless, the value remaining is the correct answer.

Decimal Number	Binary Equivalent
- 32	100 000
+ 24	011 000
-8	111 000 = $(-)10_8 = -8_{10}$

When performing additions or subtractions in the computer, carries out of the sign bit do not always signify a true overflow condition or cause the OVERFLOW indicator to be set. In an addition, it is impossible to produce an overflow if the signs of the operands are unlike. The computer sets the OVERFLOW indicator in an addition only when the signs of the two operands are the same, but the sign of the result is opposite. In a subtraction, which in the computer is accomplished by forming the two's complement of the subtrahend and then adding to the minuend, the test for overflow is similar to that for addition. That is, overflow occurs when both numbers have the same sign after the subtrahend has been complemented but the sign of the result is opposite.

DATA MULTIPLEXING SYSTEM

The standard I/O systems provided with the SDS 930 Computer provide for operation with all standard SDS peripheral equipments and for high-performance special devices. The Data Multiplexing System provides an alternate I/O system that is of particular use in dealing with multiple source of data and for systems which may have very high data rates (see Figure A-1).

The SDS 930 Computer has essentially two major paths along which I/O data can flow to and from memory. The first path is the same that is used by the main frame itself. The PIN/POT operations use the first path. All Time-Multiplexed Communication Channels also use this path. In addition to this path, which is primarily under the control of the main frame, there is an optional second path that is completely under the control of the units attached to it. The second path has priority over the first for access to memory. This path is made available with the installation of the Multiple Access to Memory Feature.

MULTIPLE ACCESS TO MEMORY FEATURE (MAM)

The Multiple Access feature provides the necessary modules on both main frame and memory to permit memories to be accessed via the second path. A word can be transferred over the path in either direction in one cycle. If the computer is equipped with two or more memories and the main frame is communicating with one memory while some other device is using the second path to another memory, then there is no interference with computation. If both the main frame and an I/O device using the second path address the same memory, the second path has priority; the program loses one cycle while the second path transmits.

The Multiple Access feature is required for the attachment of Direct Access Communication Channels (DACC), Data Multiplex Channels (DMC), or Memory Interface Connections (MIC). These devices all incorporate a priority scheme for determining the assignment of the second path. (See Figure A-1.) Only four DACCs can be attached to one computer system; Memory Interface Connections, and Data Multiplex Channels, however, are unlimited in number.

A practically unlimited number of MICs in addition to the four DACCs and the Data Multiplexing System (DMS) can be attached to a computer system. Each MIC has the necessary priority control to operate with other MICs and DACCs and the DMS. Both MICs and DACCs can be arranged so as to produce any required configuration of priorities.

DATA MULTIPLEXING BASIC ELEMENTS

A Data Multiplexing System consists of two basic elements:

1. The Data Multiplex Channel (DMC) for communicating with several data sources/destinations and for synchronizing I/O operations with memory, MICs, DACCs, and other DMCs.


2. One or more Data Subchannels (DSC) for interfacing between peripheral devices and systems and the DMC.

Data Multiplex Channel (DMC)

The Data Multiplex Channel is the basic unit for the Data Multiplexing System. It connects to the second path to memory via the Multiple Access to Memory feature. A DMC consists of 24-bit register and control logic. All addresses and data are transmitted between the DMC and subchannels via a bus system. The data and address are connected to memory via the MAM only when a transfer is to be made. All program control required for a given I/O operation operates directly on the individual subchannel, not the DMC.

The DMC is equipped with an internal interlace feature. This feature allows a subchannel to specify the address of a word in memory where the data address and count are to be found. When operating with internal interlace, the subchannel supplies the address of its interlace word instead of the actual data address. The DMC reads out the interlace word, increments the address portion, decrements the count, restores the word and then accepts the data from or transmits the data to the subchannel. The DMC also supplies a signal to the subchannel if the decremented count is zero.

The format of the internal interlace word or word pair is as shown:



The 9-bit word count allows for block lengths to 512 words. With the 930, transmissions using internal interlace require 3 cycles per word.

The DMC also provides for automatic memory incrementing. The counting capability of the DMC register is such that the entire 24-bit register or either the upper 12 bits or the lower 12 bits may be incremented. When such a memory increment operation is to be performed, the subchannel signals the DMC with a special increment line and supplies the address. The DMC reads out the word, increments it and then restores. If the word was zero after the incrementing, the DMC signals the subchannel which may then interrupt the program. The maximum incrementing rate is 1 count every 2 cycles. Parity generation and detection are available.

Data Subchannels (DSC-N)

There are a number of subchannels which can be attached to the DMC. A full word, 24 bits plus parity, is available for the 930. Words (24 bits) are assembled in two 12-bit characters. Subchannels can control and generate program interrupts but do not include the interrupt levels themselves. The signals must be routed to optional interrupt levels if the interrupt features are to be used.




Figure A-1. SDS 930 Overall Computer Configuration

The subchannels use a priority scheme to determine which may transmit to the DMC at any given time. This is similar to the scheme used by the MICs, DMCs, and in transmitting to memory. Up to 128 DSCs can be connected to a DMC. A DSC can use the internal interlace feature of the DMC to control its transmission or it can be equipped with an external interlace (EIN).

A DSC using internal interlace has two words assigned to it. These two words are adjacent even/odd locations and are fixed for a given subchannel. The program can select either the even or odd location. If the even location is selected, the subchannel will automatically switch to the odd location when the count field of the even word is zero. The program can also select whether or not the subchannel will switch back to the even word when the count field of the odd word is zero. The subchannel will generate an interrupt signal when the count field of either word reaches zero. Transmission termination occurs when the odd word's count equals zero if the subchannel does not switch back to the even word.

The two-word internal interlace allows a subchannel to handle continuous data by alternately working from one memory area or another. By allowing the subchannel to switch automatically from one interlace word to the other, the program is relieved of the necessity for making real-time responses to the zero count condition. Using first the even then the odd interlace word allows maximum word count of 1024 for a pair of interlace words.

CHARACTER SUBCHANNEL (DSC-I)

The DSC-I contains a 12-bit data register that can assemble and disassemble two 6-bit characters, and transmit one or two 6-bit characters or one 12-bit character. It checks and generates the parity of characters to enable it to couple with standard SDS peripherals. The DSC-I has a unit address register. For the 9300, it can be used for multiple typewriters or other character-oriented devices. However, it only uses 12 bits of the full 24-bit word.

The subchannel can operate with either internal or external interlace. It has one mode of output and two modes of input. During output, it transmits until the odd internal interlace word count is zero and then terminates if interlace cycling is not requested. The output can also be terminated if the device sends an END signal to the channel. This END signal may cause the DSC-I to generate an interrupt to the program.

Input, like output, can always be terminated due to an external END signal. The program can also specify if the DSC is to terminate and disconnect on zero count or disconnect only on the END signal. In either case, however, all transmission to memory is terminated after the odd interlace count reaches zero if interlace cycling is not requested.

FULL-WORD SUBCHANNEL (DSC-II)

The DSC-II is a general purpose subchannel designed to allow communication with word-oriented input/output units such as analog-digital and digital-analog converters. It contains no storage for data. The external device must be capable of holding the data during the transmission to/from the DMC. (An A-to-D converter would have such capability). Like the DSC-I, the DSC-II can operate with either internal or external interlace.

Its operation in this respect is identical to that of the DSC-I. The DSC-II also contains control logic to facilitate memory increment operations in conjunction with the DMC.

EXTERNAL INTERLACE

The external interlace (EIN) can be attached to the DSC to control the transmission of its data to/from memory. The EIN consists of a 15-bit address register and a 9-bit count register. These registers are loaded automatically when the subchannel is activated, the information coming from the internal interlace memory locations. Once the EIN is set up, it will control the transmissions of the DSC at a maximum rate of 1 word per memory cycle. After each word is transmitted, the EIN increments its address register and decrements its count. When the count equals zero, the EIN signals the DSC, which can then generate a program interrupt and/or notify the external device. Transmission normally terminates on zero count. Sequencing of interlace words is identical to the sequence of operation performed for internal interlace, except that only two memory cycles are used for interlace word processing. The first is to access the interlace word initially; the second is to restore the interlace word when the count reaches zero.

PROGRAM CONTROL OF DATA SUBCHANNELS

Transmission of data between a DSC and computer memory is controlled by two 24-bit interlace control words unique to the DSC and wired into fixed adjacent locations in memory. During a transmission the DMC/DSC uses the two interlace control words for determination of transmission address and record length.

The DSCs are numbered from 0 to 0376 in even octal numbers; this permits a maximum of 128 subchannels. The memory locations of the interlace control word pairs associated with the DSCs are numbered X0000, X0001 for DSC-0, X0002, X0003 for DSC-2 ... X0376, X0377 for DSC-376. DSC-I numbering need not be contiguous, but DSC-II's are configured one or two in a module and are numbered with adjacent numbers. If a system contains multiple DSC-II modules (each with 1 or 2 subchannels), the module numbering need not be contiguous; 4,0 and 0224, 0220 and 0314 is a typical possibility for five DSC-II subchannels. Transmissions to and from the DSC and memory may be under internal interlace control or, when so equipped, under external interlace control.

INTERNAL INTERLACE

During an internal interlace transmission, the DMC controls the interlacing operation in the following order:

1. Access Interlace Word

The DMC accesses the interlace word assigned to the requesting subchannel.

2. Process Interlace Word

The DMC increments the 15-bit address portion of the word and decrements the 9-bit word count.

3. Test for Zero and Set Indicator

Next, the DMC tests the word count for zero and if it is zero, sets an indicator in the pertinent DSC.

4. Restore

The DMC then places the new word count/address values back into memory using the assigned address of requesting subchannel.

5. Access/Store as Requested

The DMC accesses or stores the transmitted word as requested using the incremental address (see above).

6. Stop or Continue

The DSC checks its zero count indicator and

- if zero and working on the even interlace word, the DSC continues operation using the odd interlace word,
- if zero, working on the odd interlace word and the cycle bit is set, the DSC continues using the even interlace word,
- if zero, working on the odd interlace word and the cycle bit is reset, the DSC terminates the operation on a DSC-II or responds as required by the function control on a DSC-I.
- if not zero, the DSC returns operation to the DMC to continue at 1 (above).

Note that the first address used is the "address specified plus one" and the first word count is the "word count specified minus one". In particular, an initial word count of zero causes a 512-word block to be transmitted.

EXTERNAL INTERLACE


During transmissions utilizing external interlace control, the interlacing operation proceeds as described above except that when the DSC is activated, the DSC with external interlace (EIN) requests the DMC to access the desired interlace control word. The interlace control word is sent to the EIN. Thereafter, data transmissions to and from the DSC to memory utilize the interlace address and word count supplied by the EIN.

Data transmissions using the EIN require only one cycle while those data transmissions using internal interlace require three cycles. Should a transmission result in the EIN detecting a zero word count condition, the DSC-EIN will restore the external interlace word and will proceed according to 6 (above). Any termination of a DSC operation prior to zero word count due to any externally derived halt signal also causes a restoring of the EIN interlace control word.

DSC PROGRAMMING

An EOM, POT sequence selects, alerts, and controls the subchannel; an EOM, SKS sequence selects and tests the status and conditions of the subchannel.

The EOM has the form:




and is referred to as the "select EOM".

Bit positions 16-23 contain the DSC number being alerted; these numbers are the even numbers from 0 to 0376 for the DSC and the C field (bits 13, 14) specifies one of three modes to which the DSC is alerted. When followed by a POT instruction, the modes have the following meaning:


<u>C</u>	<u>Effect</u>
00	The subchannel decodes the lower 12 bits (12-23) of the "POTted" word as the lower 12 bits of a buffer control mode EOM. For DSC-I, this will select a device with the unit address field, set the character/word count, specify binary or BCD format, forward or reverse, and leader or no leader. For DSC-II, the 12 bits activate the subchannel and select the proper unit (if more than one is attached to the DSC).
01	The subchannel decodes the lower 12 bits of the "POTted" word as the lower 12 bits of an input/output control mode EOM. If bits 18 through 23 are zero, the "POTted" word addresses the selected DSC. For DSC-I, these bits perform such functions as rewind tape, space paper, etc. For DSC-II, these bits perform such functions as required by the selected device attached to the DSC.
10	The subchannel decodes the lower 12 bits of the "POTted" word for controlling the interlace and interrupts. The control type EOM should precede the buffer control EOM.

For DSC-I the form is:



FC is a 2-bit function code similar to the TMCC/DACC terminal function codes. The remaining bits function as described below for DSC-II.

For DSC-II, the form is:




<u>Bit Position</u>	<u>Function</u>
20	A 1 in the EOR bit arms the End-of-Record interrupt for this channel.
21	A 1 in the ZWC bit arms the Zero Word Count interrupt.


Bit Position	Function
22	A 1 in the CY bit (cycle) sets the cycle mode such that the interlace will switch from the odd word back to the even word at the zeroing of the odd word count. If ZWC and CY are set, a zero count interrupt is generated each time the interlace switches (to either word – even or odd). If CY is set to 0, the interlace will not proceed after the count of the odd word is zero; and a zero count interrupt occurs only when the count of the odd word is zero.
23	A 0 in the E/O bit selects the even interlace word as the first interlace word in a transmission; note that when starting on the even word, the interlace always switches to the odd word for further control when the even word count goes to zero. A 1 in E/O sets the odd interlace word as the first interlace word in a transmission; the interlace ceases control when the odd word count reaches zero unless the C bit is set to cycle.

TERMINATING DSC INPUT/OUTPUT

Once the cycle bit has been set, the interlace continues to cycle back and forth between the even/odd interlace words. An EOM, POT sequence is used to terminate the cycle. The EOM is:



The lower 12 bits of the "POTted" word must be:



The interlace terminates the next time the count reaches zero in the odd interlace word.


For example, to terminate the cycle on DSC 4, use the following sequence:

```

EOM 071004
POT 010000
:
:
010000 00000200

```

The SKS to test subchannels has the form:



A select EOM with C equal to zero (C = 0) permits the SKS to be directed to the subchannel or to the device attached to it. The UNIT field specifies the device to be tested; the TEST field is defined for the particular device.

When testing the subchannel, the UNIT field is set to 00. The TEST field contains the same testing format as SKS for testing a TMCC.

For example, to test DSC 4 for error, use the following sequence:

```

EOM 070004
SKS 071000

```

MEMORY INTERFACE CONNECTION

Once a computer is equipped with a multiple access to memory feature, one or more memory interface connections (MIC) can be attached. The MIC is a general interface between the computer and the outside world that allows special devices to be connected to the computer. The MIC converts between the 4-volt logic levels used in the computer and the 8 volts used outside. It preserves the integrity of the memory by generating the parity of incoming data words. It will also check the parity of words read from memory to indicate memory failures. If incoming data is supplied with parity, the MIC will check for odd parity as it generates the internal memory parity and respond with a signal that indicates if the transmission was correct. The device that is connected to the MIC must store both the data and the address until the transmission to/from memory is completed.

AUTOMATIC POWER FAIL-SAFE SYSTEM

The computer core memory holds its information with all power removed, but information in the computer registers is destroyed by loss of power. Upon failure of main power to the computer, this system provides that the contents of all registers and other volatile information are automatically stored in core memory; also, further writing into core storage is inhibited during the decay period of the computer dc power supply outputs. Erroneous memory control is prevented during power-off and power-on operations. Power-off/-on interrupt routines permit proper resumption of a program, automatically, after power is restored. This solid-state system consists of ac power-sensing and memory-sequencing circuitry, two high-priority interrupt channels, and a "shut-down/start-up" programming sequence.

The SKIP IF SIGNAL NOT SET (SKS) instruction is an aid in programming this option. Its address is 024000. If the OFF interrupt (37) has just occurred, the computer executes the next instruction in sequence (does not skip).

MEMORY PARITY INTERRUPTS

SDS computers incorporate an extensive memory parity checking system. The inclusion of parity generation and checking circuitry assures the integrity of data and instructions transferred among the memory, the central processing unit, and input/output channels.

In normal operation a switch on the computer console specifies the action to be performed by the computer when a memory parity error is detected. Two actions are available: the computer halts with the parity indicator lighted; or the computer ignores the parity error and proceeds with the program.

In many real-time applications it is desirable to keep the computer running when a parity error is detected. Also, the program must be notified of the error without stopping computation.

An optional feature provides this capability by means of two levels of enabled interrupts. One interrupt level is associated with the central processor; the other interrupt level with the Direct Access Communication Channels and the Data Multiplexing System. Memory parity errors detected from these two sources produce a priority interrupt associated with the cause. The processing routine associated with the interrupt can then take appropriate action, such as re-initiate the failed operation, notify the operator, or enter a diagnostic routine. Such action allows memory parity errors to be recognized and handled properly without hindering the computer's performance of real-time or on-line calculations.

REAL-TIME CLOCK

The Real-Time Clock (RTC) provides a flexible time-orientation system for the SDS 930 Computer. It derives time pulses from the 60-cycle computer power supply. These pulses are then used to produce a timing mark every 16.67 milliseconds, or optionally every 8.33 milliseconds. The Real-Time Clock can also accept timing marks from a customer-supplied input, thereby allowing time measurement to any required resolution for special applications. These timing marks are supplied at standard SDS logic levels to the computer's RTC circuitry.

The timing marks are then used by the computer and its interrupt system to provide either an elapsed-time counter or a continuously incrementing time counter depending on the needs of the customer. The RTC operates in either mode depending only on the computer's stored program.

<u>Location</u>	<u>Type</u>	<u>Computer</u>	<u>Description</u>
074	Normal	930	CLOCK SYNC
075	Single Instruction	930	CLOCK PULSE

The Clock Pulse and Clock Sync interrupts function together to provide elapsed-time, event counter, or time-of-day clocks.

The Clock Pulse interrupt is a single-instruction interrupt. (Note: See Single Instruction Interrupts in Section 3.) An MIN instruction is usually placed in the Clock Pulse interrupt location. When MIN is used as a single-instruction interrupt

subroutine, it causes the contents of the effective address to be incremented by one. Furthermore, if the new (incremented) contents of the effective address is 0000, a Clock Sync interrupt is generated. The Clock Sync interrupt can be generated in no other way.

ELAPSED-TIME CLOCK

The elapsed-time clock times the length of a program or subroutine, or initiates or discontinues processing at program-determined time intervals. An arbitrary memory location is reserved as a counter. When initialized, this cell contains the 2's complement of the number of time intervals to be counted. The Clock Pulse interrupt location contains an SKR instruction.

Each Clock Pulse interrupt results in decrementing the clock count by one. When the count is finished, an interrupt to the Clock Sync location occurs. A supervisory or other appropriate control program can then be entered to perform the customer-desired operation.

CONTINUOUSLY INCREMENTING CLOCK

The continuously incrementing clock maintains "time-of-day" for the computer. One memory location serves to count the timing marks. In this case, the Clock Pulse is used to increment this location. (The Clock Pulse interrupt location contains an MIN instruction.) A simple, straightforward subroutine can be entered to reconstruct the exact time-of-day from this twenty-four bit count.

ARM/DISARM

The Clock Pulse interrupt can be armed and disarmed with these instructions.

<u>EOM Effective Address</u>	<u>Action</u>
20200	Disarm Clock Pulse Interrupt
20100	Arm Clock Pulse Interrupt

The Clock Sync interrupt is always armed.

PROGRAMMED OPERATOR INSTRUCTIONS

The SDS Programmed Operator enables a programmer to code a subroutine call with a single instruction, just as if the subroutine were an actual machine instruction. Other computers usually perform standard subroutine calls by executing a transfer to the starting location of the subroutine and, at the same time, preserving a return address. This procedure requires an operation code (indicating a transfer) and an operand address (indicating the starting address of the subroutine). If the subroutine should require an additional operand, as in a floating point add subroutine, for example, the calling sequence must be longer to accommodate the specification of the operand.

The SDS Programmed Operator (abbreviated POP) uses the operation code to indicate the transfer address. When the computer detects a "one" in bit position 2 of an instruction, bit positions 2 through 8 are not interpreted as a normal instruction, but instead, are treated as an address to which the computer transfers control. Thus the operand address field is free to designate an address for use by the subroutine. There are 64 (decimal) locations $[(100)_8 \text{ through } (177)_8]$ to which a transfer may occur. These 64 locations constitute a linkage table; they normally contain appropriate unconditional transfer instructions (BRU) to maintain the communication link between the POP code and the subroutine being called by it.

The location from which the transfer is made, at the time the computer detects the POP code (that is, the contents of the P Register), is preserved in location 0. Thus the normal BRU instruction may be used to leave the POP subroutine and return to the main program. Also, the state of the overflow toggle is preserved in the sign bit position of location 0 and the overflow toggle is immediately reset.

To allow access to the operand in the main program by the POP subroutine, bit position 9 (the indirect address bit) is unconditionally set to "one". In this manner, when the subroutine refers indirectly to location 0, the indirect addressing is perpetuated one more level, thereby enabling the subroutine to gain access to the operand in the main program. (See the Programmed Operator Example for further explanation.)

By judicious use of the programmed operator principle, a one-to-one correspondence may be maintained between SDS 930 instructions and SDS 925 instructions. For example, XMA is a 930 machine instruction; its function may be simulated on the SDS 925 by a subroutine, and this subroutine may be called by means of a programmed operator. Thus, the main program requires the same number of instructions for either the SDS 925 or 930.

Another advantage of the programmed operator is the ability to change the arithmetic mode of a program without recoding the arithmetic portions of the program. For example, if the programmer codes all arithmetic instructions as programmed operators, he could simply change the arithmetic subroutine package and, hence, the arithmetic mode of the main program.

The following operations take place when the computer detects a programmed operator:

1. $(P) \rightarrow (C)_{10-23}$; save P Register for return address
2. $1 \rightarrow (C)_9$; insert indirect address bit
3. $(O_f) \rightarrow (C)_0$; preserve status of overflow toggle
4. $(C)_{2-8} \rightarrow (P)$; branch to location indicated in POP code

A library of programmed operator subroutines is available to greatly extend the SDS 930 instruction list. A list of these subroutines is given in this appendix. Each subroutine is specified by a unique mnemonic code and represents an available instruction which may be used directly in preparing 930 programs. Up to 64 of these programmed operator instructions may be used to prepare any one program.

The program loading system automatically organizes the interconnection between the programmed operator instructions and the corresponding subroutines. Each programmed operator instruction mnemonic code is converted on input to an instruction code of 100g to 177g. A memory location from 100g through 177g corresponding to each assigned instruction code is loaded with an unconditional branch to the corresponding subroutine.

SDS 930 PROGRAMMED OPERATOR EXAMPLE

Location	Instruction	Effective Address	Contents of Effective Address	Location 0	O_f	A Register	B Register
01342	1 XMP 02163	02163	00000012	40041342	Set	00000144	01234567
00140	0 BRU 00300				Reset		
00300	0 STB 00305						
00301	0 MUL* 00000	02163	00000012			00000000	00003720
00302	0 LSH 00027					00001750	00000000
00303	0 LDB 00305	00305	01234567			00001750	01234567
00304	0 BRR 00000				Set		
01343	Continue in main program						

Explanation: XMP is a programmed operator that produces the integer product of the integer in the A Register and the integer contained in the effective address. Overflow is set if the integer product exceeds the capacity of a single register. The contents of the B and X Registers are unaffected by this "instruction". In this example, XMP is POP code 140.

SDS 930 STANDARD PROGRAMMED OPERATOR INSTRUCTIONS

<u>Mnemonic</u>	<u>Description</u>	<u>Mnemonic</u>	<u>Description</u>
LOG	Logarithm of A, single-precision, fixed-point	FLM	Floating multiply, double-precision
LGF	Logarithm of A, floating-point	FSM	Floating multiply, single-precision
EXP	Exponential of A, single-precision, fixed-point	FLD	Floating divide, double-precision
EXF	Exponential of A, floating-point	FSD	Floating divide, single-precision
ATN	Arctangent of A, single-precision, fixed-point	FLN	Floating negate, double-precision
ATD	Arctangent of A, double-precision, fixed-point	FSN	Floating negate, single-precision
ATF	Arctangent of A, floating-point	FSQ	Floating square root, double-precision
SIN	Sine of A, single-precision, fixed-point	SQR	Square root, single-precision, fixed-point
SND	Sine of A, double-precision, fixed-point	FFF	Fixed-floating format conversion
SNF	Sine of A, floating-point	LTP	Load, triple-precision
COS	Cosine of A, single-precision, fixed-point	LQP	Load, quadruple-precision
CSD	Cosine of A, double-precision, fixed-point	STP	Store, triple-precision
CSF	Cosine of A, floating-point	STQ	Store, quadruple-precision
DPA	Double-precision add	BDD	Binary to decimal conversion, double-precision, fixed-point
DPS	Double-precision subtract	BFS	Binary to decimal conversion, single-precision, floating-point
DPM	Double-precision multiply	BDF	Binary to decimal conversion, double-precision, floating-point
DPD	Double-precision divide	DBD	Decimal to binary conversion, double-precision, fixed-point
DPN	Double-precision negate	DFS	Decimal to binary conversion, single-precision, floating-point
DSQ	Double-precision square root	DBF	Decimal to binary conversion, double-precision, floating-point
LDP	Load double-precision	BID	Binary to decimal conversion, single-precision, fixed-point
STD	Store double-precision	DIB	Decimal to binary conversion, single-precision, fixed-point
FLA	Floating add, double-precision		
FSA	Floating add, single-precision		
FLS	Floating subtract, double-precision		
FSS	Floating subtract, single-precision		

CHANNEL MEMORY ACCESS PRIORITY

During each memory cycle the control unit interrogates each channel to determine if it needs access to memory. If only one channel requires memory access, the control unit permits the channel to proceed immediately. If more than one channel requires memory access, the determination of which one proceeds first is on the basis of a fixed and a variable priority. The fixed priority is in the order: Direct Access Channel, Time-Multiplexed Channel, and Central Processor. Time-Multiplexed Channels have fixed priority in the order: D, C, Y, and W. Direct Access Channels have variable priority that is normally determined by comparison of the Word Assembly Register in each channel. The channel whose Word Assembly Register has the fewest number of characters remaining to be filled is selected for memory access. For example, if the Word Assembly Register in Channel E has one character position unfilled and the Word Assembly Register in Channel F has three character positions unfilled, Channel E is selected.

Thus, each channel increases its priority level as each character is read into the Word Assembly Register. If the contents of the register in two or more channels are equal in characters to be filled and no other channel in the set has fewer characters to be filled, priority is determined in sequence, with Channel E having top priority.

Note that the number of characters to be placed in the Word Assembly Register at any time is dependent on the characters per word count specified for the transmission. Consider, for example, that in Channel E the character count is three characters per word and in Channel F the character count is four characters per word. If both Channel F and Channel E need access to memory simultaneously, and if both have two characters filled in their respective Word Assembly Registers, then Channel E gets first memory access since it has only one character place to be filled.

DIVISION INSTRUCTION

During execution of the DIVIDE (DIV) instruction, the contents of the A, B Registers taken as a double-precision number are divided by the single-precision contents of the effective address. If the numerator is a single-precision number, the program should clear the B Register prior to executing the DIV, or erroneous results may occur. Although a double-length numerator is used, DIV is a single-precision operation; it should not be confused with a double-precision divide operation that uses a double-length denominator and produces a double-length quotient.

After the execution of DIV, the single-precision quotient replaces the contents of the A Register, and the remaining portion of the numerator that has not been divided (undivided remainder) replaces the contents of the B Register. The quotient is signed in accordance with algebraic convention, that is, positive if numerator and denominator signs are alike, but negative otherwise. However, DIV generates only 23 magnitude bits and, if the magnitude of the quotient is so small as to require more than 23 bits to resolve, DIV may produce a zero quotient regardless of the required sign; but the remainder reflects the undivided portion of the original numerator. The binary scaling of the quotient is equal to the numerator scale factor minus the denominator scale factor.

The undivided remainder replaces the contents of the B Register and has the same sign as the original numerator. It is scaled, in B, at numerator scaling minus 23. By definition, the undivided remainder is that quantity which must be added to the product of the denominator and the quotient to produce the original numerator. The results of the DIV instruction are consistent with definition. It should be noted that the program must shift the remainder right 23 places before adding it to the product of denominator and quotient to maintain proper scaling. Overflow is possible and the computer sets the Overflow Indicator if:

- a) $(A, B)/(M) \geq 1$
- or b) $(A, B)/(M) < -1$

EXAMPLE:

Let $(A, B) = 58.75B30$
 $(M) = 10B8$
 Binary scaling of the quotient $= 30 - 8 = 22$
 Binary scaling of the remainder $= 30 - 23 = 7$
 Complete quotient should be 5.875

With the binary scale point at 22 and only 23 bits generated in the quotient, the contents of A will be 5.5. In other words, only 55 of the original 58.75 units in the numerator are divided, leaving 3.75 units undivided. The undivided remainder is thus 3.75B7 in B.

EXAMPLE:

Let $(A, B) = 44.625B28$
 $(M) = 7B7$
 Quotient scaling $= 28 - 7 = 21$
 Remainder scaling $= 28 - 23 = 5$
 Complete quotient should be $44.625/7 = 6.375$

With the binary scale point at 21, only 6.25 will be generated in A. Thus only $7 \times 6.25 = 43.75$ units are divided, leaving $44.625 - 43.75 = .875$ undivided. Therefore, the undivided remainder is .875B5 in B.

SDS 930 INSTRUCTION LIST — FUNCTIONAL CATEGORIES

<u>Mnemonic</u>	<u>Instruction Code</u>	<u>Name</u>	<u>Function</u>	<u>Timing</u>	<u>Page Ref.</u>
<u>LOAD and STORE</u>					
LDA	76	LOAD A	$(M) \rightarrow A$	2	8
STA	35	STORE A	$(A) \rightarrow M$	3	8
LDB	75	LOAD B	$(M) \rightarrow B$	2	8
STB	36	STORE B	$(B) \rightarrow M$	3	8
LDX	71	LOAD INDEX	$(M) \rightarrow X$	2	8
STX	37	STORE INDEX	$(X) \rightarrow M$	3	8
XMA	62	EXCHANGE M AND A	$(A) \leftrightarrow (M)$	3	9
EAX	77	COPY EFFECTIVE ADDRESS INTO INDEX REGISTER	Effective Address $\rightarrow X$	2	8
<u>ARITHMETIC</u>					
ADD	55	ADD M TO A	$(A) + (M) \rightarrow A$	2	9
ADC	57	ADD WITH CARRY	$(A) + (M) + \text{Carry} \rightarrow A$	2	9
ADM	63	ADD A TO M	$(A) + (M) \rightarrow M$	3	9
MIN	61	MEMORY INCREMENT	$(M) + 1 \rightarrow M$	3	9
SUB	54	SUBTRACT M FROM A	$(A) - (M) \rightarrow A$	2	10
SUC	56	SUBTRACT WITH CARRY	$(A) - (M) - \text{Carry} \rightarrow A$	2	10
MUL	64	MULTIPLY	$(A) \times (M) \rightarrow A, B$	4	10
DIV	65	DIVIDE	$(A, B) \div (M) \rightarrow A, R \rightarrow B$	10	11
<u>LOGICAL</u>					
ETR	14	EXTRACT	$(A) \text{ and } (M) \rightarrow A$	2	11
MRG	16	MERGE	$(A) \text{ or } (M) \rightarrow A$	2	11
EOR	17	EXCLUSIVE OR	$(M)(\overline{A}) \text{ or } (\overline{M})(A) \rightarrow A$	2	11
<u>REGISTER CHANGE</u>					
CLA	0 46 00001	CLEAR A	$0 \rightarrow A$	1	12
CLB	0 46 00002	CLEAR B	$0 \rightarrow B$	1	12
CLR	0 46 00003	CLEAR AB	$0 \rightarrow A, B$	1	12
CAB	0 46 00004	COPY A INTO B	$(A) \rightarrow B$	1	12
CBA	0 46 00010	COPY B INTO A	$(B) \rightarrow A$	1	12
XAB	0 46 00014	EXCHANGE A AND B	$(A) \leftrightarrow (B)$	1	12
BAC	0 46 00012	COPY B INTO A, CLEAR B	$(B) \rightarrow A, 0 \rightarrow B$	1	13
ABC	0 46 00005	COPY A INTO B, CLEAR A	$(A) \rightarrow B, 0 \rightarrow A$	1	13
CLX	2 46 00000	CLEAR INDEX REGISTER	$0 \rightarrow X$	1	13
CXA	0 46 00200	COPY INDEX INTO A	$(X) \rightarrow A$	1	13

<u>Mnemonic</u>	<u>Instruction Code</u>	<u>Name</u>	<u>Function</u>	<u>Timing</u>	<u>Page Ref.</u>
<u>REGISTER CHANGE (cont.)</u>					
CAX	0 46 00400	COPY A INTO INDEX	$(A) \rightarrow X$	1	13
XXA	0 46 00600	EXCHANGE INDEX AND A	$(X) \leftrightarrow (A)$	1	13
CBX	0 46 00020	COPY B INTO INDEX	$(B) \rightarrow X$	1	13
CXB	0 46 00040	COPY INDEX INTO B	$(X) \rightarrow B$	1	13
XXB	0 46 00060	EXCHANGE INDEX AND B	$(X) \leftrightarrow (B)$	1	13
STE	0 46 00122	STORE EXPONENT	$(B_{15-23}) \rightarrow X_{15-23}$ $0 \rightarrow B_{15-23}, X_{15} \rightarrow X_{0-14}$	1 1	13
LDE	0 46 00140	LOAD EXPONENT	$(X_{15-23}) \rightarrow B_{15-23}$	1	14
XEE	0 46 00160	EXCHANGE EXPONENTS	$(B_{15-23}) \leftrightarrow (X_{15-23})$	1	14
CNA	0 46 01000	COPY NEGATIVE INTO A	$-(A) \rightarrow A$	1	14
<u>MEMORY EXTENSION</u>					
	0 06 200SR	SET EXTENSION REGISTER	$SR \rightarrow ME$	1	19
	0 40 4000T	EXTENSION REGISTER TEST	$(ME)_T = 0$	2, 3	20
<u>BRANCH</u>					
BRU	01	BRANCH UNCONDITIONALLY	$M \rightarrow P$	1	14
BRX	41	INCREMENT INDEX AND BRANCH	$(X)+1 \rightarrow X$ If X Neg., $M \rightarrow P$ If X Pos., $P+1 \rightarrow P$	1 2	14
BRM	43	MARK PLACE AND BRANCH	$(P) \rightarrow M; M+1 \rightarrow P$	2	15
BRR	51	RETURN BRANCH	$(M)+1 \rightarrow P$	2	15
<u>TEST AND SKIP</u>					
SKE	50	SKIP IF A EQUALS M	If $(A) \neq (M)$, $P+1 \rightarrow P$ If $(A) = (M)$, $P+2 \rightarrow P$	2 3	15
SKG	73	SKIP IF A GREATER THAN M	If $(A) \leq (M)$, $P+1 \rightarrow P$ If $(A) > (M)$, $P+2 \rightarrow P$	2 3	15
SKM	70	SKIP IF A=M ON B MASK	If $(B)(A) \neq (B)(M)$, $P+1 \rightarrow P$ If $(B)(A) = (B)(M)$, $P+2 \rightarrow P$	2 3	15
SKA	72	SKIP IF M AND A DO NOT COMPARE ONES	If $(A)(M) \neq 0$, $P+1 \rightarrow P$ If $(A)(M) = 0$, $P+2 \rightarrow P$	2 3	16
SKB	52	SKIP IF M AND B DO NOT COMPARE ONES	If $(B)(M) \neq 0$, $P+1 \rightarrow P$ If $(B)(M) = 0$, $P+2 \rightarrow P$	2 3	16
SKN	53	SKIP IF M NEGATIVE	If $(M) \geq 0$, $P+1 \rightarrow P$ If $(M) < 0$, $P+2 \rightarrow P$	2 3	16
SKR	60	REDUCE M, SKIP IF NEGATIVE	$(M)-1 \rightarrow M$ If (M) Pos., $P+1 \rightarrow P$ If (M) Neg., $P+2 \rightarrow P$	3	16

<u>Mnemonic</u>	<u>Instruction Code</u>	<u>Name</u>	<u>Function</u>	<u>Timing</u>	<u>Page Ref.</u>
<u>TEST AND SKIP (cont.)</u>					
SKD	74	DIFFERENCE EXPONENTS AND SKIP	$ (B_{15-23}) - (M_{15-23}) \rightarrow X_{15-23}$ If Difference is Pos., $P+1 \rightarrow P$ If Difference is Neg., $P+2 \rightarrow P$	2 3	16
SKS	40	SKIP IF SIGNAL NOT SET	If Signal=1, $P+1 \rightarrow P$ If Signal=0, $P+2 \rightarrow P$	2 3	27, 37 38, 42
<u>SHIFT</u>					
RSH	0 66 00XXX	RIGHT SHIFT AB	AB Shift Right N Places	2-7	17
RCY	0 66 20XXX	RIGHT CYCLE AB	AB Cycled Right N Places	2-7	17
LRSH	0 66 24XXX	LOGICAL RIGHT SHIFT AB	AB Shift Right N Places	2-7	17
LSH	0 67 00XXX	LEFT SHIFT AB	AB Shift Left N Places	2-5	18
LCY	0 67 20XXX	LEFT CYCLE AB	AB Cycled Left N Places	2-5	18
NOD	0 67 10XXX	NORMALIZE AND DECREMENT INDEX	AB Left and $X-1 \rightarrow X$ until $A_0 \neq A_1$, or N Shifts	2-5	18
<u>CONTROL</u>					
HLT	00	HALT	Halts Computation	1	18
NOP	20	NO OPERATION	- - -	1	19
EXU	23	EXECUTE	Instruction M is Performed, P is Unchanged	1	19
<u>BREAKPOINT TESTS</u>					
BPT1	0 40 20400	BREAKPOINT NO. 1 TEST	Test Breakpoint Switch	1,2	19
BPT2	0 40 20200	BREAKPOINT NO. 2 TEST	Test Breakpoint Switch	1,2	19
BPT3	0 40 20100	BREAKPOINT NO. 3 TEST	Test Breakpoint Switch	1,2	19
BPT4	0 40 20040	BREAKPOINT NO. 4 TEST	Test Breakpoint Switch	1,2	19
<u>OVERFLOW</u>					
OVT	0 40 20001	OVERFLOW INDICATOR TEST AND RESET	Test Overflow Indicator	1,2	19
ROV	0 02 20001	RESET OVERFLOW	Turn Off Overflow Indicator	1	19
REO	0 02 20010	RECORD EXPONENT OVERFLOW	$1 \rightarrow$ Overflow Indicator if $X_{14} \neq X_{15}$	1	18
<u>INTERRUPT</u>					
EIR	0 02 20002	ENABLE INTERRUPT SYSTEM		1	23
DIR	0 02 20004	DISABLE INTERRUPT SYSTEM		1	23
IET	0 40 20004	INTERRUPT ENABLED TEST	Skip if Interrupt System Enabled	1,2	23
IDT	0 40 20002	INTERRUPT DISABLED TEST	Skip if Interrupt System Disabled	1,2	23
AIR	0 02 20020	ARM INTERRUPTS		1	23

<u>Mnemonic</u>	<u>Instruction Code</u>	<u>Name</u>	<u>Function</u>	<u>Timing</u>	<u>Page Ref.</u>
<u>CHANNEL CONTROL</u>					
ALC 0	0 02 50000	ALERT CHANNEL W	(For other channel codes, see page 35.) 3	1	33
DSC 0	0 02 00000	DISCONNECT CHANNEL W	(For other channel codes, see page 35.)	1	33
ASC 0	0 02 12000	ALERT TO STORE ADDRESS IN CHANNEL W	(For other channel codes, see page 35.)	1	33
TOP 0	0 02 14000	TERMINATE OUTPUT ON CHANNEL W	(For other channel codes, see page 35.)	1	33
<u>CHANNEL TESTS</u>					
CAT 0	0 40 14000	CHANNEL W ACTIVE TEST; SKIP IF CHANNEL INACTIVE	(For other channel codes, see page 39.)	2, 3	37
CET 0	0 40 11000	CHANNEL W ERROR TEST; SKIP IF NO ERROR	(For other channel codes, see page 39.)	2, 3	37
CIT 0	0 40 10400	CHANNEL W INTER-RECORD TEST	(For other channel codes, see page 40.)	2, 3	38
CZT 0	0 40 12000	CHANNEL W ZERO COUNT TEST; SKIP IF COUNT EQUALS ZERO	(For other channel codes, see page 40.)	2, 3	38
<u>INPUT/OUTPUT</u>					
MIW	12	M INTO W BUFFER WHEN EMPTY	(M)→W	2 + wait	38
MIY	10	M INTO Y BUFFER WHEN EMPTY	(M)→Y	2 + wait	39
WIM	32	W BUFFER INTO M WHEN FULL	(W)→M	3 + wait	39
YIM	30	Y BUFFER INTO M WHEN FULL	(Y)→M	3 + wait	39
PIN	33	PARALLEL INPUT	(Unit M)→M in Parallel	4 + wait	41
POT	13	PARALLEL OUTPUT	(M)→Unit M in Parallel	3 + wait	41
EOM	02	ENERGIZE OUTPUT M		1	26, 31
EOD	06	ENERGIZE OUTPUT TO DIRECT ACCESS CHANNEL		1	27, 33
BETW	0 40 20010	W BUFFER ERROR TEST		1, 2	37
BETY	0 40 20020	Y BUFFER ERROR TEST		1, 2	37
BRTW	0 40 21000	W BUFFER READY TEST		1, 2	37
BRTY	0 40 22000	Y BUFFER READY TEST		1, 2	37
<u>TYPEWRITER</u>					
RKB 0, 1, 4	0 02 02601	READ KEYBOARD			46
TYP 0, 1, 4	0 02 02641	WRITE TYPEWRITER			46
<u>PAPER TAPE</u>					
RPT 0, 1, 4	0 02 02604	READ PAPER TAPE		1	49
PTL 0, 1, 4	0 02 00644	PUNCH PAPER TAPE WITH LEADER		1	49
PPT 0, 1, 4	0 02 02644	PUNCH PAPER TAPE WITH NO LEADER		1	49

<u>Mnemonic</u>	<u>Instruction Code</u>	<u>Name</u>	<u>Function</u>	<u>Timing</u>	<u>Page Ref.</u>
<u>PUNCHED CARD</u>					
CRT 0, 1	0 40 12006	CARD READER READY TEST		2, 3	53
CFT 0, 1	0 40 11006	CARD READER END-OF-FILE TEST		2, 3	53
RCD 0, 1, 4	0 02 02606	READ CARD DECIMAL (HOLLERITH)		1	53
RCB 0, 1, 4	0 02 03606	READ CARD BINARY		1	53
CPT 0, 1	0 40 14046	CARD PUNCH READY TEST		2, 3	53
PCD 0, 1, 4	0 02 02646	PUNCH CARD DECIMAL (HOLLERITH)		1	53
PCB 0, 1, 4	0 02 03646	PUNCH CARD BINARY		1	53
FCT 0, 1	0 40 14006	FIRST COLUMN TEST		2, 3	53
PBT 0, 1	0 40 12046	PUNCH BUFFER TEST		2, 3	53
SRC 0, 1	0 02 12006	SKIP REMAINDER OF CARD		1	53
<u>MAGNETIC TAPE</u>					
TRT 0, n	0 40 1041n	TAPE READY TEST		2, 3	57
FPT 0, n	0 40 1401n	FILE PROTECT TEST		2, 3	57
BTT 0, n	0 40 1201n	BEGINNING OF TAPE TEST		2, 3	57
ETT 0, n	0 40 1101n	END OF TAPE TEST		2, 3	58
DT2 0, n	0 40 1621n	DENSITY TEST, 200 BPI		2, 3	58
DT5 0, n	0 40 1661n	DENSITY TEST, 556 BPI		2, 3	58
DT8 0, n	0 40 1721n	DENSITY TEST, 800 BPI		2, 3	58
TFT 0	0 40 13610	TAPE END-OF-FILE TEST		2, 3	58
TGT 0, n	0 40 1261n	TAPE GAP TEST		2, 3	58
WTB 0, n, 4	0 02 0365n	WRITE TAPE IN BINARY		1	58
WTD 0, n, 4	0 02 0265n	WRITE TAPE IN DECIMAL (BCD)		1	58
EFT 0, 4	0 02 0367n	ERASE TAPE FORWARD		1	58
ERT 0, n, 4	0 02 0767n	ERASE TAPE IN REVERSE		1	58
RTB 0, n, 4	0 02 0361n	READ TAPE IN BINARY		1	58
RTD 0, n, 4	0 02 0261n	READ TAPE IN DECIMAL (BCD)		1	58
SFB 0, n, 4	0 02 0363n	SCAN FORWARD IN BINARY		1	58
SFD 0, n, 4	0 02 0263n	SCAN FORWARD IN DECIMAL (BCD)		1	58
SRB 0, n, 4	0 02 0763n	SCAN REVERSE IN BINARY		1	58
SRD 0, n, 4	0 02 0663n	SCAN REVERSE IN DECIMAL (BCD)		1	58
REW 0, n	0 02 1401n	REWIND		1	58
	0 40 1021n	MAGPAK TEST		2, 3	58
RTS 0	0 02 14000	CONVERT READ TO SCAN		1	58
SRR 0	0 02 13610	SKIP REMAINDER OF RECORD		1	58
<u>PRINTER</u>					
PRT 0, 1	0 40 12060	PRINTER READY TEST		2, 3	63
EPT 0, 1	0 40 14060	END OF PAGE TEST		2, 3	63
PFT 0, 1	0 40 11060	PRINTER FAULT TEST		2, 3	63
POL 0, 1	0 02 10260	PRINTER OFF-LINE		1	63
PSC 0, 1, N	0 02 1N460	PRINTER SKIP TO CHANNEL N		1	63
PSP 0, 1, N	0 02 1N660	PRINTER SPACE N LINES		1	63
PLP 0, 1, 4	0 02 02660	PRINT LINE PRINTER		1	63

SDS 930 INSTRUCTION LIST-NUMERICAL ORDER

<u>Instruction Code</u>	<u>Mnemonic</u>	<u>Name</u>	<u>Page References</u>
00	HLT	HALT	18
01	BRU	BRANCH UNCONDITIONALLY	14
02	EOM	ENERGIZE OUTPUT M	25, 26, 27, 28, 31, 34, 41
0 02 00000	DSC 0	DISCONNECT CHANNEL W	For other channel codes see page 33
0 02 02601	RKB 0, 1, 4	READ KEYBOARD	46
0 02 02641	TYP 0, 1, 4	WRITE TYPEWRITER	46
0 02 00644	PTL 0, 1, 4	PUNCH PAPER TAPE WITH LEADER	49
0 02 02604	RPT 0, 1, 4	READ PAPER TAPE	49
0 02 02606	RCD 0, 1, 4	READ CARD DECIMAL (HOLLERITH)	53
0 02 0261n	RTD 0, n, 4	READ TAPE IN DECIMAL (BCD)	58
0 02 0263n	SFD 0, n, 4	SCAN FORWARD IN DECIMAL (BCD)	58
0 02 02644	PPT 0, 1, 4	PUNCH PAPER TAPE WITH NO LEADER	49
0 02 02646	PCD 0, 1, 4	PUNCH CARD DECIMAL (HOLLERITH)	53
0 02 0265n	WTD 0, n, 4	WRITE TAPE IN DECIMAL (BCD)	58
0 02 02660	PLP 0, 1, 4	PRINT LINE PRINTER	63
0 02 03606	RCB 0, 1, 4	READ CARD BINARY	53
0 02 0361n	RTB 0, n, 4	READ TAPE IN BINARY	58
0 02 0363n	SFB 0, n, 4	SCAN FORWARD IN BINARY	58
0 02 03646	PCB 0, 1, 4	PUNCH CARD BINARY	53
0 02 0365n	WTB 0, n, 4	WRITE TAPE IN BINARY	58
0 02 0367n	EFT n, 4	ERASE TAPE FORWARD	58
0 02 0663n	SRD 0, n, 4	SCAN REVERSE IN DECIMAL (BCD)	58
0 02 0763n	SRB 0, n, 4	SCAN REVERSE IN BINARY	58
0 02 0767n	ERT 0, n, 4	ERASE TAPE IN REVERSE	58
0 02 10260	POL 0, 1	PRINTER OFF-LINE	63
0 02 12000	ASC 0	ALERT TO STORE ADDRESS IN CHANNEL W	For other channel codes, see page 33
0 02 12006	SRC 0	SKIP REMAINDER OF CARD	53
0 02 13610	SRR 0	SKIP REMAINDER OF RECORD	58
0 02 14000	TOP 0	TERMINATE OUTPUT ON CHANNEL W	For other channel codes, see page 34
0 02 14000	RTS 0	CONVERT READ TO SCAN	58
0 02 1401n	REW 0, n	REWIND	58
0 02 1N460	PSC 0, 1, N	PRINTER SKIP TO CHANNEL N	63
0 02 1N660	PSP 0, 1, N	PRINTER SPACE N LINES	63
0 02 20001	ROV	RESET OVERFLOW	19
0 02 20002	EIR	ENABLE INTERRUPT SYSTEM	23
0 02 20004	DIR	DISABLE INTERRUPT SYSTEM	23
0 02 20010	REO	RECORD EXPONENT OVERFLOW	18

<u>Instruction Code</u>	<u>Mnemonic</u>	<u>Name</u>	<u>Page References</u>
0 02 20020	AIR	ARM INTERRUPTS	23
0 02 50000	ALC 0	ALERT CHANNEL W	For other channel codes, see page 33
06	EOD	ENERGIZE OUTPUT TO DIRECT ACCESS CHANNEL	27, 28, 33, 34
0 06 200SR		SET EXTENSION REGISTER	19
10	MIY	M INTO Y BUFFER WHEN EMPTY	39
12	MIW	M INTO W BUFFER WHEN EMPTY	38
13	POT	PARALLEL OUTPUT	41
14	ETR	EXTRACT	11
16	MRG	MERGE	11
17	EOR	EXCLUSIVE OR	11
20	NOP	NO OPERATION	19
23	EXU	EXECUTE	19
30	YIM	Y BUFFER INTO M WHEN FULL	39
32	WIM	W BUFFER INTO M WHEN FULL	39
33	PIN	PARALLEL INPUT	41
35	STA	STORE A	8
36	STB	STORE B	8
37	STX	STORE INDEX	8
40	SKS	SKIP IF SIGNAL NOT SET	27, 37, 38, 42
0 40 1021n		MAGPAK TEST	58
0 40 10400	CIT 0	CHANNEL W INTER-RECORD TEST	For other channel codes, see page 38
0 40 1041n	TRT 0, n	TAPE READY TEST	57
0 40 11000	CET 0	CHANNEL W ERROR TEST; SKIP IF NO ERROR	For other channel codes, see page 37
0 40 11006	CFT 0, 1	CARD READER END-OF-FILE TEST	53
0 40 1101n	ETT 0, n	END OF TAPE TEST	58
0 40 11060	PFT 0, 1	PRINTER FAULT TEST	63
0 40 12000	CZT 0	CHANNEL W ZERO COUNT TEST; SKIP IF COUNT EQUALS ZERO	For other channel codes, see page 38
0 40 12006	CRT 0, 1	CARD READER READY TEST	53
0 40 1201n	BTT 0, n	BEGINNING OF TAPE TEST	57
0 40 12046	PBT 0, 1	PUNCH BUFFER TEST	53
0 40 12060	PRT 0, 1	PRINTER READY TEST	63
0 40 1261n	TGT 0, n	TAPE GAP TEST	58
0 40 13610	TFT 0	TAPE END-OF-FILE TEST	58
0 40 14000	CAT 0	CHANNEL W ACTIVE TEST; SKIP IF CHANNEL INACTIVE	For other channel codes, see page 37
0 40 14006	FCT 0, 1	FIRST COLUMN TEST	53
0 40 1401n	FPT 0, n	FILE PROTECT TEST	57
0 40 14046	CPT 0, 1	CARD PUNCH READY TEST	53
0 40 14060	EPT 0, 1	END OF PAGE TEST	63
0 40 1621n	DT2 0, n	DENSITY TEST, 200 BPI	58
0 40 1661n	DT5 0, n	DENSITY TEST, 556 BPI	58

<u>Instruction Code</u>	<u>Mnemonic</u>	<u>Name</u>	<u>Page References</u>
0 40 1721n	DT8 0, n	DENSITY TEST, 800 BPI	58
0 40 20001	OVT	OVERFLOW INDICATOR TEST AND RESET	19
0 40 20002	IDT	INTERRUPT DISABLED TEST	23
0 40 20004	IET	INTERRUPT ENABLED TEST	23
0 40 20010	BETW	W BUFFER ERROR TEST	37
0 40 20020	BETY	Y BUFFER ERROR TEST	37
0 40 20040	BPT4	BREAKPOINT NO. 4 TEST	19
0 40 20100	BPT3	BREAKPOINT NO. 3 TEST	19
0 40 20200	BPT2	BREAKPOINT NO. 2 TEST	19
0 40 20400	BPT1	BREAKPOINT NO. 1 TEST	19
0 40 21000	BRTW	W BUFFER READY TEST	37
0 40 22000	BRTY	Y BUFFER READY TEST	37
0 40 4000T		EXTENSION REGISTER TEST	20
41	BRX	INCREMENT INDEX AND BRANCH	14
43	BRM	MARK PLACE AND BRANCH	15
0 46 00001	CLA	CLEAR A	12
0 46 00002	CLB	CLEAR B	12
0 46 00003	CLR	CLEAR AB	12
0 46 00004	CAB	COPY A INTO B	12
0 46 00005	ABC	COPY A INTO B, CLEAR A	13
0 46 00010	CBA	COPY B INTO A	12
0 46 00012	BAC	COPY B INTO A, CLEAR B	13
0 46 00014	XAB	EXCHANGE A AND B	12
0 46 00020	CBX	COPY B INTO INDEX	13
0 46 00040	CXB	COPY INDEX INTO B	13
0 46 00060	XXB	EXCHANGE INDEX AND B	13
0 46 00122	STE	STORE EXPONENT	13
0 46 00140	LDE	LOAD EXPONENT	14
0 46 00160	XEE	EXCHANGE EXPONENTS	14
0 46 00200	CXA	COPY INDEX INTO A	13
0 46 00400	CAX	COPY A INTO INDEX	13
0 46 01000	CNA	COPY NEGATIVE INTO A	14
2 46 00000	CLX	CLEAR INDEX REGISTER X	13
50	SKE	SKIP IF E EQUALS M	15
51	BRR	RETURN BRANCH	15
52	SKB	SKIP IF M AND B DO NOT COMPARE ONES	16
53	SKN	SKIP IF M NEGATIVE	16
54	SUB	SUBTRACT	10
55	ADD	ADD M TO A	9
56	SUC	SUBTRACT WITH CARRY	10
57	ADC	ADD WITH CARRY	9
60	SKR	REDUCE M, SKIP IF NEGATIVE	16
61	MIN	MEMORY INCREMENT	9

<u>Instruction Code</u>	<u>Mnemonic</u>	<u>Name</u>	<u>Page References</u>
62	XMA	EXCHANGE M AND A	9
63	ADM	ADD A TO M	9
64	MUL	MULTIPLY	10
65	DIV	DIVIDE	11
0 66 00XXX	RSH	RIGHT SHIFT AB	17
0 66 20XXX	RCY	RIGHT CYCLE AB	17
0 66 24XXX	LRSH	LOGICAL RIGHT SHIFT AB	17
0 67 00XXX	LSH	LEFT SHIFT AB	18
0 67 10XXX	NOD	NORMALIZE AND DECREMENT INDEX	18
0 67 20XXX	LCY	LEFT CYCLE AB	18
70	SKM	SKIP IF A=M ON B MASK	15
71	LDX	LOAD INDEX	8
72	SKA	SKIP IF M AND A DO NOT COMPARE ONES	16
73	SKG	SKIP IF A GREATER THAN M	15
74	SKD	DIFFERENCE EXPONENTS AND SKIP	16
75	LDB	LOAD B	8
76	LDA	LOAD A	8
77	EAX	COPY EFFECTIVE ADDRESS INTO INDEX REGISTER	8

SDS 930 INSTRUCTION LIST — ALPHABETICAL ORDER

<u>Mnemonic</u>	<u>Instruction Code</u>	<u>Name</u>	<u>Page References</u>
ABC	0 46 00005	COPY A INTO B, CLEAR A	13
ADC	57	ADD WITH CARRY	9
ADD	55	ADD M TO A	9
ADM	63	ADD A TO M	9
AIR	0 02 20020	ARM INTERRUPTS	23
ALC 0	0 02 50000	ALERT CHANNEL W	For other channel codes, see page 33
ASC 0	0 02 12000	ALERT TO STORE ADDRESS IN CHANNEL W	For other channel codes, see page 33
BAC	0 46 00012	COPY B INTO A, CLEAR B	13
BETW	0 40 20010	W BUFFER ERROR TEST	37
BETY	0 40 20020	Y BUFFER ERROR TEST	37
BPT1	0 40 20400	BREAKPOINT NO. 1 TEST	19
BPT2	0 40 20200	BREAKPOINT NO. 2 TEST	19
BPT3	0 40 20100	BREAKPOINT NO. 3 TEST	19
BPT4	0 40 20040	BREAKPOINT NO. 4 TEST	19
BRM	43	MARK PLACE AND BRANCH	15
BRR	51	RETURN BRANCH	15
BRTW	0 40 21000	W BUFFER READY TEST	37
BRTY	0 40 22000	Y BUFFER READY TEST	37
BRU	01	BRANCH UNCONDITIONALLY	14
BRX	41	INCREMENT INDEX AND BRANCH	14
BTT 0,n	0 40 1201n	BEGINNING OF TAPE TEST	57
CAB	0 46 00004	COPY A INTO B	12
CAT 0	0 40 14000	CHANNEL W ACTIVE TEST; SKIP IF CHANNEL INACTIVE	For other channel codes, see page 37
CAX	0 46 00400	COPY A INTO INDEX	13
CBA	0 46 00010	COPY B INTO A	12
CBX	0 46 00020	COPY B INTO INDEX	13
CET 0	0 40 11000	CHANNEL W ERROR TEST; SKIP IF NO ERROR	For other channel codes, see page 37
CFT 0,1	0 40 11006	CARD READER END-OF-FILE TEST	53
CIT 0	0 40 10400	CHANNEL W INTER-RECORD TEST	For other channel codes, see page 38
CLA	0 46 00001	CLEAR A	12
CLB	0 46 00002	CLEAR B	12
CLR	0 46 00003	CLEAR AB	12
CLX	2 46 00000	CLEAR INDEX REGISTER X	13
CNA	0 46 01000	COPY NEGATIVE INTO A	14
CPT 0,1	0 40 14046	CARD PUNCH READY TEST	53
CRT 0,1	0 40 12006	CARD READER READY TEST	53

<u>Mnemonic</u>	<u>Instruction Code</u>	<u>Name</u>	<u>Page References</u>
CXA	0 46 00200	COPY INDEX INTO A	13
CXB	0 46 00040	COPY INDEX INTO B	13
CZT 0	0 40 12000	CHANNEL W ZERO COUNT TEST; SKIP IF COUNT EQUALS ZERO	38
DIR	0 02 20004	DISABLE INTERRUPT SYSTEM	23
DIV	65	DIVIDE	11
DSC 0	0 02 00000	DISCONNECT CHANNEL W	For other channel codes, see page 33
DT2 0, n	0 40 1621n	DENSITY TEST, 200 BPI	58
DT5 0, n	0 40 1661n	DENSITY TEST, 556 BPI	58
DT8 0, n	0 40 1721n	DENSITY TEST, 800 BPI	58
EAX	77	COPY EFFECTIVE ADDRESS INTO INDEX REGISTER	8
EFT n, 4	0 02 0367n	ERASE TAPE FORWARD	58
EIR	0 02 20002	ENABLE INTERRUPT SYSTEM	23
EOD	06	ENERGIZE OUTPUT TO DIRECT ACCESS CHANNEL	27, 28, 33, 34
EOM	02	ENERGIZE OUTPUT M	25, 26, 27, 28, 31, 34, 41
EOR	17	EXCLUSIVE OR	11
EPT 0, 1	0 40 14060	END OF PAGE TEST	63
ERT 0, n, 4	0 02 0767n	ERASE TAPE IN REVERSE	58
ETR	14	EXTRACT	11
ETT 0, n	0 40 1101n	END OF TAPE TEST	58
EXU	23	EXECUTE	19
FCT 0, 1	0 40 14006	FIRST COLUMN TEST	53
FPT 0, n	0 40 1401n	FILE PROTECT TEST	57
HLT	00	HALT	18
IDT	0 40 20002	INTERRUPT DISABLED TEST	23
IET	0 40 20004	INTERRUPT ENABLED TEST	23
IORD		I/O OF A RECORD AND DISCONNECT	35
IORP		I/O OF A RECORD AND PROCEED	35
IOSD		I/O UNTIL SIGNAL THEN DISCONNECT	35
IOSP		I/O UNTIL SIGNAL THEN PROCEED	36
LCY	0 67 20XXX	LEFT CYCLE AB	18
LDA	76	LOAD A	8
LDB	75	LOAD B	8
LDE	0 46 00140	LOAD EXPONENT	14
LDX	71	LOAD INDEX	8
LRSH	0 66 24XXX	LOGICAL RIGHT SHIFT AB	17
LSH	0 67 00XXX	LEFT SHIFT AB	18
MIN	61	MEMORY INCREMENT	9
MIW	12	M INTO W BUFFER WHEN EMPTY	38
MIY	10	M INTO Y BUFFER WHEN EMPTY	39
MRG	16	MERGE	11

<u>Mnemonic</u>	<u>Instruction Code</u>	<u>Name</u>	<u>Page References</u>
MUL	64	MULTIPLY	10
NOD	0 67 10XXX	NORMALIZE AND DECREMENT INDEX	18
NOP	20	NO OPERATION	19
OVT	0 40 20001	OVERFLOW INDICATOR TEST AND RESET	19
PBT 0, 1	0 20 12046	PUNCH BUFFER TEST	53
PCB 0, 1, 4	0 02 03646	PUNCH CARD BINARY	53
PCD 0, 1, 4	0 02 02646	PUNCH CARD DECIMAL (HOLLERITH)	53
PFT 0, 1	0 40 11060	PRINTER FAULT TEST	63
PIN	33	PARALLEL INPUT	41
PLP 0, 1, 4	0 02 02660	PRINT LINE PRINTER	63
POL 0, 1	0 02 10260	PRINTER OFF LINE	63
POT	13	PARALLEL OUTPUT	41
PPT 0, 1, 4	0 02 02644	PUNCH PAPER TAPE WITH NO LEADER	49
PRT 0, 1	0 40 12060	PRINTER READY TEST	63
PSC 0, 1, N	0 02 1N460	PRINTER SKIP TO CHANNEL N	63
PSP 0, 1, N	0 02 1N660	PRINTER SPACE N LINES	63
PTL 0, 1, 4	0 02 00644	PUNCH PAPER TAPE WITH LEADER	49
RCB 0, 1, 4	0 02 03606	READ CARD BINARY	53
RCD 0, 1, 4	0 02 02606	READ CARD DECIMAL (HOLLERITH)	53
RCY	0 66 20XXX	RIGHT CYCLE AB	17
REO	0 02 20010	RECORD EXPONENT OVERFLOW	18
REW 0, n	0 02 1401n	REWIND	58
RKB 0, 1, 4	0 02 02601	READ KEYBOARD	46
ROV	0 02 20001	RESET OVERFLOW	19
RPT 0, 1, 4	0 02 02604	READ PAPER TAPE	49
RSH	0 66 00XXX	RIGHT SHIFT AB	17
RTB 0, n, 4	0 02 0361n	READ TAPE IN BINARY	58
RTD 0, n, 4	0 02 0261n	READ TAPE IN DECIMAL (BCD)	58
RTS 0	0 02 14000	CONVERT READ TO SCAN	58
SFB 0, n, 4	0 02 0363n	SCAN FORWARD IN BINARY	58
SFD 0, n, 4	0 02 0263n	SCAN FORWARD IN DECIMAL (BCD)	58
SKA	72	SKIP IF M AND A DO NOT COMPARE ONES	16
SKB	52	SKIP IF M AND B DO NOT COMPARE ONES	16
SKD	74	DIFFERENCE EXPONENTS AND SKIP	16
SKE	50	SKIP IF A EQUALS M	15
SKG	73	SKIP IF A GREATER THAN M	15
SKM	70	SKIP IF A=M ON B MASK	15
SKN	53	SKIP IF M NEGATIVE	16
SKR	60	REDUCE M, SKIP IF NEGATIVE	16

<u>Mnemonic</u>	<u>Instruction Code</u>	<u>Name</u>	<u>Page References</u>
SKS	40	SKIP IF SIGNAL NOT SET	27, 37, 38, 42
SRB 0, n, 4	0 02 0763n	SCAN REVERSE IN BINARY	58
SRC 0, 1	0 02 12006	SKIP REMAINDER OF CARD	53
SRD 0, n, 4	0 02 0663n	SCAN REVERSE IN DECIMAL (BCD)	58
SRR 0	0 02 13610	SKIP REMAINDER OF RECORD	58
STA	35	STORE A	8
STB	36	STORE B	8
STE	0 46 00122	STORE EXPONENT	13
STX	37	STORE INDEX	8
SUB	54	SUBTRACT	10
SUC	56	SUBTRACT WITH CARRY	10
TFT 0	0 40 13610	TAPE END-OF-FILE TEST	58
TGT 0, n	0 40 1261n	TAPE GAP TEST, CHANNEL W	58
TOP 0	0 02 14000	TERMINATE OUTPUT OF CHANNEL W	33, 34
TRT 0, n	0 40 1041n	TAPE READY TEST	57
TYP 0, 1, 4	0 02 02641	WRITE TYPEWRITER	46
WIM	32	W BUFFER INTO M WHEN FULL	39
WTB 0, n, 4	0 02 0365n	WRITE TAPE IN BINARY	58
WTD 0, n, 4	0 02 0265n	WRITE TAPE IN DECIMAL (BCD)	58
XAB	0 46 00014	EXCHANGE A AND B	12
XEE	0 46 00160	EXCHANGE EXPONENTS	14
XMA	62	EXCHANGE M AND A	9
XXA	0 46 00600	EXCHANGE INDEX AND A	13
XXB	0 46 00060	EXCHANGE INDEX AND B	13
YIM	30	Y BUFFER INTO M WHEN FULL	39

SDS 930 INPUT/OUTPUT INSTRUCTIONS

Mnemonic	Octal Code	Name	Page Ref.	Mnemonic	Octal Code	Name	Page Ref.
INPUT/OUTPUT INSTRUCTIONS				MAGNETIC TAPE			
GENERAL				TRT C,U	0 40 10410	Tape Ready Test	57
EOM A	02	Energize Output M	26	FPT C,U	0 40 14010	File Protect Test	57
EOD A	06	Energize Output to Direct Access Channel	27	BTT C,U	0 40 12010	Beginning of Tape Test	57
MTW A,T	12	Memory into W when Empty	38	TGT C	0 40 12610	Tape Gap Test	58
MIY A,T	10	Memory into Y when Empty	39	ETT C,U	0 40 11010	End of Tape Test	58
PIN A,T	33	Parallel Input	41	DT2 C,U	0 40 16210	Density Test, 200 BPI	58
POT A,T	13	Parallel Output	41	DT5 C,U	0 40 16610	Density Test, 556 BPI	58
WIM A,T	32	W into Memory when Full	39	DT8 C,U	0 40 17210	Density Test, 800 BPI	58
YIM A,T	30	Y into Memory when Full	39	TFT C	0 40 13610	Tape EOF Test	58
CHANNEL					0 40 10210	MAGPAK Test	58
ALC C	0 02 50000	Alert Channel	33	RTD C,U,CC	0 02 02610	Read Tape Decimal (BCD)	58
DSC C	0 02 00000	Disconnect Channel	33	RTB C,U,CC	0 02 03610	Read Tape Binary	58
TOP C	0 02 14000	Terminate Output	33	RTS C	0 02 14000	Convert READ to Scan	58
BET W	0 40 20010	Buffer Error Test W	37	SRR C	0 02 13610	Skip Remainder of Record	58
BET Y	0 40 20020	Buffer Error Test Y	37	SFD C,U,CC	0 02 02630	Scan Forward Decimal (BCD)	58
BRT W	0 40 21000	Buffer Ready Test W	37	SFB C,U,CC	0 02 03630	Scan Forward Binary	58
BRT Y	0 40 22000	Buffer Ready Test Y	37	SRD C,U,CC	0 02 06630	Scan Reverse Decimal (BCD)	58
ASC C	0 02 12000	Alert to Store Address	33	SRB C,U,CC	0 02 07630	Scan Reverse Binary	58
CAT C	0 40 14000	Channel Active Test; Skip if Inactive	37	WTD C,U,CC	0 02 02650	Write Tape Decimal (BCD)	58
CET C	0 40 11000	Channel Error Test; Skip if no Error	37	WTB C,U,CC	0 02 03650	Write Tape Binary	58
CIT C	0 40 10400	Channel Inter-Record Test	38	EFT C,U,CC	0 02 03670	Erase Forward Tape	58
CZT C	0 40 12000	Channel 0 Count Test; Skip if Count=0	38	ERT C,U,CC	0 02 07670	Erase Reverse Tape	58
PERIPHERAL DEVICE INSTRUCTIONS AND TESTS				REW C,U	0 02 14010	Rewind	58
Octal Codes given are for the W Channel, device number 0 (bits 21-23), and 4 character/word mode (bits 15, 16).				LINE PRINTER			
PAPER TAPE				PRT C,U	0 40 12060	Printer Ready Test	63
RPT C,U,CC	0 02 02604	Read Paper Tape	49	EPT C,U	0 40 14060	End of Page Test	63
PTL C,U,CC	0 02 00644	Punch Paper Tape, Leader	49	PFT C,U	0 40 11060	Printer Fault Test	63
PPT C,U,CC	0 02 02644	Punch Paper Tape, No Leader	49	POL C,U	0 02 10260	Print Off-Line	63
CARD				PSC C,U,N	0 02 1N460	Printer Skip to Channel N	63
CRT C,U	0 40 12006	Card Reader Ready Test	53	PSP C,U,N	0 02 1N660	Printer Space N Lines	63
FCT C,U	0 40 14006	First Column Test	53	PLP C,U,CC	0 02 02660	Print Line Printer	63
RCD C,U,CC	0 02 02606	Read Card Decimal (Hollerith)	53	TYPEWRITER			
RCB C,U,CC	0 02 03606	Read Card Binary	53	RKB C,U,CC	0 02 02601	Read Keyboard	46
CFT C,U	0 40 11006	Card Reader EOF Test	53	TYP C,U,CC	0 02 02641	Write Typewriter	46
SRC C,U	0 02 12006	Skip Remainder of Card	53	OCTAL CODE CHANNEL SELECTION			
CPT C,U	0 40 14046	Card Punch Ready Test	53	Channel	EOM (02)	SKS (40)	
PBT C,U	0 40 12046	Punch Buffer Test	53	W	00000000	00000000	
PCD C,U,CC	0 02 02646	Punch Card Decimal (Hollerith)	53	Y	00000100	00000100	
PCB C,U,CC	0 02 03646	Punch Card Binary	53	C	20000000	20000000	
				D	20000100	20000100	
				E	00400000	00040000	
				F	00400100	00040100	
				G	20400000	20040000	
				H	20400100	20040100	

Legend:

A=address; T=tag field; C = channel number; U = unit number; CC = character/word count; N = number.

Add the appropriate entry to the octal code to select the channel.
Example: PCD (i. e. , 00202646) for channel G is 20602646.

SCIENTIFIC DATA SYSTEMS 1649 Seventeenth Street • Santa Monica, California • Phone (213) UP 1-0960

EASTERN

Maryland Engineering Center
12150 Parklawn Drive
Rockville, Maryland
(301) 933-5900

69 Hickory Drive
Waltham, Massachusetts
(617) 899-4700

1301 Avenue of the Americas
New York City, New York
(212) 765-1230

One Bala Avenue Building
Bala-Cynwyd, Pennsylvania
(215) 667-4944

SOUTHERN

Holiday Office Center
3322 South Memorial
Parkway
Huntsville, Alabama
(205) 881-5746

1325 North Atlantic Avenue
Cocoa Beach, Florida
(305) 784-1555

6434 Maple Avenue
Dallas, Texas
(214) 357-0451

3334 Richmond Avenue
Houston, Texas
(713) 526-2693

MIDWEST

3150 Des Plaines Avenue
Des Plaines, Illinois
(312) 824-8147

17500 W. Eight Mile Road
Southfield, Michigan
(313) 353-7360

Suite 222, Kimberly Building
2510 South Brentwood Blvd.
St. Louis, Missouri
(314) 968-0250

One Parkway Center
875 Greentree Road
Pittsburgh, Pennsylvania
(412) 921-3640

WESTERN

1360 So. Anaheim Blvd.
Anaheim, California
(213) 865-5293 (F.X.)
(714) 774-0461 (Local)

2526 Broadway Avenue
Santa Monica, California
(213) 870-5862

Sunnyvale Office Center
505 West Olive Avenue
Sunnyvale, California
(408) 736-9193

World Savings Building
1111 South Colorado Blvd.
Denver, Colorado
(303) 756-8505

Fountain Professional
Building
9000 Menaul Blvd., N. E.
Albuquerque, New Mexico
(505) 298-7683

Suite 100, Redwood Bldg.
845 106th Street, N. E.
Bellevue, Washington
(206) 454-3991

CANADA

864 Lady Ellen Place
Ottawa 3, Ontario
(613) 722-3242

AUSTRALIA

GEC Australia Pty. Limited
GPO Box 1594
104-114 Clarence Street
Sydney, NSW, Australia

ENGLAND

International Systems
Control Limited
East Lane
Wembley
Middlesex, England

FRANCE

CITEC
101 Boulevard Murat
Paris 16, France

JAPAN

F. Kanematsu & Co. Inc.
Central P. O. Box 141
New Kaijo Building
Marunouchi
Tokyo, Japan